

PANASONIC

NV-M25

MODEL

SERVICE MANUAL

Service Manual

General Description
Adjustment Procedures
Block/Schematic Diagrams
Exploded Views/Parts List

National **VHS** **HQ**

PAL

VHS Movie


NV-M1000 ^{EN}_{EM}

AC Adaptor


VW-AM10 ^{EN}_{EM}

Line Adaptor


VW-KM10EN



NV-M1000



VW-AM10



VW-KM10

National

Matsushita Electric Industrial Co., Ltd.
 Central P.O. Box 288, Osaka 530-91, Japan

INTRODUCTION

This service manual contains technical information which will allow service personnels to understand and service this model.

Section 1 presents you with some general information of features and controls, enabling you to become familiar with each function.

Section 2 contributes to your mechanical and electrical adjustment as well disassembly and replacement procedures.

In the case of very common information relating to other models like mechanical adjustments, please refer to each service manual.

Section 3 contains block diagrams which offers you information for checking and understanding each circuit. Schematic diagrams which give you detailed information such as waveforms, voltage data, function e.t.c...

Section 4 contains exploded views and parts list.

Please place orders using the parts list and not the drawing reference numbers.

If the circuit is changed or modified, this information will be followed by supplementary service manual to be filed with original service manual.

Technical Information

SERVICE CAUTION

1. PREPARATION FOR CAMERA ADJUSTMENT

Remove cabinet parts and remove camera section from VTR referring disassembly section and place them as shown in Fig. T1.

Connection of Extension Cable (A) (VFK0430) and Camera Holder (refer to next item) are necessary for servicing.




Fig. T1

2. HOW TO USE CAMERA HOLDER ARM (VEK0431)

This Camera Holder Arm which is adjustable the span must be mounted to VFK0382 (Camera Holder of NV-M5) and it can be used with VFK0432 for camera adjustments or checking for NV-M1000EN/EM.

- | | |
|------------------|----------------------|
| (A) --- VFK0613 | Holder Spacer (2pcs) |
| (B) --- VFK0431 | Camera Holder Arm |
| (C) --- XSN26+25 | Screw (2pcs.) |
| (D) --- VFK0382 | Camera Holder |

- (1) Fix the Holder Arm (4) and (5) temporarily by screw (1) as shown in Fig. T2.
- (2) Mount the Camera Holder Arm (B) to the Camera Holder (D) by screws (2) and (3) as shown in Fig. T3.
- (3) Tighten the screws (C) with the Holder Spacers (A) as shown in Fig. T2.




Fig. T3




Fig. T2

3. SERVICE THE CAMERA SECTION

When servicing the Camera Section, connection of 18Pin Extension Cables (B) (VFK0380X2pcs) is necessary as shown in Fig. T4.




Fig. T4

4. HOW TO REPLACE THE LENS UNIT

1. REPLACEMENT AND ADJUSTMENT PROCEDURES (REPLACEMENT OF FOCUS LENS UNIT)

- (1) Remove the Camera Unit from the VHS Movie.
- (2) Remove the C.B.As (Process, Auto Focus, Sensor) and Lens Cover from Camera Unit.
- (3) Unscrew the Screw (A) and remove the zoom Motor Unit.
- (4) Unscrew the Screw (B) and remove the Focus Motor Unit.
- (5) Unscrew the Screw (C) and remove the Focus Drive Unit.
- (6) Unscrew the Screw (D) and remove the Encoder C.B.A.
- (7) Unscrew the Screw (E) and remove the Lens Angle B.




Fig. T5

- (8) Remove the Focus Fastener and Tape as shown in below.
- (9) Remove the Focus Ring by turning the Focus Adjustment Pitch to the counter clockwise.




Fig. T6

- (10) Unscrew 4 Screws (F) and remove the Focus Lens Unit with Iris Unit as shown in below.
- (11) Remove the Iris Unit from Focus Lens Unit and replace the Focus Lens Unit.




Fig. T7

[ADJUSTMENT PROCEDURES]

Note:

Do not remove the Helicoid Lens from Focus Lens Unit because they have the relationship to be paired.
If the Helicoid Lens is happened to be removed, the Helicoid Lens should be installed as following step.

- a. Install the Helicoid Lens so that the projection with groove on Helicoid Lens comes to the portion "A" on lens unit as show in below.




Fig. T8




Fig. T9

- (12) After replacing the Focus Lens Unit, Install the Iris Unit to Focus Lens Unit.
- (13) Install the Focus Lens Unit with Iris Unit and then tighten 4 Screws (F) as shown in Fig. T7.
- (14) Adjust the Helicoid Lens position as follows.

- a. Turn the Helicoid Lens to fully clockwise and return it for approx. 20mm (so that next installation become easy) as shown in Fig. T9.

- (15) Install the Focus Ring so that the Portion "B" on Focus Ring comes to Projection with Groove on Focus Lens Unit as shown below.




Fig. T10

- (16) In order to lock the Focus Ring, Turn the Focus Adjustment Pitch to clock wise.




Fig. T11




Fig. T12

- (17) Install the Focus Fastener and Tape as shown in Fig. T6.
- (18) Install the C.B.As (Process, Auto Focus, Sensor, Encoder) and Zoom Motor in reverse assembly order.
- (19) After installation of the Focus Ring, Adjust the position of Back Focus Pitch as follows.
- Prepare the Hunting chart for object and aim the camera at the hunting chart 3m distance.
 - Focus the Lens on the object.
 - Confirm that Focus Ring indicates 3m.
 - Adjust the Back Focus Pitch so that the sharpest focus is obtained.
 - Zoom all the way back and adjust the Back Focus Pitch so that the sharpest focus is obtained.
 - Repeat the procedure as follows, Zoom In, Focus, Zoom Out and adjust the Back Focus Pitch until the best focus is obtained over the entire zoom range.

SERVICE INFORMATION

1-1. HOW TO CHECK THE CRACKED CHIP PART

- (1) Apply heat to the soldered portions of chip part using a soldering iron for about 2-3 seconds.
- (2) If the chip part is faulty, it will be broken or cracked.

Caution: Do not leave soldering iron on the PCB too long as damage may occur to the PCB or the chip parts.




FIG. G1

Note: Regarding intermittent faults
The main causes of these faults are poor soldering and cracked chip parts.

1-2. HOW TO REPLACE THE CHIP PART

1) REMOVAL (RESISTOR, CAPACITOR, etc...)

- (1) Presolder the one side of soldering portion for chip part and grasp the chip part by tweezers.
- (2) Melt the presoldered portion. And then remove the chip part with a twisting motion while melting the soldering portion of another side quickly.




FIG. G2

2) REMOVAL (transistor, diode, etc...)

- (1) Grasp the chip part with tweezers and melt the solder of one lead.




FIG. G3

- (2) Lift the side of that lead upward.




FIG. G4

Caution: Do not lift the chip part too high as damage may occur to the PCB or the leads that are still soldered on the PCB.

- (3) Simultaneously heat the solder of the two remaining leads and lift part to remove.




FIG. G5

3) INSTALLATION

- (1) Presolder the one side of contact point on the circuit board.




FIG. G6

- (2) To install the chip part, hold in position using tweezers, apply heat to the pre-soldered portions using a fine tip soldering iron.
- (3) Solder the other side of the chip part.
- (4) Check your soldering.




FIG. G7

1-3. HOW TO REMOVE THE FLAT-IC

(WITH HOT-AIR FLAT-IC DESOLDERING MACHINE)

(FOR EXAMPLE)




FIG. G8

- (1) Prepare the HOT-AIR FLAT-IC DESOLDERING MACHINE. And then apply hot air to FLAT-IC about 5 ~ 8 seconds.
- (2) Remove the FLAT-IC with tweezers while applying the hot air.

Caution: Do not supply the hot air to the chip parts around the Flat-IC for long time as damage may occur to the chip parts around the Flat-IC.




FIG. G9

(WITH SOLDERING IRON)

- (1) Using solder braid remove the solder from all pins of the Flat-IC. When you use the solder flux which is applied to all pins of the Flat-IC, you can remove it easily.




FIG. G10

- (2) Lift each lead of the Flat-IC upward one by one using a sharp pin or non solder wire (iron wire), while heating the pins using a fine tip soldering iron or a hot air blower.




FIG. G11

(WITH IRON WIRE)

- (1) Affix the wire to workbench or solid mounting point as shown in FIG. G12.
- (2) Pull up wire as the solder melts so as to lift the IC lead from the PCB contact pad, while heating the pins using a fine tip soldering iron or hot air blower.





FIG. G12

Note: When using a soldering iron care must be taken to ensure that the Flat IC is not being held by glue before it is the PCB may be damaged if force is used.

VHS Movie

NV-M1000^{EN}_{EM}



SPECIFICATIONS

ITEM	SPECIFICATION	ITEM	SPECIFICATION
POWER	Source: BATTERY; DC 12V Consumption; Recording mode; 8.7 W (Battery operation)	AUDIO	Head: 1 Stationary head (Normal Audio)
VIDEO RECORDING SYSTEM	4 rotary heads, helical scanning system PAL		Input: ADAPTOR (10P); -10 dB, 47 k Ω unbalanced MIC IN (M3); -70 dB, 4.7 k Ω unbalanced
TAPE FORMAT	VHS-C Cassette Tape (Tape width 12.7 mm)		Output: (PHONO Type); -8 dB 600 Ω unbalanced Head Phone (M3); -21 dB, 32 Ω unbalanced
TAPE SPEED	23.39 mm/s Record/Playback Time 24 min. with NV-E240 FF/REW Time less than 12 min. with NV-E180	WEIGHT	Approx. 2.7 kg (without Battery Pack)
CAMERA	Pick-up Element: CCD (Charge Coupled Device)	DIMENSIONS	134(W) $\times$ 228.8(H) $\times$ 429(D) mm
	Standard Illumination: 1,400 lux	STANDARD ACCESSORIES	1 pc. AV Output Cable
	Minimum Required Illumination: 10 lux		1 pc. AC Adaptor
	Lens: Built-in 8 : 1, Power Zoom Lens with MACRO Function, Auto Iris, Auto Focus System, F1.2 (8.5~68 mm), Lens Front Diameter/ ϕ 49 mm		1 pc. Battery Pack
	View Finder: 2/3" Electric View Finder		1 pc. Shoulder Strap
VIDEO	Heads: 4 rotary heads, 1 flying erase head		1 pc. Battery for Clock
	Input: ADAPTOR (10P); Y signal, 1.75 $\pm$ 0.05 Vp-p 1.5 k Ω DC 1.95 $\pm$ 0.2 V C Burst signal, 500 $\pm$ 75 mVp-p (RED/BURST) 1.75 $\pm$ 0.3 Vp-p) 22 k Ω DC 1.75 $\pm$ 0.2 V		1 pc. Cassette Tape
	Output: (PHONO Type); 1.0 Vp-p 75 Ω unbalanced		1 pc. DC Input Cable
			1 pc. System Carrying Case (NV-M1000EM Only)
			1 pc. Battery Pack Charging Connector
			1 pc. RF Adaptor
			1 pc. Power Plug Adaptor (NV-M1000EM Only)

Weight and dimensions shown are approximate.
Specifications are subject to change without notice.

CONTENTS

TECHNICAL INFORMATION

SERVICE INFORMATION

SECTION 1 GENERAL DESCRIPTION

1-1. CONTROLS AND COMPONENTS	1-1
1-2. VHS MOVIE SYSTEM ACCESSORIES	1-4

SECTION 2 ADJUSTMENT PROCEDURES

2-1. DISASSEMBLY PROCEDURES	2-1
2-2. REPLACEMENT PROCEDURES	2-8
2-3. MECHANICAL ADJUSTMENT PROCEDURES	2-11
2-4. ELECTRICAL ADJUSTMENT PROCEDURES	2-21
LOCATION OF TEST POINTS & CONTROLS (1)	2-35
LOCATION OF TEST POINTS & CONTROLS (2)	2-36

SECTION 3 BLOCK DIAGRAM & SCHEMATIC DIAGRAM

3-1. CAMERA STAGE BLOCK DIAGRAM	3-1
3-2. LUMINANCE & CHROMINANCE BLOCK DIAGRAM	3-5
3-3. SYSTEM CONTROL BLOCK DIAGRAM	3-9
3-4. SERVO BLOCK DIAGRAM	3-12
3-5. POWER SUPPLY BLOCK DIAGRAM	3-15
3-6. CAMERA OPERATION C.B.A.	3-17
3-7. CAMERA OPERATION SCHEMATIC DIAGRAM	3-19
3-8. E.V.F. SCHEMATIC DIAGRAM	3-21
3-9. E.V.F. C.B.A.	3-23
3-10. AWT SCHEMATIC DIAGRAM	3-25
3-11. AWT C.B.A.	3-25
3-12. PROCESS SCHEMATIC DIAGRAM	3-27
3-13. PROCESS C.B.A.	3-31
3-14. CCD DRIVE SCHEMATIC DIAGRAM	3-35
3-15. CCD DRIVE C.B.A.	3-37
3-16. AUTO FOCUS SCHEMATIC DIAGRAM	3-39
3-17. AUTO FOCUS C.B.A.	3-42
3-18. MAIN C.B.A. & VTR OPERATION C.B.A.	3-44
3-19. POWER SUPPLY SCHEMATIC DIAGRAM	3-50
3-20. SERVO SCHEMATIC DIAGRAM	3-52

3-21. SYSTEM CONTROL SCHEMATIC DIAGRAM	3-57
3-22. AUDIO SCHEMATIC DIAGRAM	3-61
3-23. AUDIO INTERFACE SCHEMATIC DIAGRAM	3-63
3-24. SUB VIDEO & HEAD AMP SCHEMATIC DIAGRAM	3-65
3-25. LUMINANCE & CHROMINANCE C.B.A.	3-68
3-26. LUMINANCE & CHROMINANCE SCHEMATIC DIAGRAM	3-71
3-27. VTR JACK SCHEMATIC DIAGRAM	3-75
3-28. VTR JACK C.B.A.	3-77
3-29. CIRCUIT BOARD LAYOUT	3-79
3-30. CAMERA INTERCONNECTION SCHEMATIC DIAGRAM	3-80
3-31. VTR INTERCONNECTION SCHEMATIC DIAGRAM	3-82
3-32. ICs & TRs INFORMATION	3-84

SECTION 4 EXPLODED VIEWS & PARTS LIST


4-1. EXPLODED VIEWS	4-1
❶ CAMERA LENS SECTION	4-1
❷ MECHANISM SECTION (1)	4-2
❸ MECHANISM SECTION (2)	4-3
❹ CHASSIS & FRAME SECTION	4-4
❺ E.V.F. SECTION	4-6
❻ PACKING PARTS & ACCESSORIES SECTION (NV-M1000EM)	4-7
❼ PACKING PARTS & ACCESSORIES SECTION (NV-M1000EN)	4-8
4-2. MECHANICAL REPLACEMENT PARTS LIST	4-9
4-3. ELECTRICAL REPLACEMENT PARTS LIST	4-12

SECTION 1


GENERAL DESCRIPTION

1-1. CONTROLS AND COMPONENTS

RIGHT VIEW




- ① White Balance Sensor Window
- ② Start/Stop Button
- ③ Power Zoom Control Button
- ④ Built-in Microphone
- ⑤ Tally Indicator
- ⑥ General Operation Controls



- ① Operation On/Off Switch
- ② Reset Button
- ③ Memory Button
- ④ Date Shift Button
- ⑤ Date Set Button
- ⑥ Tracking Adjust Buttons
- ⑦ Eject Switch

⑦ Tape Running Buttons




⑧ Camera/VTR Operation Selector Cover

Closed For camera recording.
Open (as illustrated) For other operations than camera recording.

- ⑨ Record Button
- ⑩ Rewind/Review Button
- ⑪ Play Button
- ⑫ Fast Forward/Cue Button
- ⑬ Audio Dubbing Button
- ⑭ Stop Button
- ⑮ Pause/Still Button


- ⑧ Lens Cap
- ⑨ Lens Hood
- ⑩ Iris Close/Open Control

When a Subject is backlit:
Turn in the "OPEN" direction.



•When shooting a backlit subject, be careful that the lens is not aimed at extremely bright light.


When the picture is too bright:
Turn in the "CLOSE" direction.



•For normal lighting conditions, this control should be set to the centre detent position. (Automatic adjustment)

- 11 Focus Ring
- 12 Zoom Ring
- 13 Manual Zoom Lever with Macro Button
- 14 Electronic Viewfinder

The following indications are displayed in the Electronic Viewfinder (EVF) to inform you of the operating conditions of the VHS Movie.



Warning/Alarm Indications — Recording Indication Lamp



There is little battery power left. The VHS Movie will be turned off in a few minutes. Replace the battery pack by a fully recharged one.



It is impossible to record because the erasure prevention tab of the cassette is not intact.



During recording, the tape has reached its end. Replace the tape with a new one.



When condensation has formed inside the VHS Movie, the "DEW" indication will flash and a few seconds later, the unit will turn itself off.



Video Head Clogging (see page 40).

1 Remaining Battery Power/Index Indication

E----F The "—" indications begin to disappear from right to left as the power of the battery pack weakens.

INDEX This indicator flashes when a recording is started or when the Index Signal Recording Button is pressed and it indicates that an index signal is being recorded.

2 Self-Timer/Interval Indication

SELF-20S Self-timer recording for 20 seconds.

SELF-END Self-timer recording until the end of the tape.

INTERVAL Recordings of approx. 1 second will be made at 1-minute intervals for up to 10 hours.

3 Counter Indication

M0123 Tape Counter

0:12.34 Lap Time Counter

4 Clock Indications

5 Date Indications

6 Camera Mode Indication

PAUSE Recording Pause,
Rec Review

REC Recording

<< Camera Search
(In reverse
direction)

> Camera Search
(In forward
direction)

VTR Mode Indication

<< Rewind/Review

>> Fast Forward/Cue

> Play

|| Still

INST> Insert

INST|| Insert Pause

A.DUB> Audio Dubbing

A.DUB|| Audio Dubbing Pause

REC> Recording

REC|| Recording Pause

7 High Speed Shutter Mode Indication

1/500 1/500 sec.

1/1000 1/1000 sec.

8 Manual White Balance Indication

OUT OUTDOOR

IN INDOOR

•Some of the above indications may light up alternately at the same place in the EVF to indicate the corresponding operating condition or warning.

15 Eyepiece Corrector Control

16 Fade Button

17 Date/Time Selector

18 Camera Search (-)/Rec Review Button

Camera Search for checking

longer recorded scenes.

Rec Review for a quick check

of the end of a recorded scene.

Camera Search Function

In the recording pause mode, a recorded scene can be played back at high speed in reverse direction by keeping the Camera Search (-) Button pressed (sound is not reproduced). And it can then be played back at normal speed in forward direction by keeping the Camera Search (+) Button pressed.

When the button is released, the VHS Movie will return to recording pause mode.

Rec Review Function

Press the Rec Review Button whilst the VHS Movie is in the recording pause mode.

•The last 2 seconds of the recorded scene will be played back and the VHS Movie will again stop in the recording pause mode, ready for further recording.

19 Camera Search (+)/Button

20 Focus Mode Selector

21 Focus Adjusting Button/Zone Selector

22 White Balance Mode Selector

23 Index Signal Recording Button

Notes about Recording the Index Signal (VISS)

The recording of index signals at the beginning of and during recordings makes possible the use of the VHS Index Search or the Intro Scan function when playing back the tape on a VTR equipped with the VISS function.

An index signal is recorded when one of the following operations is performed.


- When recording is started for the first time after the VHS Movie is turned on.
- When recording is restarted after the cassette is exchanged or the tape is played back.
- When the Index Signal Recording Button is pressed during recording.

In each of these cases, the "INDEX" indication will flash for a few seconds in the EVF.

•When recording index signals, space the signals at least 2 minutes.

24 Timer/Interval Recording Button

■ Pressing the Timer/Interval Recording Button repeatedly:



- Depending on the TV set used, the top of the picture may become distorted when playing back scenes shot with the interval recording function.

Self-Timer Recording

10 Seconds after the self-timer function is activated on the VHS Movie, the recording will start.

If the VHS Movie is mounted on a tripod, this handy function allows the person behind the camera to join the action that is being recorded.

- 1 Press the Timer/Interval Recording Button during recording pause to select the desired recording mode.
 - When the Timer/Interval Recording Button is pressed once, "SELF-20S" will appear in the EVF, and when the button is pressed twice, "SELF-END" will appear in the EVF.
- 2 Press the Start/Stop Button and the self-timer recording will start 10 seconds later.
 - When "SELF-20S" is indicated, the recording will be made for 20 seconds.
 - When "SELF-END" is indicated, the recording will be made until the tape reaches its end.

To stop the Self-Timer Recording Midway

Press the Start/Stop Button, and the self-timer recording will be cancelled.

Interval Recording

This recording function automatically makes recordings of approx. 1 second duration at 1-minute intervals. (However, the initial recording will last for about 10 seconds.) The interval recording will continue for a maximum of 10 hours, after which the VHS Movie will turn itself off.

- 1 Press the Timer/Interval Recording Button three times during recording pause mode.
- 2 Press the Start/Stop Button.


To stop the Interval Recording Midway

Press the Start/Stop Button, and the interval recording will be cancelled.

25 High Speed Shutter Selector

26 Standby Button with Indicator

LEFT VIEW



- 27 Metal Fitting for Shoulder Strap
- 28 Accessory Shoe
- 29 Metal Fitting for Shoulder Strap
- 30 Microphone Sensitivity Selector
- 31 Earphone Socket
- 32 External Microphone Socket
- 33 Edit Switch
- 34 Remote Control Socket
- 35 Battery Eject Button
- 36 Battery Compartment
- 37 Battery Compartment for Auto Date/Clock
- 38 Cassette Compartment
- 39 Tripod Receptacle
- 40 EVF/Character Generator Terminal
- 41 Start/Stop Button
- 42 Handgrip
- 43 Grip Belt
- 44 Edit Socket
- 45 Adaptor Socket
- 46 Video Output Socket
- 47 RF DC Output Socket
- 48 Audio Output Socket
- 49 DC Input Socket

1-2. VHS MOVIE SYSTEM ACCESSORIES

MEMO:

Standard Accessories

○ : Supplied
× : Not Supplied

	NV-M1000EN	NV-M1000EM
AC Adaptor	○	○
Battery Pack	○	○
Shoulder Strap	○	○
System Carrying Case	×	○
AV Output Cable	○	○
Battery Pack Charging Connector	○	○
Battery for Clock Operation	○	○
DC Input Cable	○	○
RF Adaptor	○	○

Optional Accessories

Line Adaptor (VW-KM10EN)

Pause Remote Contral Unit (VW-RM1)

System Carrying Case
(VW-SHM10EN: NV-M1000EN)

Character Generator (VW-CG2)

Shoulder Pad (VW-SP7)

Car Battery Cord (VW-ACM10EN/EM)

SECTION 2

ADJUSTMENT PROCEDURES

2-1. DISASSEMBLY PROCEDURES

Note:

2-1-1. DISASSEMBLY FLOW CHART

This flow chart indicates disassembly steps for the cabinet parts and the P.C. boards in order to find the items necessary for servicing. When reassembling perform the steps in the reverse order.

- (1) When removing the cabinet, work with care so as not to break the locking tabs.
- (2) Place a cloth or some other soft material under the P.C. boards or Unit to prevent damage.
- (3) When re-installing, ensure that the connectors are connected and electrical components have not been damaged.
- (4) Do not supply power to the Unit during disassembly.




Fig. D1

2-1-2. DETAILED DISASSEMBLY METHOD

1. REMOVAL OF E.V.F. UNIT

- (1) Remove the E.V.F. Unit connector.
- (2) Slide the E.V.F. Unit in the direction shown by the arrow.
- (3) Remove the E.V.F. Unit while pushing on the Locking Lever on the bottom of the Unit.




Fig. D2

2. REMOVAL OF MIC UNIT

- (1) Remove 2 Screws (A) and (B).
- (2) Slide the MIC Unit in the direction shown by the arrow.
- (3) Disconnect the connector on the MIC Unit.




Fig. D3

3. REMOVAL OF CASSETTE COVER

- (1) Remove 2 Screws (C).
- (2) Pull the Cassette Cover straight up to remove.




Fig. D4

Note:

Be carefull not to damage the Locking Portions when removing or realigning the Cassette Cover.

4. REMOVAL OF SIDE CASE (R) UNIT

- (1) Remove 2 Screws (D) shown in Fig. D3.
- (2) Remove the E.V.F. Base Case.
- (3) Remove 2 Screws (E), 2 Screws (F), 2 Screws (G) and Screw (H).
- (4) Lift the Side Case (R) Unit slightly. Then disconnect 4 Connectors on the Side Case (R) Unit.




Fig. D5

5. REMOVAL OF SIDE CASE (L) UNIT

- (1) Remove Screw (I), 2 Screws (J) and 2 Screws (K) shown in Fig. D4.
- (2) Remove the Lens Hood and then remove Screw (L) shown in Fig. D6.
- (3) Lift the Side Case (L) Unit slightly. Then disconnect the Connector.




Fig. D6

6. REMOVAL OF OPERATION PANEL UNIT

- (1) Unlock 4 Locking Tabs (M).
- (2) Lift the Operation Panel Unit up slightly.




Fig. D7

7. OPENING OF OPERATION/MAIN C.B.A.

- (1) Remove 2 Screws (N) and then unsnap 5 Locking Tabs (O).
- (2) Open the Operation / Main C.B.A. slightly.
- (3) Disconnect the Connector P6016 on Main C.B.A.




Fig. D8

8. OPENING OF LUMINANCE/CHROMINANCE C.B.A.

- (1) Unlock the Locking Portions (P) shown in Fig. D8 and then open the Luminance / Chrominance C.B.A. slightly.

9. REMOVAL OF CAMERA OPERATION C.B.A.

- (1) Remove 4 Screws (R) and 2 Screws (S).
- (2) Unsnap 5 Locking Tabs (T) and then lift the Camera Operation C.B.A. up slightly.




Fig. D9

10. REMOVAL OF START/STOP SW C.B.A. AND ZOOM SW C.B.A.

- (1) Remove 2 Screws (U) and Screw (V).
- (2) Unlock 4 Locking Portions (W) and then remove the Grip Unit slightly.




Fig. D10

- (3) Unlock the Locking Portion (X) and then lift the Start/Stop SW C.B.A. up slightly.
- (4) Remove 2 Screws (Y) shown in Fig. D10 and then remove the Zoom SW Unit.
- (5) Unlock 2 Locking Portions (Z) and then lift the Zoom Button up slightly.
- (6) Remove the Zoom SW C.B.A.




Fig. D11

11. OPENING OF BATTERY CASE UNIT

- (1) Open the Operation/Main C.B.A. shown in Fig. D12.
- (2) Remove 3 Screws (a) and 2 Screws (b). Then lift the Battery Case Unit slightly in order to release it from 2 Locking Pins (c).
- (3) Loosen wires located around the Battery Case Unit.




Fig. D12

12. REMOVAL OF HANDLE UNIT

- (1) Remove 4 Screws (d) and 3 Screws (e) shown in Fig. D12.
- (2) Remove the Handle Unit.

13. REMOVAL OF CASSETTE COMPARTMENT UNIT

- (1) Remove 4 Screws (f) and then remove the Cassette Compartment Unit.

Note:

When re-installing the Cassette Compartment Unit, install it in the closed (cassette down) condition.




Fig. D13

14. REMOVAL OF CAMERA UNIT

- (1) Remove 2 Screws (g).
- (2) Disconnect the Connector P3804 and Flexible Connector P3802 on Main C.B.A.




Fig. D14

15. REMOVAL OF CAMERA ANGLE

- (1) Remove 2 Screws (h) and Screw (i).
- (2) Remove the Camera Angle.




Fig. D15

16. REMOVAL OF AWT CASE UNIT

- (1) Remove 2 Screws (j), Screw (k) and Screw (l).
- (2) Remove the AWT Case Unit.




Fig. D16

17. REMOVAL OF CAMERA C.B.A.

- (1) Remove 5 Screws (m) on Auto Focus and Process C.B.A.'s.
- (2) Disconnect Connectors B301, B305.
- (3) Lift the Process C.B.A. up slightly and then disconnect the flexible wire FP310 on Process C.B.A.
- (4) Remove the Process C.B.A.
- (5) Disconnect Connectors P701, P702, P704 and P705 on Auto Focus C.B.A.
- (6) Remove the Auto Focus C.B.A.




Fig. D17

18. REMOVAL OF SENSOR C.B.A.

- (1) Remove 2 Screws (n) shown in Fig. D16.
- (2) Using soldering iron remove the solder from solder portion "A", and then remove the sensor frame Shield Barrier.
- (3) Remove 2 Screws (o).
- (4) Lift the Sensor C.B.A. up slightly and then disconnect the Flexible Wire FP201 on Sensor C.B.A.




Fig. D18

19. REMOVAL OF CCD UNIT

- (1) Remove 3 Screws (p) and Screw (g). And Then remove the Sensor C.B.A. Flame.
- (2) Remove 2 Screws (r) and then remove the Sensor Flame.




Fig. D19

- (3) Remove 2 Screws (s) and then remove the CCD Unit.




Fig. D20

20. REMOVAL OF ACTUATOR UNIT

- (1) Remove 3 Screw (t) and then remove the Actuator Unit.




Fig. D21

21. DISASSEMBLY OF E.V.F. UNIT

- (1) Remove 3 Screws (u) on the bottom of the E.V.F. Unit and then remove the Bottom Case.
- (2) Remove CRT Top Case from CRT Bottom Case shown in Fig. D22.




Fig. D22

- (3) Lift the CRT Assembly up shown in Fig. D23.




Fig. D23

- (4) Rotate Nut (v) and then pull DY Assembly in the direction shown in Fig. D24 to remove it. Then the CRT can be replaced.
- (5) For re-installation, reverse the above steps.




Fig. D24

22. REMOVAL OF VTR JACK UNIT

- (1) Remove 2screws (w) show in Fig.D25.
- (2) Disconnect Connectors P4901, P4901, P4904, P4906 and P4934 on VTR JACK UNIT.




Fig. D25

23. REMOVAL OF VTR JACK C.B.A.

- (1) Using Soldering Iron remove the solder from EDIT pins (5pins), ADAPTOR pins (10pins), VIDEO pins (2pins), RF DC OUT pins(3pins), AUDIO pins (2pins) and DC IN 12V pins (5pins) on the VTR JACK C.B.A.
- (2) Remove 2 screws (x).
- (3) Remove the VTR JACK C.B.A.




Fig. D26

2-2. REPLACEMENT PROCEDURES

2-2-1. REPLACEMENT OF CCD UNIT

- (1) After removing of the CCD Unit install the new CCD Unit.
- (2) Assemble the unit subject to the reverse steps of disassembly procedures.

NOTE:

- (1) Do not touch the sureface of CCD Unit.
- (2) Confirm the Whole adjustment procedures for Camera Section after replacing this CCD Unit.

2-2-2. REPLACEMENT OF ZOOM MOTOR UNIT

- (1) Remove the Screw (A) and then remove the Zoom Motor Unit.
- (2) Install the new Zoom Motor Unit.
Prior to this replacement, no dust around the Zoom Motor, especially around the gear unit should be confirmed.

2-2-3. REPLACEMENT OF FOCUS MOTOR UNIT

- (1) Remove the Screw (B) and then remove the Focus Motor Unit.
- (2) Install the new Focus Motor Unit.
Prior to this replacement, no dust around the Focus Motor Unit, especially around the gear should be confirmed.
- (3) After this replacement, all the correct adjustments for all parts of auto-focus should be confirmed.




Fig. R1

2-2-4. REPLACEMENT OF CAPSTAN MOTOR UNIT

- * Equipment required:
Reel Table Height Gauge (VFK0190)
- * Specification... $0.5 \pm 0.05\text{mm}$




Fig. R2

- (1) Remove the 2 screws and take belt cover off. After that remove the capstan belt.
- (2) Tighten the Thrust Adjust Screw fully and pull the capstan rotor.

Note :

In this time pay attention not to lose two pieces of Dust Seal.

- (3) Replace the new rotor with two pieces of Dust Seal.

Note :

- (1) Pay attention to the replaced new rotor not to shock because of magnet absorbtion. So hold the rotor firmly and replace it carefully.
- (2) In this replacement, do not touch the Capstan shaft with any hard material like drivers or tweezers.

- (4) After replacement, wipe off the Capstan shaft to remove oil, grease or dust.
- (5) Unscrew Thrust Adjust Screw till the rotor is just touching to the stator.
- (6) Turn this mechanism upside down and place the Reel Table Height Gauge so that the gauge fits to the chassis correctly, and read the height.
- (7) Adjust the Thrust Adjust Screw so that the height difference just meets in the specification ($0.5 \pm 0.005\text{mm}$) reading the height from the gauge.




Fig. R3

Note:

If the Thrust Adjust Screw is fully opened, you have to pay attention not to lose Thrust Bearing. When it is fixed, confirm that the direction of Thrust Bearing is correct as shown below.




Fig. R4

2-2-5. REPLACEMENT OF TENSION BAND

- (1) Remove the cassette compartment.
- (2) Remove a retaining ring and take out a Rew Arm (A) Unit.
- (3) Remove a retaining ring and a snap washer and take out a tension Band Unit.




Fig. R5

- (4) Remove a Tension Band from Band Release Arm and Tension Arm Unit.
















Fig.R6

- (5) Replace a new Tension Band by Proceeding reverse steps shown above.

2-3. MECHANICAL ADJUSTMENT PROCEDURES

1. SERVICING FIXTURES & TOOLS

VFK0326 Hex Wrench Set (0.7, 0.9, 1.2, 1.5, 1.6, 2, 2.4, 3mm) 	VFJ8125H3F VHS Alignment Tape 	VFK0335 Retaining Ring Remover (3mm/4mm) 
VFK0191 Post Adjustment Plate 	VFK0190 Reel Table Height Gauge 	VFK0328 H-Position Adj. Fixture 
VFK0329 Post Adjustment Screwdriver 	VFK0157 Fine Adjustment Screwdriver  Approx. 2.5mm. Grind the top portion approximately 2.5mm	VFK0133 Dial Torque Gauge VFK0134 Adaptor for VFK0133 VFK0180 (Plastic Clamper Only) 
VFK0343 Check Light 	VFK0132 Back Tension Meter (TZ-H7-UM) (Tentelometer, Made in U.S.A.) 	VKF27 Head Cleaning Stick 
MOR265 Morlytone Grease 	High Quality Machine Oil <Purchase Locally> (Reel Shaft, Capstan Shaft etc.) Cleaning Liquid (Freon, TF, Alcohol) <Purchase Locally> (Tape Transport Rubber Parts etc.)	

2. PROCEDURES FOR CLEANING OF UPPER CYLINDER UNIT

- (1) Position the video head to clean and hold the upper cylinder to keep it from turning while cleaning.
- (2) Gently rub the video head in direction of tape travel with Head Cleaning Stick.
- (3) Repeat for the other three video heads.




Fig. U1


Note:

- (1) Do not rub vertically.
- (2) Do not apply any pressure to heads. If contamination is not easily removed, continued gentle wiping will usually remove the substance.

3. TAPE INTERCHANGEABILITY ADJUSTMENT PROCEDURES

3-1. ADJUSTMENT FLOW CHART

This flow chart describes the order of steps for adjusting the tape guide posts and A/C head in order to gain access to the items needing servicing.



AFTER REINSTALLING THE UPPER CYLINDER OR CYLINDER UNIT.

3-2-5. CONFIRMATION OF THE ENVELOPE OUTPUT.

3-2-9. FINE ADJUSTMENT OF THE A/C HEAD HORIZONTAL POSITION (X-VALUE).

* Note:

Do not change the height of the P1 and P4 posts and position of the A/C head.

AFTER REINSTALLING ALL POSTS OR IF ALL POSTS HAVE BEEN TURNED EXTREMELY.

3-2-1. COARSE ADJUSTMENT OF THE TAPE GUIDE POST HEIGHTS.

3-2-2. CONFIRMATION OF THE TAPE TRANSPORT.

3-2-3. ADJUSTMENT OF THE PULL-OUT POST (P5 POST) HEIGHT.

3-2-4. CONFIRMATION OF THE A/C HEAD TILT.

3-2-5. CONFIRMATION OF THE ENVELOPE OUTPUT.

AFTER REINSTALLING THE A/C HEAD.

3-2-4. CONFIRMATION OF THE A/C HEAD TILT.

* Note:

Do not change the height of P4 post.

3-2-6. COARSE ADJUSTMENT OF THE A/C HEAD HEIGHT.

3-2-7. ADJUSTMENT OF THE A/C HEAD HEIGHT AND AZIMUTH.

3-2-8. COARSE ADJUSTMENT OF THE A/C HEAD HORIZONTAL POSITION (X-VALUE).

3-2-9. FINE ADJUSTMENT OF THE A/C HEAD HORIZONTAL POSITION (X-VALUE).

AFTER REINSTALLING THE P4 POST, OR IF THE P4 POST HAS BEEN TURNED EXCESSIVELY.

3-2-1. COARSE ADJUSTMENT OF THE TAPE GUIDE POST HEIGHTS.

* Note:
Adjust the P4 post only.

3-2-2. CONFIRMATION OF THE TAPE TRANSPORT.

* Note:
Adjust the P4 post only.

3-2-4. CONFIRMATION OF THE A/C HEAD TILT.

3-2-5. CONFIRMATION OF THE ENVELOPE OUTPUT (LINEARITY).

AFTER REINSTALLING THE PULL-OUT POST (P5 POST).

3-2-3. ADJUSTMENT OF THE PULL-OUT POST (P5 POST).

* Note:
Do not readjust any other post.

3-2. ADJUSTMENT PROCEDURES

3-2-1. COARSE ADJUSTMENT OF THE TAPE GUIDE POST HEIGHT (P1, P2, P3 AND P4)

* Equipment Required:
Post Adjustment Plate.....VFK0191
Reel Table Height Gauge.....VFK0190
Nut Driver (Purchase locally)
Post Adjustment Screwdriver.....VFK0329

1. Remove the cassette compartment from the mechanical chassis.
2. Place the Post Adjustment Plate over the reel tables.
(Fig. M1)
Confirm that the Post Adjustment Plate is firmly seated.




Fig. M1

3. Lower all 4 tape guide posts so that the lower tape guide on each post is below the top surface of the adjustment plate.
Use the post Adjustment screwdriver to lower posts P2 and P3, and the Nut Driver to lower Posts P1, P4 and P5.
4. Place the Reel Table Height Gauge on the Post Adjustment Plate and lower the scraper so that it touches the plate (Fig. M2).




Fig. M2

5. Place the side of the scraper against the each post as shown in Figure M3, set the gauge to zero, then slowly raise the post until the lower tape guide just touches the bottom of the scraper. Use the gauge to determine the exact point at which the lower tape guide touches the scraper. (Fig. M3)




Fig. M3

3-2-2. CONFIRMATION OF THE TAPE TRANSPORT (TAPE GUIDE POSTS)

* Note:

1. The tape guide posts have been precisely adjusted at the factory. Therefore, normally do not change the height of P1, P4 and P5 posts. The following adjustment is required only when replacing the posts.
2. If curling is apparent proceed to the P4 post, wipe dirt from the pressure roller and capstan shaft using a soft cloth impregnated with Freon TF or cleaning liquid.
3. The adjustment of the post height is required only the one which has been replaced.

* Equipment Required
 Post Adjustment Screwdriver.....VFK0329
 Check Light.....VFK0343
 Nut Driver (Purchase locally)

1. To prevent the alignment tape from being damaged, use a normal cassette tape for this procedure. Playback the normal cassette tape and confirm that the tape travels without any curling at the edges of all the posts by using the check light. (Fig. M4 and Fig. M5)




Fig. M4 Tape Transport Posts




Fig. M5 Tape Guide Posts

2. If curling is apparent, adjust the height of posts by turning the top of post with the post adjustment screwdriver (posts P2 and P3) or the nut-driver (Posts P1 and P4). (Fig. M4 and M5)
3. After adjusting the P4 post, adjustment of the pull-out post (P5) is required. (Refer to "ADJUSTMENT OF THE PULL-OUT POST HEIGHT".)
4. If the tape curling cannot be corrected by adjusting the tape guide posts, then adjustment of the A/C head tilt may be needed.

3-2-3. ADJUSTMENT OF THE PULL-OUT POST (P5 POST) HEIGHT

* Notes:

1. This adjustment should be performed only after adjusting tape guide post P4 as the height of the pull-out post is based on the height of post P4.
- * Tools and Equipment Required:
 Post Adjustment Plate.....VFK0191
 Reel Table Height Gauge.....VFK0190
 Check Light.....VFK0343
 Nut Driver (Purchase locally)




Fig. M6

1. Remove the cassette compartment by unscrewing 4 screws. Unit.
2. Place the Post Adjustment plate over the reel tables.
3. Place the Reel Table Height Gauge on the tape guide post P4, lower the scraper so that it touches the lower edges of P4, then set the gauge to zero ("0"). (Fig. M6)
4. Slightly lower the pull-out post by turning the nut on the post clockwise with the nut driver, and set the side of the scraper against the post as shown in Fig. M7.
5. Slowly turn the nut on the post counterclockwise until the gauge reads 0mm. (Fig. M6)
6. Confirm there is no tape curling at P4 post during reverse mode by using the check light. If tape curling occurs, back to step 3.




Fig. M7 Post Adjustment

3-2-4. CONFIRMATION OF THE A/C HEAD TILT

* Note:

This procedure should be performed after replacing the A/C head and pressure roller, and adjusting the height of the tape guide post (P4). (Refer to "COARSE ADJUSTMENT OF THE TAPE GUIDE POST HEIGHTS".)

* Tools and Equipment Required:
 Hex. Wrench Set.....VFK0326
 Nut Driver (purchase locally)

1. Play back the beginning portion of NV-E240 blank cassette tape and confirm that the tape runs between lower and upper limiters of the P4 post. If there is waving or frilling in the lower edge or top edge of the tape, correct the tilt of the A/C head by turning the screw located behind the A/C head. (Fig. M8)




Fig. M8

2. If the tape curling cannot be accomplished by adjusting the A/C head tilt, then readjustment of the height of the tape guide post (P4) may be needed.

* Notes:

1. The tape guide post (P4) has been precisely adjusted at the factory. Therefore, normally the tape guide post (P4) readjustment is not required to eliminate the tape curling.
2. After adjusting the A/C head tilt, the A/C head height adjustment is required.

3-2-5. CONFIRMATION OF THE ENVELOPE OUTPUT (LINEARITY)

* Note:

Before playing back the alignment tape, play back a normal cassette tape and confirm correct transport. (Refer to "CONFIRMATION OF THE TAPE TRANSPORT".)

* Tools and Equipment Required:
Post Adjustment Screwdriver.....VFK0329
Alignment Tape.....VFJ8125H3F

1. Connect the scope to the output of the Head Amp (TP3001) on the Main C.B.A. and TP2001 on the same C.B.A. to EX + - Trigger of the scope.
2. Play back the monoscope portion of the alignment tape VFJ8125H3F.
3. Turn the Tracking Control VR and adjust for maximum RF envelope.
4. If the RF envelope appears like example "A" or "B" in Fig. M9, then adjustment of tape guide post (P2 : Entrance) is necessary.
5. Adjust the tape guide post (P2) with the post adjustment screwdriver so that the RF envelope waveform at the entrance portion becomes flat as shown "C" in Fig. M9. (See Fig. M12 also)




Fig. M9

6. If the RF envelope appears like example "D" or "E" in Fig. M10, then adjustment of the tape guide post (P3 : Exit) is necessary.
7. Adjust the tape guide post (P3) in the same manner as the P2 post so that the exit portion becomes flat as shown in "F" in Fig. M10.




Fig. M10

8. Turn the Tracking VR from end to end. The variation of RF envelope should be nearly parallel as shown in Figure M11.
9. Turn the Tracking VR and adjust for maximum RF envelope. If the RF envelope does not meet these specs, V1/V 0.7, V2/V 0.8, then repeat steps 1-9 of item 3-2-5. again. (Fig. M13)




Fig. M11




Fig. M12 Loading of post




Fig. M13 Spec. of Envelope Figure

10. Turn the Tracking VR from end to end again and then back to the detent (Fix) position. At the detent position, the RF envelope waveform should be at maximum. If it is not at maximum then "ADJUSTMENT OF THE A/C HEAD HORIZONTAL POSITION" is necessary. (Refer to "FINE ADJUSTMENT OF THE A/C HEAD HORIZONTAL POSITION".)

3-2-6. COARSE ADJUSTMENT OF THE A/C/ HEAD HEIGHT

* Note:

This procedure should be performed only when the A/C Head is replaced.

* Tools and Equipment Required:

Check Light.....VFK0343
Nut Driver (Purchase locally)

- (1) Looking at the lower edge of the control head within the tape running, ensure that lower edge of the tape runs along 0.25mm far from lower edge of the control head. (little bit up position from lower edge of control head.) If it doesn't, slightly turn the nut (A) in either direction to correct clockwise to lower the head and counterclockwise to raise it.




Fig. M14

3-2-7. ADJUSTMENT OF THE A/C HEAD AND AZIMUTH

* Note:

This procedure should be performed only when the A/C Head is replaced and posts height are readjusted.

* Tools and Equipment Required:

Nut Driver (Purchase locally)
Alignment Tape.....VFJ8125H3F

1. Connect the scope to the audio output. (TP4001)
2. Play back the 2nd portion (Normal Audio 6KHz) of the alignment tape, VFJ8125H3F.
3. Adjust the screw (B) so that the audio output level at TP4001 becomes maximum. (Fig. M15)




Fig. M15

4. Then adjust the nut (A) so that the audio output level (at TP4001) maximum.

3-2-8. ADJUSTMENT OF A/C HEAD HORIZONTAL POSITION

Note:

This procedure should be performed only when the A/C head is replaced and after performing the tape interchangeability adjustment.

* Tools and Equipment Required:

H. Position Adj. Fixture.....VFK0328
Alignment Tape.....VFJ8125H3F

1. Set the Tracking Control VR to the center detent (fixed) position.
2. Connect the scope CH1 to TP3001 on the Main C.B.A., and TP4001 on the Audio C.B.A. to Ext-trigger the scope.
3. Play back the Monoscope pattern of the alignment tape (VFM8125H3F).
4. Adjust the adjust screw so that the RF envelope output level becomes maximum at the detent position (Fig. M16, M17).
5. Turn the Tracking VR from end to end and then back to the detent position. Confirm that the RF envelope output level is maximized at the detent position. (Fig. M11)




Fig. M16




Fig. M17

4. OTHER ADJUSTMENT PROCEDURES

4-1. CONFIRMATION OF BRAKE TORQUE

* Equipment Required:

Dial Torque Gauge.....VFK0133

Adaptor for Gauge.....VFK0134

* Specification:-----see spec table (Fig. M19).

- (1) Remove the cassette compartment by unscrewing 4 screws.
- (2) Attach the adaptor to the torque gauge and place the unit in STOP mode.
- (3) Place the torque on the reel table. The weight of gauge should not rest on the reel table.




Fig. M18

- (4) Turn torque gauge in either direction indicated in the Fig. M19, and read the gauge when the brake begins slipping.

Note:

If proper brake torque can not be obtained, check the both take-up and supply clutch gear.




Fig. M19

4-2. TENSION POST POSITION ADJUSTMENT

* Specification : -----2.4mm~2.9mm

- (1) Remove the Cassette Up unit by unscrewing 4 screws. (Refer to the disassembly procedures titled in Removal of the Cassette Up Unit). Place the unit in Play mode by rotating Drive Gear (A) in clockwise shown below.




Fig. M20

Note:

In this case, make sure that the power is not applied.

- (2) Loosen the screw (A) a little bit and adjust the Tension Post adjustment plate so that the "Distance (A)" shown below becomes just meet in the specification (2.4mm~2.9mm).
- (3) Tighten the screw (A) to fix it.




Fig. M21

4-3. BACK TENSION ADJUSTMENT

* Equipment Required:

Back Tension Meter.....VFK0132

VHS Cassette Tape (120min.)

* Specification:-----19~23g

1. Playback the cassette tape from the beginning and wait until the tape movement get the stabilization. (for approx. 10~20 seconds)

2. Insert the Back Tension Meter into the path of a tape, and measure the back tension to be within specification as shown in Fig. M22.




Fig. M22 Measurement of Back Tension

Note:

1. While measuring, make sure that the three probes of the meter are all in good contact with the tape.
2. As the tension meter is very sensitive, we recommend taking 3 separate readings.
3. If it is out of specification, change the spring notch as shown in Fig. M23.




Fig. M23

4.4. REEL TABLES HEIGHT ADJUSTMENT

- * Equipment Required:
 Post Adjustment Plate.....VFK0191
 Reel Table Height Gauge.....VFK0190
 * Specification-----0~-0.15mm

Note:

Cut-out on Post Adjustment Plate is reference of reel table height and their height is measured based on this reference.

1. Place the post adjustment plate on the reels, and put the Gauge on the plate. Set the gauge to zero "0" with the foot scraper of the gauge touching the cut-out portion of the plate.




Fig. M24

2. Then measure the height of reel table and confirm the difference just performed in former step as shown below. Do the same way for the other reel table.




Fig. M25

3. If a height difference in readings between the cut-out portion of plate and reel tables is not 0~-0.15mm (higher or lower), adjust the height of the reel to obtain specified height.
4. For adjustment add or reduce a washer.

4.5. ADJUSTMENT OF FG HEAD GAP

* Specification:-----0.17~0.18mm

- (1). Slightly loosen the 2 screws.
- (2). Put the paper which is used for cover page of this volume into the gap between F.G.Head and Capstan rotor. (The thickness of the cover page is approx 0.17mm)
- (3). After adjustment, tighten 2 screws.




Fig. M26

Note:

Do not touch the surface of rotor and keep any magnetizable material away.

4.6. ASSEMBLY ADJUSTMENT PROCEDURES OF MECHANISM

The mechanism of this model is mostly engaged to the System Control Circuit, through the mode select switch.

Therefore the relation between the mode select switch and the cam gear decides all further mechanical movement of the mechanical parts such as levers, gears, rollers and so on.

If these parts are fixed in properly, the unit will be unloaded or compulsorily stopped.

And it will result being damaged at any mechanical or electrical parts.

4-6-1. ASSEMBLY PROCEDURES OF LOADING RINGS AND LOADING GEARS

- (1). Install a Loading-Ring T (1) unit and a Loading Gear (B) so that both triangle marks meet each other as shown below.




Fig. M27

- (2). Install a Loading Gear (A) and next fix a Loading Ring S (1) Unit so that the holes of Loading-Ring S (1) Unit and T (1) Unit meet each other as shown below.




Fig. M28

Note:

Pay attention that the washers are remaining under the loading gears or any other parts.

4-6-2. ASSEMBLY PROCEDURES OF TAKE-UP LOADING GUIDE AND TAKE-UP LOADING POSTS UNIT

- (1). Install Loading Guide T Unit and Take-up Post Stopper.
In that time, the small projection of a Loading Link T Unit must be inserted into a gap of Loading Guide T Unit.
- (2). Fix a Take-up side Loading Post Unit holding the small projection of the Loading Link T Unit and install a T Shaft Holder Unit.

4-6-3. ASSEMBLY PROCEDURES OF SUPPLY LOADING GUIDES AND SUPPLY LOADING POST UNIT

- (1). Install 2 Supply Loading Guides screwing 4 screws.
- (2). Slide a Supply Loading Post Unit into a gap between the Loading Guide S1 and S2 hooking a Connection Rod to a Connection Tie Unit as shown below.




Fig. M29

- (3). Set the Supply Loading Post Unit into unloading position by turning a intermediate pully gear as shown below.




Fig. M30

- (4). Install a V Stopper Base and Supply Post Stopper.

4-6-4. ASSEMBLY PROCEDURES OF MAIN ROD.

- (1). Place a Main Rod inserting 3 Thrust Washers and then insert 3 washers. After that, fix them using 2 retaining rings as shown below.




Fig. M31

- (2). Install a Drive Arm Kick Lever hooking a Drive Arm Kick Lever Spring and fix it using ring.

4-6-5. ASSEMBLY PROCEDURES OF CAM GEAR AND SECTOR

- (1). Make sure that the hole on a Main Rod just should coincide with the hole on chassis as shown below and install a Cam Gear should coincide with the hole between a Cam Gear and the chassis. Then install a retaining ring.




Fig. M32

- (2). Install a Loading Gear (C) keeping the relation as shown below.




Fig. M33

- (3). Install a Sector Gear as shown below.




Fig. M34

- (4). Fix a SG Limiter by 2 retaining rings.

4-6-6. ASSEMBLY PROCEDURES OF MODE SWITCH

- (1). Perform this procedures after confirming the complete setting of mechanical parts. First of all confirm that the hole on a Main Rod is meeting with a hole on a chassis.
- (2). Move the moving contact of a Mode Select Switch into Stop position as shown below.




Fig. M35

- (3). Install the Mode Select Switch keeping these relation written in item (1) and (2) by screwing 2 screw.

2-4. ELECTRICAL ADJUSTMENT PROCEDURES

2-4.1. ELECTRICAL ADJUSTMENT FOR CAMERA SECTION

TEST EQUIPMENT AND TOOLS

The following equipments are required for adjustment of the VHS Movie NV-M1000EN/EM.

- (1) Dual trace Oscilloscope
*Voltage range : 0.05 ~ 50V/div.
*probe : 10:1 or 1:1
- (2) V.T.V.M. (Vacuum Tube Volt Meter)
D.V.M. (Digital Volt Meter)
*Voltage range : 0.01 ~ 50V
- (3) Frequency Counter
*Frequency range : 0 ~ 10MHz
- (4) Vectorscope
- (5) Light Meter
- (6) Tripod
- (7) TV Monitor
- (8) Lighting
*3200 degrees kelvin / 1400lux on the chart surface.
- (9) Reflection Charts
*Logarithmic Gray Scale Chart (YWV2310RB99)
*Colour Chip Chart (YWV2100RB98)
*Ball Chart / J-Chart (VFK0580)
*B/W / G/W / Hunting Chart (VFK0546)
*White Chart (White paper)
- (10) Plastic tip driver
- (11) Camera Unit Holder (VFK0382)
- (12) Camera Holder Arm (VFK0431)
- (13) Colour temperature conversion filters
*C12 filter (VFK0374)
*C2 filter (VFK0375)
*C8 filter (VFK0547)
- (14) Camera Extension Cables
*14Pin Cable (VFK0430)
*18Pin Cable (VFK0380) 2pcs




Fig. C1




Fig. C2

PREPARATION

- (1) Remove the casing panels.
- (2) Mount the unit to tripod directly.
- (3) White balance switch to "INDOOR"
- (4) Auto focus selector to "OFF"
- (5) High speed shutter to "OFF"
- (6) Iris VR to centre click portion.




Fig. C3




Fig. C4

HOW TO READ THE ADJUSTMENT PROCEDURES

Connecting Point (Test Point) of Measuring Equipment		Adjustment Component	Lens Cap Yes or No	Camera Target Chart
TP	ADJ.	LENS CAP	CHART	
TP1	VR604	YES	WHITE CHART	
M. EQ.		SPEC.		
OSCILLOSCOPE		SIGNAL CLIP 1.48V±0.04Vp-p		
Measuring Equipment		Specification for Adjustment or Adjusting Method		

Note: If ☐ appears in any block, this means it is not used or not important.

Fig. C5

CCD DRIVE SECTION

1. BACK FOCUS ADJUSTMENT

2. PLL FREQUENCY ADJUSTMENT

3. V-SUB ADJUSTMENT

4. CCD OUTPUT ADJUSTMENT

PROCESS SECTION

5. AGC ADJUSTMENT

6. Y 1H/2H DELAY LEVEL ADJUSTMENT

7. YH LEVEL ADJUSTMENT

8. CHROMA 1H/2H DELAY LEVEL ADJUSTMENT

9. BURST PHASE ADJUSTMENT

10. PEDESTAL LEVEL ADJUSTMENT

11. IRIS VR ADJUSTMENT

12. ALC ADJUSTMENT

13. CARRIER BALANCE AND BLACK LEVEL ADJUSTMENT

14. INDOOR WHITE BALANCE ADJUSTMENT

15. OUTDOOR WHITE BALANCE ADJUSTMENT

16. AWB OFFSET ADJUSTMENT

17. COLOUR PHASE AND R-Y/B-Y GAIN ADJUSTMENT

18. HIGH INTENSITY SUPPRESS (HIGH CUT) ADJUSTMENT

19. AWT MODE (OFFSET) ADJUSTMENT

20. AWT MODE (GAIN) ADJUSTMENT

21. HALL AMP ADJUSTMENT

AUTO FOCUS SECTION

22. AF GATE ADJUSTMENT

23. BIMOLF GAIN CONTROL ADJUSTMENT

24. AF VH FREQUENCY ADJUSTMENT

TABLE 1

CCD DRIVE SECTION

1. BACK FOCUS ADJUSTMENT

- (1) Aim the camera at the Hunting Chart 3m distance and zoom all the way in fully tele position.
- (2) Focus the lens on the object.
- (3) Confirm that Focus ring indicates 3m.
- (4) Adjust the relay lens adjustment point as shown in Fig. C6.




Fig. C6

2. PLL FREQUENCY ADJUSTMENT

TP	ADJ.	LENS CAP	CHART
PIN 7 OF B201	C206		
M. EQ.		SPEC.	
FREQUENCY COUNTER		9.656250 MHz $\pm$ 10Hz	

B201, C206 : Sensor C.B.A.

- (1) Connect the frequency counter to Pin 7 of B201
- (2) Adjust the C206 (PLL frequency control) so that the frequency becomes 9.656250MHz $\pm$ 10Hz

3. V-SUB ADJUSTMENT

TP	ADJ.	LENS CAP	CHART
	VR201	NO	REFER TO Fig. C7
M. EQ.		SPEC.	
MONITOR TV		NO BLOOMING	

- (1) Zoom all the way in fully tele position and aim the camera at the Halogen lamp as shown in Fig. C7.
- (2) Set the High Speed Shutter SW to OFF position.




Fig. C7

- (3) Blind the lighting using frosted glass or acryl plate to diffuse incoming light, and also put a corrugated cardboard which inside is cut to "U" shape as shown in Fig. C8.
- (4) Connect the jumper wire between TP516 and TP520 to open the iris.
- (5) Adjust VR201 (Blooming control) so that blooming is just disappeared. If blooming is not disappeared completely, adjust VR201 until minimum blooming.
- (6) High Speed Shutter "ON" and "OFF" both mode, confirm that the monitored picture does not contain the blooming even the corrugated cardboard moves as shown in Fig. C8.




Fig. C8

Note:

J-Chart is also available for rough

- (1) Aim the camera at J-Chart.
- (2) Set the lens to fully tele position. And set the distance so that lower 1/3 of J-Chart comes to full picture frame on TV screen.
- (3) Connect the jumper wire between TP516 and TP520 to open the the iris.
- (4) Adjust the VR201 so that the blooming is just disappeared.

4. CCD OUTPUT ADJUSTMENT

TP	ADJ.	LENS CAP	CHART
TP201	VR202	NO	J CHART
M. EQ.		SPEC.	
OSCILLOSCOPE		180mV $\pm$ 10mV	

Note:

TP201,VR202 : Sensor C.B.A.
TP515,VR327 : Process C.B.A.

- (1) Aim the camera at J-Chart.
- (2) Adjust the VR327 (ALC control) so that the voltage at TP515 becomes 280mV $\pm$ 10mV.
- (3) Adjust the VR202 (CCD output control) so that the level "A" of TP201 becomes 180mV $\pm$ 10mV as shown in Fig. C9.




Fig. C9

PROCESS SECTION

5. AGC ADJUSTMENT

TP	ADJ.	LENS CAP	CHART
TP514	VR324	NO	GRAY SCALE CHART
M. EQ.		SPEC.	
OSCILLOSCOPE		300mV $\pm$ 20mVp-p	

Note:

TP514,VR324 : Process C.B.A.

- (1) Aim the camera at the Gray Scale Chart.
- (2) Connect the oscilloscope to TP514 and trigger with pin 7 of FP306 (H-rate).
- (3) Adjust the zoom to obtain 40usec picture frame as shown in Fig. C10.
- (4) Adjust the VR324 (AGC control) so that the signal level becomes 300mV $\pm$ 20mVp-p.




Fig. C10

6. Y 1H/2H DELAY LEVEL ADJUSTMENT

TP	ADJ.	LENS CAP	CHART
TS5, TS2, TS8 (TEST ROUND)	VR320 VR318	NO	GRAY SCALE
M. EQ.		SPEC.	
OSCILLOSCOPE		0 $\pm$ 4.5mVp-p	

Note:

TS2,TS5,TS8,VR318,VR320 : Process C.B.A.

- (1) Aim the camera at the Gray Scale Chart.
- (2) Connect the oscilloscope to TS5 (CH-A) and TS2 (CH-B). (The gain for CH-A and CH-B should be same.)
- (3) Set the CH-B for "INVERT" mode.
- (4) Set the oscilloscope for "ADD" mode.
- (5) Adjust the VR320 (1H delay level control) so that the waveform level becomes 0 $\pm$ 4.5mVp-p.
- (6) Reconnect the CH-B probe to TS8 and continue the "INVERT" mode for CH-B. (CH-A still connecting to TS5.)
- (7) Adjust the VR318 (2H delay level control) so that waveform level becomes 0 $\pm$ 4.5mVp-p.




Fig. C11

7. YH LEVEL ADJUSTMENT

TP	ADJ.	LENS CAP	CHART
PIN 7 OF FP 306	VR315	NO	GRAY SCALE CHART
M. EQ.		SPEC.	
OSCILLOSCOPE		B/A = 2.33 $\pm$ 0.15	

Note:

FP306,VR315 : Process C.B.A.

- (1) Aim the camera at the Gray Scale Chart.
- (2) Connect the oscilloscope to pin7 of FP306.
- (3) Adjust the VR315 (YH level control) so that the signal ratio "B/A" becomes 2.33 ± 0.15 as shown in Fig. C12.




Fig. C12

8. CHROMA 1H/2H DELAY LEVEL ADJUSTMENT

TP	ADJ.	LENS CAP	CHART
TS7, TS10, TS11 (TEST ROUND)	VR319 VR317	YES	
M. EQ.		SPEC.	
OSCILLOSCOPE		$0 \pm 4.5 \text{ mV}$	

Note:

TS7, TS10, TS11, VR317, VR319 : Process C.B.A.

- (1) Cover the camera lens with lens cap.
- (2) Supply the "WHD" signal from Pin2 of B305 to TS7 through the buffer circuit and adjust VR1 on the buffer circuit so that the level of TS7 becomes $300 \text{ mV} \pm 5 \text{ mVp-p}$ as shown in Fig. C13.




Fig. C13

- (3) Set the oscilloscope to "ADD" mode and "INVERT" mode for CH-B.
- (4) Connect the oscilloscope CH-A to TS7 and CH-B to TS10.
- (5) Adjust the VR319 (Chroma 1H delay level control) so that the level of waveform becomes $0 \pm 4.5 \text{ mV}$.
- (6) Exchange the connecting point of CH-B from TS10 to TS11.
- (7) Adjust the VR317 (Chroma 2H delay level control) so that the level of waveform becomes $0 \pm 4.5 \text{ mV}$.




Fig. C14

9. BURST PHASE ADJUSTMENT

TP	ADJ.	LENS CAP	CHART
VIDEO OUT	VR329	YES	
M. EQ.		SPEC.	
VECTOR SCOPE		$135 \text{ degree} \pm 2 \text{ degree}$	

Note:

VR329 : Process C.B.A.

- (1) Cover the lens with lens cap.
- (2) Supply the video output to vectorscope.
- (3) Set the vectorscope for NTSC mode.
- (4) Adjust the VR329 (Burst phase control) so that burst phase becomes $135 \pm 2 \text{ degrees}$.




Fig. C15

10. PEDESTAL LEVEL ADJUSTMENT

TP	ADJ.	LENS CAP	CHART
TP514	VR301	YES	
M. EQ.		SPEC.	
OSCILLOSCOPE		SIGNAL LEVEL EQUALS THE BLANKING (BLANK) LEVEL.	

Note:

TP514,VR301 : Process C.B.A.

- (1) Cover the camera lens with lens cap.
- (2) Connect the oscilloscope to TP514 and trigger with Pin7 of FP306 (H-rate).
- (3) Adjust the VR301 (Pedestal level control) so that the signal level equals the BLK (Blanking) level as shown in Fig. C16.




Fig. C16

11. IRIS VR ADJUSTMENT

TP	ADJ.	LENS CAP	CHART
TP523	VR322	YES	
M. EQ.		SPEC.	
D.V.M. V.T.V.M.		2.1V±0.1V	

Note:

TP523,VR322 : Process C.B.A.

AGC adjustment should be completed.

- (1) Set the iris VR to centre click position and cover the camera lens with the lens cap.
- (2) Connect the volt meter to TP523.
- (3) Adjust VR322 (Iris control) so that the DC voltage of TP523 becomes 2.1V ± 0.1V

12. ALC ADJUSTMENT

TP	ADJ.	LENS CAP	CHART
TP515	VR327	NO	GRAY SCALE CHART
M. EQ.		SPEC.	
OSCILLOSCOPE		280mV±20mVp-p	

Note:

TP515,VR327 : Process C.B.A.

- (1) Set the iris VR to centre click position.
- (2) Aim the camera at the Gray Scale Chart.
- (3) Connect the oscilloscope to TP515 and trigger with Pin7 of FP306 (H-rate).
- (4) Adjust the zoom to obtain 40usec picture frame as shown in Fig. C17.
- (5) Adjust the VR327 (Auto iris control) so that the signal level becomes 280mV ± 20mVp-p.




Fig. C17

13. CARRIER BALANCE AND BLACK LEVEL ADJUSTMENT

TP	ADJ.	LENS CAP	CHART
VIDEO OUTPUT	VR305 VR306 VR303 VR304	YES	
M. EQ.		SPEC.	
VECTORSCOPE		CENTER OF VECTORSCOPE	
OSCILLOSCOPE		WAVEFORM IS MINIMIZED	

Note:

TP511,TP512,TP513,VR303,VR304,VR305,VR306 : Process C.B.A.

WITH VECTORSCOPE

- (1) Cover the lens with lens cap.
- (2) Connect the jumper wire between centre of VR324 and TP511.
- (3) Connect the jumper wire among TP511,TP512 and TP513 to cut the R-Y, B-Y feed back loop.

- (4) Adjust the VR305 and VR306 (Black pedestal controls) so that the colour vector at the centre of screen on vectorscope.
- (5) Disconnect the jumper wire between VR324 and TP511.
- (6) Adjust the VR303 and VR304 (Carrier balance controls) so that the colour vector at the centre of screen on vectorscope.




Fig. C18

WITH OSCILLOSCOPE

- (1) Adjustment condition and procedures are the same as using vectorscope.
- (2) Adjust the VR305 and VR306 first so that the waveform becomes minimized as shown in Fig. C19.
- (3) Adjust the VR303 and VR304 so that the waveform becomes minimized as shown in Fig. C19.




Fig. C19

14. INDOOR WHITE BALANCE ADJUSTMENT

TP	ADJ.	LENS CAP	CHART
VIDEO OUTPUT	VR311 VR312	NO	WHITE CHART
M. EQ.		SPEC.	
VECTORSCOPE		CENTER OF VECTORSCOPE	
OSCILLOSCOPE		WAVEFORM IS MINIMIZED	

Note:

TP511,TP512,TP513,VR311,VR312 : Process C.B.A.

WITH VECTORSCOPE

- (1) Set the White balance switch to "INDOOR" mode.
- (2) Connect the jumper wire among TP511,TP512 and TP513 to cut the R-Y, B-Y feed back loop.
- (3) Aim the camera at the White Chart.
- (4) Supply the video output to vectorscope.
- (5) Adjust the VR311 and VR312 (White balance controls) so that the colour vector at the centre of screen on vectorscope.




Fig. C20

WITH OSCILLOSCOPE

- (1) Adjustment condition and procedures are the same as using vectorscope.
- (2) Adjust the VR311 and VR312 so that the waveform becomes minimized.




Fig. C21

15. OUTDOOR WHITE BALANCE ADJUSTMENT

TP	ADJ.	LENS CAP	CHART
VIDEO OUTPUT	VR528 VR529	NO	WHITE CHART
M. EQ.		SPEC.	
VECTORSCOPE		CENTER OF VECTORSCOPE	
OSCILLOSCOPE		WAVEFORM IS MINIMIZED	

Note :
TP511,TP512,TP513,VR528,VR529 : Process C.B.A.

WITH VECTORSCOPE

- (1) Set the White balance switch to "OUTDOOR".
- (2) Connect the jumper wire among TP511,TP512 and TP513 to cut the R-Y, B-Y feed back loop.
- (3) Aim the camera at the White Chart.
- (4) Supply the video output to vectorscope.




Fig. C22

- (5) Attach the colour temperature conversion filter VFK0374 (C12) and VFK0375 (C2) which convert 3200 degrees Kelvin to 5600 degrees Kelvin in front of the lens and AWT sensor. (If the colour temperature conversion filters are not available, use a day light source.)
- (6) Adjust the VR528 and VR529 (Outdoor gain controls) so that the colour vector at the centre of screen on vectorscope.

WITH OSCILLOSCOPE

- (1) Adjustment condition and procedures are the same as using vectorscope.
- (2) Adjust VR528 and VR529 so that the waveform becomes minimized.




Fig. C23

HOW TO ATTACH THE FIXTURE

Attach the fixture to the lens and then set the colour temperature conversion filter to fixture.




Fig. C24

HOW TO MAKE A FIXTURE

- (1) Print the actual measure at the hard paper referring Fig. C25.
- (2) Cut the paper along the solid line.
- (3) Apply the past to the oblique line.
- (4) Fold the paper along the dotted line.
- (5) Construct the fixture referring completion drawing.




Fig. C25

HOW TO USE THE SUN LIGHT

Incoming light must be outdoor source (Sun light) only, source and illumination on the sensor must be more than 500Lux, and colour temperature must be within 5000 to 6000 degrees Kelvin.




Fig. C26

16. AWB OFFSET ADJUSTMENT WITH OSCILLOSCOPE

TP	ADJ.	IRIS	CHART
TP511 TP512 TP513	VR530 VR531		WHITE CHART
M. EQ.		SPEC.	
OSCILLOSCOPE		$0 \pm 0.1V$	

Note :

TP511, TP512, TP513, TP519, TP521, VR530, VR531 :
Process C.B.A.

- (1) Set the White Balance Switch to "INDOOR".
- (2) Connect the jumper wire between TP519 and TP521 to make a easy adjustment.
- (3) Aim the camera to White Chart.
- (4) Connect the oscilloscope to TP512 and GND probe to TP511.
- (5) Adjust the VR530 (AWB OFFSET) so that the voltage becomes $0 \pm 0.1V$ at TP512.
- (6) Exchange the HOT probe from TP512 to TP513.
- (7) Adjust the VR531 (AWB OFFSET) so that the voltage becomes $0 \pm 0.1V$ at TP513.

17. COLOUR PHASE AND R-Y/B-Y GAIN ADJUSTMENT

TP	ADJ.	LENS CAP	CHART
VIDEO OUTPUT	VR310 VR307 VR314 VR313 VR328	NO	COLOUR CHIP CHART
M. EQ.		SPEC.	
VECTORSCOPE		Fig. C27	

Note:

TP511, TP512, TP513, VR307, VR310, VR313, VR314, VR328 : Process C.B.A.

- (1) Aim the camera at the Colour Chip Chart.
- (2) Set the vectorscope for NTSC mode.
- (3) Adjust the VR310 (Colour phase control) so that the cracked Red vector comes one.
- (4) Set the vectorscope to PAL mode.
- (5) Connect the jumper wire among TP511, TP512 and TP513.
- (6) Adjust the VR307 and VR308 (Colour phase control), VR313 (R-Y Gain control), VR314 (B-Y Gain control) so that the vector of each colour as shown in Fig. C27.




Fig. C27

18. HIGH INTENSITY SUPPRESS (HC) ADJUSTMENT

TP	ADJ.	LENS CAP	CHART
	VR309	NO	COLOUR CHART
M. EQ.		SPEC.	
TV MONITOR		HALF SIZE (YELLOW) YELLOW COLOUR IS JUST BEFORE CUT OFF	

Note:

VR309 : Process C.B.A.

- (1) Aim the camera at the Colour Bar.
- (2) Set the horizontal picture frame to 40usec, and memorize the level of Yellow part.
- (3) Set the horizontal picture frame to 16usec. (Expand the Yellow part.)
- (4) In case that the level of Yellow part is more than 50% compared with the Yellow level of when horizontal picture frame was 40usec, adjust the VR309 (High cut control) so that the level of yellow becomes 50% as shown in Fig. C28.
- (5) In case that the level of Yellow part is already less than 50% of when the horizontal picture frame was 40usec, adjust the VR309 until before just Yellow part begins to disappear.




Fig. C28

19. AWT MODE (OFFSET) ADJUSTMENT

TP	ADJ.	LENS CAP	CHART
VIDEO OUTPUT	VR525 VR526	NO	WHITE CHART
M. EQ.		SPEC.	
VECTORSCOPE		CENTER OF VECTORSCOPE	
OSCILLOSCOPE		WAVEFORM IS MINIMIZED	

Note:

TP511, TP512, TP513, TP519, TP521, VR525, VR526 : Process C.B.A.

WITH VECTORSCOPE

- (1) Set the White balance switch to "AUTO".
- (2) Aim the camera at the White Chart.
- (3) Supply the video output to vectorscope.
- (4) Connect the jumper wire among TP511, TP512 and TP513 to cut the R-Y, B-Y feed back loop.
- (5) Connect the jumper wire between TP519 and TP521 to make a easy adjustment.
- (6) Adjust the VR525 and VR526 (AWT Offset control) so that the vectors move to centre of screen on vectorscope.




Fig. C29

WITH OSCILLOSCOPE

- (1) Adjustment condition and procedures are the same as using vectorscope.
- (2) Adjust the VR525 and VR526 so that the waveform becomes minimized.




Fig. C30

20. AWT MODE (GAIN) ADJUSTMENT

TP	ADJ.	LENS CAP	CHART
VIDEO OUTPUT	VR523 VR527	NO	WHITE CHART
M. EQ.		SPEC.	
VECTORSCOPE		CENTER OF VECTORSCOPE	
OSCILLOSCOPE		WAVEFORM IS MINIMIZED	

Note:
TP511, TP512, TP513, TP519, TP521, VR523, VR527 :
Process C.B.A.

WITH VECTORSCOPE

- (1) Set the White balance switch to "AUTO".
- (2) Aim the camera at the White Chart.
- (3) Supply the video output to vectorscope.
- (4) Connect the jumper wire among TP511, TP512 and TP513 to cut the R-Y, B-Y feed back loop.
- (5) Connect the jumper wire between TP519 and TP521 to make a easy adjustment.
- (6) Attach the fixture with colour temperature conversion filter VFK0547 (C8) to the in front of lens.




Fig. C31

- (7) Adjust the VR523 and VR527 ((AWT Gain control)) so that the colour vector moves to centre of screen on vectorscope.
- (8) Next, remove the fixture with filter from lens and confirm that whether colour vector moves to centre or not. If not, readjust the AWT offset adjustment again and then repeat this adjustment.




Fig. C29

WITH OSCILLOSCOPE

- (1) Adjustment condition and procedures are the same as using vectorscope.
- (2) Adjust the VR523 and VR527 so that the waveform becomes minimized.
- (3) Confirm the AWT offset mode.




Fig. C33

21. HALL AMP ADJUSTMENT

TP	ADJ.	LENS CAP	CHART
TP518 TP516 TP521 TP520	VR532 VR533	NO	GRAY SCALE CHART
M. EQ.		SPEC.	
D.V.M.			

Note:

TP516, TP518, TP520, TP521, VR532, VR533 :
Process C.B.A.

- (1) Connect the jumper wire between TP516 and TP521 to iris close.
- (2) Adjust the VR532 (Hall amp control) so that the voltage at TP518 becomes $1.74V \pm 0.02V$.
- (3) Exchange the connecting jumper wire from TP521 to TP520 to iris open. (Now connecting TP516 and TP520.)
- (4) Adjust the VR533 (Hall amp control) so that the voltage at TP518 becomes $3.72V \pm 0.05V$.
- (5) Confirm the voltage at TP518 by connecting a jumper wire between TP516 and TP521 then if it is out of specification, repeat this adjustment from first item.
(Voltage at TP518 is control by both VR, so even if iris close voltage has adjusted by VR532 correctly, it is changed when iris open voltage is adjusted by VR533. Please consider changing level when you adjust.)

AUTO FOCUS SECTION

Note:

PREPARATION

Camera zoom is positioned at the end of TELE side.

22. AF GATE ADJUSTMENT

TP	ADJ.	IRIS CAP	CHART
TP702 TP703	C703	NO	
M. EQ.		SPEC.	
OSCILLOSCOPE		$T = 9.6 \pm 0.4 \mu\text{sec}$	

Note:

TP702, TP703, C703 : Auto Focus C.B.A.

- (1) Connect the oscilloscope to TP702 and TP703 by dual trace mode.
- (2) Adjust the C703 (AF Gate control) so that the phase difference becomes $9.6 \mu\text{sec} \pm 0.4 \mu\text{sec}$.




Fig. C34

23. BIMOLF GAIN CONTROL ADJUSTMENT

TP	ADJ.	LENS CAP	CHART
TP704	VR703	YES	
M. EQ.		SPEC.	
OSCILLOSCOPE		$A = 11V \pm 0.5V_{p-p}$	

Note:

TP704, VR703 : AF C.B.A.

- (1) Set the Focus selector to "MANUAL".
- (2) Cover the camera lens with the lens cap.
- (3) Connect the oscilloscope to TP704.
- (4) Adjust the VR703 (Bimolf gain control) so that the signal level becomes $11V \pm 0.5V_{p-p}$.




Fig. C35

24. AF VH FREQUENCY ADJUSTMENT

TP	ADJ.	IRIS CAP	CHART
TP705	C737	NO	WHITE/GRAY CHART
M. EQ.		SPEC.	
OSCILLOSCOPE		A=2.80V±0.05V DC-RANGE	

Note:

TP705,TP710,C737 : Auto Focus C.B.A.
TP516,TP520 : Process C.B.A.




Fig. C36

- (1) Set the Focus selector to "AUTO".
- (2) Connect the jumper wire between TP516 and TP520 to iris open.
- (3) Aim the camera at White/Gray Chart.
- (4) Adjust the lighting condition so that level at TP710 becomes $180\text{mV} \pm 10\text{mVp-p}$ as shown in Fig. C37.




Fig. C37

- (5) Adjust the C737 (AF VH Frequency control) so that DC level at TP705 becomes $2.8\text{V} \pm 0.05\text{V}$.




Fig. C38

2-4-2. ELECTRICAL ADJUSTMENT FOR E.V.F. SECTION

Note:

PREPARATION

Adjustment of camera section must be completed.
Electric View Finder must be connected to camera unit.

1. H-OSC ADJUSTMENT

TP	ADJ.	LENS CAP	CHART
Pin 2 of P701	VR702	NO	BALL CHART
M. EQ.		SPEC.	
FREQUENCY COUNTER		15.9kHz±0.1kHz	

Note:

P701,VR702 : E.V.F. C.B.A.

- (1) Connect the frequency counter to Pin2 of P701.
- (2) Adjust the VR702 (H-OSC control) so that the frequency becomes $15.9\text{KHz} \pm 0.1\text{KHz}$.


2. CENTERING ADJUSTMENT

Note:


Deflection York, Centering Magnet : CRT

- (1) Aim the camera at the Ball Chart
- (2) Adjust the Deflection yolk and Centering magnet so that the picture on CRT is centered.

LOCATION OF TEST POINTS & CONTROLS (2)



LUMINANCE & CHROMINANCE C.B.A.



2-4.3. ELECTRICAL ADJUSTMENT FOR VTR SECTION

The following equipments are required for adjustment of the VHS Movie NV-M1000EN/EM.

- (1) V.T.V.M. (Vacuum Tube Volt Meter)
D.V.M. (Digital Volt Meter)
- (2) Dual trace Oscilloscope
*Voltage range : 0.06 ~ 50V/div.
*Probe : 10:1 or 1:1
- (3) Frequency Counter
*Frequency range : 0 ~ 10MHz
- (4) Signal Generator (Sine wave)
*Frequency range : 0 ~ 10MHz
- (5) Video Sweep Generator
- (6) Colour monitor TV
- (7) Plastic tip driver
- (8) VHS Alignment tape (VFJ8125H3F)
- (9) VHS Blank tape
- (10) Pattern generator
- (11) Y/C Separator (VFK0304)
- (12) Extension cable (VFK0430)
- (13) Y/C Separator connector (VFKS0074)

PREPARATION

- (1) Remove the casing panels.
- (2) Connect the Y/C Separator (VFK0304) to P3803 on the Main C.B.A. through Connector (VFKS0047) and extension cable (VFK0430).
- (3) Supply the video signal to the unit through the Y/C Separator (VFK0304).
- (4) Supply the audio signal to audio circuit through the external microphone socket.

HOW TO THE ADJUSTMENT PROCEDURES




Fig. E1




Fig. E2

POWER SECTION

1. REG. 5V ADJUSTMENT

TP	ADJ.	MODE	INPUT
TP1003	VR1003	REC/PLAY	
TAPE	M. EQ.	SPEC.	
BLANK TAPE	D.V.M.	$4.96 \pm 0.025V$	

Note :

Camera unit should be connected to main C.B.A. during Power REG. adjustment (REG. 5V, REG. 9V and Camera REG. 16V)




Fig. E3

2. REG. 9V ADJUSTMENT

TP	ADJ.	MODE	INPUT
TP1002	VR1002	CAMERA RECORDING	
TAPE	M. EQ.	SPEC.	
BLANK TAPE	D.V.M.	$8.62^{+0.07V}_{-0.03V}$	

3. CAMERA REG. 16V ADJUSTMENT

TP	ADJ.	MODE	INPUT
TP1001	VR1001	REC/PLAY	
TAPE	M. EQ.	SPEC.	
BLANK TAPE	D.V.M.	$15.2 \pm 0.3V$	

Note :

REG. 5V, REG 9V adjustment should be completed before this adjustment.

LUMINANCE & CHROMINANCE SECTION

5. E-E LEVEL ADJSUTMENT

TP	ADJ.	MODE	INPUT
VIDEO OUT	VR3003	STOP	COLOUR BAR
TAPE	M. EQ.	SPEC.	
	OSCILLOSCOPE	$A = 1.0 \pm 0.05 V_{p-p}$ (75Ω Terminated)	




Fig. E4

SERVO SECTION

4. PG SHIFTER ADJSUTMENT

TP	ADJ.	MODE	INPUT
TP2001 VIDEO OUT	VR2001	PLAY	
TAPE	M. EQ.	SPEC.	
ALIGNMENT TAPE (VFJ8125H3F)	OSCILLOSCOPE	$6.5H \pm 0.5H$	

6. AFC ADJUSTMENT

TP	ADJ.	MODE	INPUT
TP8004	VR8007	STOP	
TAPE	M. EQ.	SPEC.	
	FREQ. COUNTER	$623 \pm 15 kHz$	

- (1) Connect the jumper wire among TP8002, TP8003 and TP8001 (GND).
- (2) Connect the frequency counter to TP8004.
- (3) Adjust the VR8007 so that the frequency becomes $623KHz \pm 15KHz$.

7. REC CHROMA LEVEL ADJUSTMENT

TP	ADJ.	MODE	INPUT
P5003-2 (GND) P5003-1 (HOT)	VR8001	REC/PLAY	COLOUR BAR (W/WHITE WINDOW)
TAPE	M. EQ.	SPEC.	
BLANK TAPE	OSCILLOSCOPE	$44 \pm 5 \text{ mVp-p}$	

- (1) Connect the oscilloscope to TP5003 (HOT) and TP5002 (GND).
- (2) Eliminate luminance recording current by turning VR3002.
- (3) Adjust VR8001 so that the Chrominance recording current become $44 \text{ mV} \pm 5 \text{ mVp-p}$.




Fig. E5

8. LUMINANCE RECORDING CURRENT ADJUSTMENT

TP	ADJ.	MODE	INPUT
P5003-2 (GND) P5003-1 (HOT)	VR3002	REC/PLAY	VIDEO SIGNAL
TAPE	M. EQ.	SPEC.	
BLANK TAPE	OSCILLOSCOPE	$150 \text{ mV} \pm 5 \text{ mVp-p}$	

- (1) Connect the oscilloscope to TP5003 (HOT) and TP5002 (GND).
- (2) Adjust the VR3002 so that the luminance recording current becomes $150 \pm 5 \text{ mVp-p}$.




Fig. E6

9. LINE NOISE CANCEL ADJUSTMENT

TP	ADJ.	MODE	INPUT
TP3004	VR3001	SELF RECORDING	
TAPE	M. EQ.	SPEC.	
BLANK TAPE	OSCILLOSCOPE	Minimum as possible	

- (1) Record the video signal.
- (2) Connect the oscilloscope to TP3004.
- (3) Playback the just recorded portion.
- (4) Adjust the VR3001 so that the level between sync tip and white peak becomes minimum as possible.




Fig. E7

10. VIDEO PLAYBACK LEVEL ADJUSTMENT

TP	ADJ.	MODE	INPUT
VIDEO OUT	VR3004	SELF RECORDING	COLOUR BAR
TAPE	M. EQ.	SPEC.	
BLANK TAPE	OSCILLOSCOPE	$A = 1.0 \pm 0.05 \text{ Vp-p}$	

- (1) Record the colour bar and playback the just recorded portion.
- (2) Connect the oscilloscope to video out.
- (3) Adjust the VR3004 so that the out put level becomes $1.0 \text{ V} \pm 0.05 \text{ Vp-p}$.




Fig. E8

11. HEAD AMP FREQUENCY RESPONSE ADJUSTMENT

TP	ADJ.	MODE	INPUT
VIDEO OUT	VR3005	SELF RECORDING	VIDEO SWEEP SIGNAL
TAPE	M. EQ.	SPEC.	
BLANK TAPE	VIDEO SWEEP/ OSCILLO-SCOPE	A: $0 \pm 2\text{ dB}$ (80~125%)	

Note:

Edit switch should be "OFF"

- (1) Set the video sweep generator as shown in Fig. E9.




Fig. E9

- (2) Record the sweep signal and playback just recorded portion.
- (3) Adjust the VR3005 so that the level at 2MHz becomes $0 \pm 2\text{ dB}$ comparing with the level at 0.1MHz as shown in Fig. E10.




Fig. E10

AUDIO SECTION

12. AUDIO PLAYBACK LEVEL ADJUSTMENT

TP	ADJ.	MODE	INPUT
AUDIO OUT	VR4001	SELF RECORDING	1kHz AUDIO 0dB SIGNAL/ VIDEO SIGNAL
TAPE	M. EQ.	SPEC.	
BLANK TAPE	SIGNAL GENERATOR/ D.V.M.	$-8.0\text{ dBV} \pm 1\text{ dB}$	

- (1) Supply the audio signal (1KHz/-10dB Sine wave) to audio circuit through external microphone socket.
- (2) Record the audio signal and playback just recorded portion.
- (3) Adjust VR4001 so that the audio level becomes $-8\text{ dBV} \pm 1\text{ dB}$.

13. AUDIO BIAS CURRENT ADJUSTMENT

TP	ADJ.	MODE	INPUT
TP4002 (HOT) TP4003 (GND)	VR4002	REC/PLAY	
TAPE	M. EQ.	SPEC.	
BLANK TAPE	D.V.M.	$2.7\text{ mVrms} \pm 0.1\text{ mVrms}$	

SYSTEM CONTROL SECTION

14. UNDER CUT ADJUSTMENT

TP	ADJ.	MODE	INPUT
Pin 6 of P6011	VR6001	REC/PLAY	
TAPE	M. EQ.	SPEC.	
BLANK TAPE	OSCILLO-SCOPE/ DC POWER SUPPLY/ D.V.M.		

Note:

Do not connect AC adaptor, supply the DC voltage ($10.5\text{ V} \pm 0.05\text{ V}$) to Pin1 of P1001 (HOT) and Pin2 of P1001 (GND). Connect the Diode (MA165) Pin1 of P6011 for Cathode and Pin2 of P6011 for Anode to make Recording mode.

- (1) Turn the Power SW to ON.
- (2) Adjust the VR6001 so that the waveform is disappeared.




Fig. E11

15. CHARACTER POSITION ADJUSTMENT

TP	ADJ.	MODE	INPUT
VIEW FINDER	C6011	STOP	
TAPE	M. EQ.	SPEC.	
	VIEW FINDER	CHARACTER IS CENTRE	

- (1) Connect the E.V.F. unit to the Main unit.
- (2) Display the tape counter on the E.V.F.
- (3) Adjust the C6011 so that the character comes centre.




Fig.E12

SECTION 3

BLOCK DIAGRAM & SCHEMATIC DIAGRAM

3-1. CAMERA STAGE BLOCK DIAGRAM

← LUMINANCE SIGNAL


← PRE VIDEO SIGNAL

← CHROMINANCE SIGNAL


← B-Y/R-Y COMPOSITE SIGNAL

← R-Y SIGNAL

← B-Y SIGNAL




Y SIGNAL
Y SIGNAL





3-2. LUMINANCE & CHROMINANCE BLOCK DIAGRAM

← MAIN SIGNAL PATH IN R




3-3. SYSTEM CONTROL BLOCK DIAGRAM







3-4. SERVO BLOCK DIAGRAM



3-5. POWER SUPPLY BLOCK DIAGRAM



3-6. CAMERA OPERATION C.B.A. (VEP06614A)



CAMERA OPERATION C.B.A.	
Transistor	
Q6701	A-3
Q6702	A-4
Q6703	A-2
Connector	
P6701	A-4
P6702	B-4
P6703	A-4
P6704	A-4

ADDRESS INFORMATION

ZOOM SW C.B.A. (VEK4730)

WIDE TELE

(TO AUTO FOCUS)

P706-2 WIDE
P706-1 TELE
P706-3 GND
P706-4 HI SPEED ①

START/STOP SW C.B.A. (VEK4730)

SUB START/STOP SW C.B.A. (VEK4730)

AF/MF

VSS0126

SW6711

AF

MF

SW6709 EVQSU04W

PUSH AF

Q6702 2SB641 (AGC CONTROL)

R6731 1K

R6733 15K

R6732 390K

R6734 33K

R6735 22K

Q6701 2SD636 (VOLTAGE CONTROL)

R6736 15K

Q6703 2SD636 (FADE DRIVE)

DATE/TIME SW6708
SLF/INT SW6707
CAMERA SEARCH SW6706
SHUTTER SW6704
INDEX SW6703
ST-BY SW6702
STAND-BY D6701 BR36685
FADE SW6701

D6709
D6708
D6707
D6706
D6704
D6703
D6702

D6702 ~ D6709 MA165 x 7

P6702 (TO START/STOP SW)

1 KEY 8
2 SCAN 2

P6703 (TO AUTO FOCUS)

8 AWT ② P707-10
7 MACRO RESET P707-9
6 FADE P707-8
5 PUSH AF P707-7
4 AF/MF P707-6
3 OUT DOOR ② P707-5
2 GND P707-4
1 5V P707-3

P6704 (TO PROCESS)


3
2 AGC OUT P309-3
1 AGC CONT P309-1

P6701 (TO SYSTEM CONTROL)


1 MACRO RESET P6002-1
2 SCAN 1 P6002-2
3 SCAN 5 P6002-3
4 KEY 7 P6002-4
5 SCAN 6 P6002-5
6 ST-BY LED P6002-6
7 SCAN 2 P6002-7
8 KEY 8 P6002-8
9 GND P6002-9
10 FADER P6002-10

NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.

3-8. E.V.F. SCHEMATIC DIAGRAM




3-9. E.V.F. C.B.A. (VEP27033G)




3-10. AWT SCHEMATIC DIAGRAM

E.V.F. C.B.A.	
Transistor	
Q701	C-4
Q702	B-4
Q703	A-4
Integrated Circuit	
IC701	C-6
Adjustment	
VR701	B-6
VR702	B-5
VR704	A-6
VR705	A-6
Connector	
P1505	D-3
P701	B-3
P702	A-3
P703	A-3
P751	C-2
P761	A-1
BA701	A-5
BA751	D-2
J1504	D-3

ADDRESS INFORMATION



3-11. AWT C.B.A. (VEP26055A)



AWT C.B.A.	
Integrated Circuit	
IC601	A-2
IC602	B-4
Connector	
P601	A-1
P602	A-5

ADDRESS INFORMATION
 Ⓢ...COMPONENT SIDE
 Ⓢ...FOIL SIDE

3-12. PROCESS SCHEMATIC DIAGRAM

←■ LUMINANCE SIGNAL


←■ CHROMINANCE SIGNAL


← R-Y SIGNAL

← PRE VIDEO SIGNAL

← □ B-Y/R-Y COMPOSITE SIGNAL

← B-Y SIGNAL






NOTE: DO NOT USE ANY PART NUMBER SHOWN IN THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.

NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS STOP MODE WITH AIM THE CAMERA AT THE LOGARITHMIC GRAY SCALE CHART.


NOTE: THE WAVEFORM OF THIS DIAGRAM IS MEASURED WITH AIM THE CAMERA AT THE LOGARITHMIC GRAY SCALE CHART.

3-13. PROCESS C.B.A. (VEP23095A)


PROCESS CIRCUIT TP (Test Point)
WAVEFORM (REF. NO. 500 Series)




TP514 STOP
0.1V/20μsec. div. 0.32Vp-p




TP515 STOP
0.1V/20μsec. div. 0.45Vp-p




3-14. CCD DRIVE SCHEMATIC DIAGRAM



3-15. CCD DRIVE C.B.A. (VEP22085A)



CCD DRIVE CIRCUIT TP (Test Point)
WAVEFORM (REF. NO. 200 Series)





TP201 STOP
0.2V/20μsec. div. 0.8Vp-p

CCD DRIVE C.B.A.			
Transistor		Test Point	
Q201	C-1	TP201	C-3
Q202	B-2	TP201	O-6
Q203	B-1	Adjustment	
Q204	C-4		
Q205	C-6	C206	B-7
Q206	C-6	VR201	B-8
Q207	B-7	Connector	
Q208	C-7		
Q209	B-7	B201	A-4
Q210	B-7	B201	A-5
Integrated Circuit		FP201	C-4
		FP201	C-5
IC201	C-3		
IC202	B-8		
IC203	C-1		


ADDRESS INFORMATION
©... COMPONENT SIDE
○... FOIL SIDE

3-16. AUTO FOCUS SCHEMATIC DIAGRAM







AUTO FOCUS CIRCUIT TP (Test Point)
WAVEFORM (REF. NO. 700 Series)




TP702 STOP
2.0V/20μsec. div. 4.5Vp-p




TP703 STOP
2.0V/20μsec. div. 5.0Vp-p



TP704 STOP
10.0V/20msec. div. 30Vp-p




TP705 STOP
0.5V/5msec. div. 1.3Vp-p



TP710 STOP
0.1V/20μsec. div. 0.3Vp-p

3-17. AUTO FOCUS C.B.A. (VEP27044B)


AUTO FOCUS Section



AUTO FOCUS C.B.A.		
Transistor		
Q701	A-6	Ⓢ
Q704	E-7	Ⓢ
Q705	B-8	Ⓢ
Q706	A-2	Ⓢ
Q707	B-8	Ⓢ
Q708	C-7	Ⓢ
Q771	E-8	Ⓢ
Integrated Circuit		
IC701	F-6	Ⓢ
IC702	F-3	Ⓢ
IC704	D-6	Ⓢ
IC705	B-9	Ⓢ
IC706	C-6	Ⓢ
IC771	C-9	Ⓢ
Test Point		
TP702	C-5	Ⓢ
TP702	E-5	Ⓢ
TP703	A-6	Ⓢ
TP703	D-6	Ⓢ
TP704	C-8	Ⓢ
TP704	E-8	Ⓢ
TP705	B-5	Ⓢ
TP705	F-5	Ⓢ
TP709	C-5	Ⓢ
TP709	E-5	Ⓢ
TP710	A-2	Ⓢ
TP710	F-2	Ⓢ
Adjustment		
C703	B-7	Ⓢ
C737	C-2	Ⓢ
VR701	E-1	Ⓢ
VR703	B-9	Ⓢ
Connector		
B701	A-7	Ⓢ
B701	F-7	Ⓢ
FP701	A-5	Ⓢ
FP701	F-5	Ⓢ
P702	C-7	Ⓢ
P702	D-7	Ⓢ
P704	D-8	Ⓢ
P704	D-8	Ⓢ
P705	D-5	Ⓢ
P705	D-5	Ⓢ
P706	C-5	Ⓢ
P706	E-5	Ⓢ
P707	A-8	Ⓢ
P707	F-8	Ⓢ

ADDRESS INFORMATION
Ⓢ ... COMPONENT SIDE
Ⓢ ... FOIL SIDE

3-18. MAIN C.B.A. (VEP06612C) & VTR OPERATION C.B.A. (VEP06613A)




TO C.B.A. (VEK3414)

FE HEAD C.B.A. (VEP00H73B)


SUPPLY PHOTO C.B.A. (VEK3415)

VTR OPERATION C.B.A. (VEP06613A)



MAIN C.B.A. (VEP06612C)



(COMPONENT SIDE)



(FOIL SIDE)



13

14

15

16

17

18

19

20

21

3-19. POWER SUPPLY SCHEMATIC DIAGRAM

POWER SUPPLY Section on MAIN C.B.A.		
Transistor		
Q1001	A-20	Ⓢ
Q1002	B-1	Ⓢ
Q1003	A-3	Ⓢ
Q1004	B-21	Ⓢ
Q1005	B-19	Ⓢ
Q1006	C-15	Ⓢ
Q1007	B-21	Ⓢ
Q1008	B-19	Ⓢ
Q1011	B-18	Ⓢ
Transistor & Resistor		
QR1001	A-19	Ⓢ
QR1002	B-4	Ⓢ
Integrated Circuit		
IC1001	A-2	Ⓢ
IC1001	A-21	Ⓢ
IC1002	A-2	Ⓢ
IC1002	A-20	Ⓢ
IC1003	A-3	Ⓢ
IC1004	A-19	Ⓢ
IC1005	C-15	Ⓢ
Test Point		
TP1001	B-19	Ⓢ
TP1002	C-16	Ⓢ
TP1003	B-21	Ⓢ
TP1004	B-21	Ⓢ
TP1005	B-18	Ⓢ
Adjustment		
VR1001	A-19	Ⓢ
VR1002	B-20	Ⓢ
VR1003	A-20	Ⓢ
Connector		
P1001	B-1	Ⓢ
P1001	B-21	Ⓢ
P1003	A-1	Ⓢ
P1003	A-21	Ⓢ

ADDRESS INFORMATION
 Ⓢ ... COMPONENT SIDE
 Ⓢ ... FOIL SIDE

SERVO Section on MAIN C.B.A.		
Transistor		
Q2001	B-5	Ⓢ
Q2002	B-6	Ⓢ
Q2003	B-6	Ⓢ
Transistor & Resistor		
QR2005	C-18	Ⓢ
Integrated Circuit		
IC2001	D-4	Ⓢ
IC2002	C-17	Ⓢ
IC2005	B-5	Ⓢ
IC2006	B-17	Ⓢ
Test Point		
TP2001	C-16	Ⓢ
TP2002	D-18	Ⓢ
TP2003	E-18	Ⓢ
TP2004	C-17	Ⓢ
TP GND	C-19	Ⓢ
Adjustment		
VR2001	C-17	Ⓢ
Connector		
P2001	A-17	Ⓢ
P2001	A-5	Ⓢ
P2002	A-18	Ⓢ
P2002	A-4	Ⓢ

ADDRESS INFORMATION
 Ⓢ ... COMPONENT SIDE
 Ⓢ ... FOIL SIDE

SYSTEM CONTROL Section on MAIN C.B.A.		
Transistor		
Q1501	F-5	Ⓢ
Q1502	F-9	Ⓢ
Q1503	F-4	Ⓢ
Q6001	C-20	Ⓢ
Q6002	E-19	Ⓢ
Q6003	E-21	Ⓢ
Q6004	D-19	Ⓢ
Q6005	C-19	Ⓢ
Q6006	D-21	Ⓢ
Q6007	D-21	Ⓢ
Transistor & Resistor		
QR6001	C-20	Ⓢ
QR6002	C-19	Ⓢ
QR6003	C-2	Ⓢ
QR6004	D-20	Ⓢ
QR6005	C-1	Ⓢ
QR6006	C-20	Ⓢ
QR6009	D-21	Ⓢ
QR6010	C-1	Ⓢ
QR6011	D-21	Ⓢ
QR6014	D-21	Ⓢ
QR6017	D-21	Ⓢ
QR6019	C-21	Ⓢ
QR6020	D-19	Ⓢ
QR6022	E-19	Ⓢ
QR6027	D-21	Ⓢ
QR6029	C-17	Ⓢ
QR6030	E-8	Ⓢ
QR6031	D-8	Ⓢ
QR6032	E-7	Ⓢ
QR6033	D-15	Ⓢ
QR6034	E-8	Ⓢ
QR6035	E-19	Ⓢ
Integrated Circuit		
IC6001	C-2	Ⓢ
IC6002	D-2	Ⓢ
IC6003	E-1	Ⓢ
IC6004	C-21	Ⓢ
IC6005	D-18	Ⓢ
IC6005	D-4	Ⓢ
IC6006	C-20	Ⓢ
IC6006	D-20	Ⓢ
IC6007	D-1	Ⓢ
IC6008	E-15	Ⓢ
Adjustment		
C6011	C-21	Ⓢ
VR6001	C-19	Ⓢ
Connector		
P1503	E-4	Ⓢ
P1504	F-4	Ⓢ
P6002	E-10	Ⓢ
P6002	E-12	Ⓢ
P6003	E-8	Ⓢ
P6003	F-16	Ⓢ
P6004	D-19	Ⓢ
P6004	D-4	Ⓢ
P6005	C-19	Ⓢ
P6005	C-3	Ⓢ
P6006	A-10	Ⓢ
P6006	A-12	Ⓢ
P6007	C-20	Ⓢ
P6007	C-3	Ⓢ
P6010	C-1	Ⓢ
P6010	C-21	Ⓢ
P6011	D-1	Ⓢ
P6011	E-21	Ⓢ
P6012	C-19	Ⓢ
P6012	C-4	Ⓢ
P6013	E-1	Ⓢ
P6013	E-21	Ⓢ
P6014	C-19	Ⓢ
P6014	C-4	Ⓢ
P6016	E-13	Ⓢ
P6016	E-9	Ⓢ
P6501	E-16	Ⓢ

ADDRESS INFORMATION
 Ⓢ ... COMPONENT SIDE
 Ⓢ ... FOIL SIDE

SUB VIDEO & HEAD AMP Section on MAIN C.B.A.		
Transistor		
Q3801	C-14	Ⓢ
Q3802	B-8	Ⓢ
Q3803	B-12	Ⓢ
Q3804	A-12	Ⓢ
Q3805	C-10	Ⓢ
Q3806	C-10	Ⓢ
Q3808	A-15	Ⓢ
Q5001	B-16	Ⓢ
Q5002	A-15	Ⓢ
Q5003	A-8	Ⓢ
Q5004	A-16	Ⓢ
Q5005	A-16	Ⓢ
Transistor & Resistor		
QR3801	B-12	Ⓢ
QR3802	B-12	Ⓢ
QR3803	A-12	Ⓢ
QR3804	A-12	Ⓢ
QR3805	B-14	Ⓢ
QR3806	A-14	Ⓢ
QR3807	A-15	Ⓢ
QR3808	A-8	Ⓢ
QR3809	B-14	Ⓢ
QR5001	B-16	Ⓢ
QR5002	A-7	Ⓢ
QR5003	A-6	Ⓢ
Integrated Circuit		
IC5001	B-7	Ⓢ
Test Point		
TP3801	C-16	Ⓢ
TP3802	C-16	Ⓢ
TP3807	C-16	Ⓢ
TP5001	A-15	Ⓢ
TP5002	A-16	Ⓢ
TP5003	A-16	Ⓢ
Connector		
P3801	C-12	Ⓢ
P3801	C-11	Ⓢ
P3802	D-11	Ⓢ
P3802	D-12	Ⓢ
P3803	B-13	Ⓢ
P3803	B-9	Ⓢ
P3804	C-10	Ⓢ
P3804	C-12	Ⓢ
P3805	A-10	Ⓢ
P3805	A-12	Ⓢ
P5001	A-16	Ⓢ
P5001	A-7	Ⓢ

ADDRESS INFORMATION
 Ⓢ ... COMPONENT SIDE
 Ⓢ ... FOIL SIDE


AUDIO Section on MAIN C.B.A.		
Transistor		
Q1504	F-10	Ⓢ
Q4001	C-17	Ⓢ
Q4005	D-16	Ⓢ
Transistor & Resistor		
QR4002	D-6	Ⓢ
QR4003	C-18	Ⓢ
QR4004	D-16	Ⓢ
Integrated Circuit		
IC4001	D-6	Ⓢ
IC4002	D-17	Ⓢ
Test Point		
TP4001	C-17	Ⓢ
Adjustment		
C4002	D-5	Ⓢ
VR4001	D-16	Ⓢ
Connector		
P4001	D-16	Ⓢ
P4001	D-7	Ⓢ
P4002	D-18	Ⓢ
P4002	D-5	Ⓢ
P4004	C-16	Ⓢ
P4004	C-7	Ⓢ

ADDRESS INFORMATION
 Ⓢ ... COMPONENT SIDE
 Ⓢ ... FOIL SIDE
 Ⓢ ... COMPONENT SIDE
 Ⓢ ... FOIL SIDE

AUDIO INTERFACE Section on MAIN C.B.A.		
Transistor		
Q4802	D-12	Ⓢ
Q4804	D-11	Ⓢ
Q4805	E-13	Ⓢ
Q4807	D-8	Ⓢ
Q4808	D-9	Ⓢ
Q4810	C-13	Ⓢ
Transistor & Resistor		
QR4803	C-13	Ⓢ
QR4804	B-13	Ⓢ
QR4805	C-9	Ⓢ
QR4806	D-15	Ⓢ
QR4807	D-9	Ⓢ
QR4808	E-9	Ⓢ
Integrated Circuit		
IC4801	D-10	Ⓢ
IC4804	C-13	Ⓢ
IC4805	D-14	Ⓢ
Test Point		
TP4806	C-16	Ⓢ
Connector		
P4801	D-11	Ⓢ
P4801	D-12	Ⓢ


ADDRESS INFORMATION
 Ⓢ ... COMPONENT SIDE
 Ⓢ ... FOIL SIDE

E
D
C
B
A



NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.

NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS STOP MODE.

[illegible][illegible]


3-20. SERVO SCHEMATIC DIAGRAM

← CAPSTAN SERVO SPEED LOOP.


← CYLINDER SERVO SPEED LOOP.

← CAPSTAN SERVO PHASE LOOP.

← CYLINDER SERVO PHASE LOOP.



POP. ← □ CYLINDER SERVO PHASE LOOP.



NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE IN THE BRACKETS () ON THIS DIAGRAM IS RECORD MODE WITH PAL COLOUR SIGNAL.
THE MEASUREMENT MODE OF THE DC VOLTAGE OUT OF THE BRACKETS ON THIS DIAGRAM IS PLAYBACK MODE WITH PAL COLOUR SIGNAL.

NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.


5

6


2

3—53


TP2001 PLAY/REC
5.0V/10msec. div. 5.0Vp-p



TP2002 REC
1.0V/10msec. div. 5.0Vp-p



TP2002 PLAY
2.0V/10msec. div. 4.8Vp-p



TP2004 PLAY/REC
5.0V/20msec. div. 5.0Vp-p

[illegible]

3-54


SYSTEM CONTROL ICs DC VOLTAGE CHART

REF. NO.	IC6001																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16				
STOP	0	4.7	4.7	0	0	4.9	4.8	0	4.8	4.3	4.9	4.9	4.9	0	4.9	4.9				
PLAY	0	0	4.7	0	0	0	4.7	0	4.8	4.3	4.9	4.9	0	0	4.9	4.9				
F.F	0	4.7	4.7	0	0	4.8	4.7	0	4.8	4.3	4.8	4.9	4.8	0	4.9	4.9				
REF. NO.	IC6002																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
STOP	5.0	0	0	0	3.2	4.9	4.6	4.8	4.9	0	0	8.6	4.8	3.6	3.6	0	0	0	0	0.1
PLAY	5.0	0	0	0	3.2	4.9	4.6	4.8	4.8	0	0	8.6	3.8	3.6	3.6	3.4	2.3	0	0	1.0
F.F	5.0	0	0	0	3.2	4.9	4.6	4.8	4.8	0	0	6.3	4.7	3.6	3.6	0	3.9	0	0	0.7
REF. NO.	IC6002																			
MODE	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
STOP	0	0	0	0	4.9	2.2	1.0	3.5	0	4.9	4.7	4.7	4.7	4.9	4.7	4.9	4.9	0	0	4.5
PLAY	0.9	0	0	0	4.9	2.1	0.9	3.5	0	4.9	4.7	4.7	4.7	4.9	4.9	4.7	4.7	0	4.7	0
F.F	0	0	0	0	4.9	2.1	1.0	3.3	0	4.9	4.7	4.7	4.7	4.9	4.7	4.9	4.9	0	4.8	4.5
REF. NO.	IC6002																			
MODE	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60
STOP	4.3	0	8.6	4.5	8.6	5.0	4.9	4.8	4.7	4.7	4.7	4.8	4.9	4.9	0	0	0	0	4.9	0
PLAY	0	4.9	8.6	4.5	8.6	5.0	3.8	4.8	4.6	4.7	4.7	4.8	4.9	4.9	0	0	0	0	4.9	0
F.F	4.3	0	8.6	4.5	8.6	5.0	4.2	4.8	4.7	4.7	4.7	4.9	4.9	4.9	0	0	0	4.9	4.9	0
REF. NO.	IC6002																			
MODE	61	62	63	64	65	66	67	68	69	70	71	72								
STOP	0	0	4.9	0	0	0	4.9	0	4.9	4.8	4.9	1.8								
PLAY	0	2.5	2.5	1.1	0	1.5	4.9	0	4.9	4.8	4.9	2.6								
F.F	0	2.5	4.9	0.1	0	0.1	4.9	0	4.9	2.5	4.9	2.5								
REF. NO.	IC6003																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14						
STOP	0	0.1	0	0	0	0	0	0	0	0	0	0.3	0	0						
PLAY	0	0.2	0	0	0	0	0	0	0	0	0	0.3	0	0						
F.F	0	0	0	0	0	0.4	0	0.7	0.6	0.3	0	0.4	0	0.3						
REF. NO.	IC6004																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
STOP	5.0	4.8	0	3.7	0	5.0	1.9	2.4	2.4	0	0	0	0	0	0	0	0	0.1	0.1	5.0
PLAY	5.0	3.8	0	3.7	0	5.0	1.9	2.4	2.4	0	0	0	0	0	0	0	0	0.1	0.1	5.0
F.F	0	4.8	0	3.7	0	5.0	1.9	2.4	2.4	0	0	0	0	0	0	0	0	0	0	5.0
REF. NO.	IC6005																			
MODE	1	2	3	4	5	6	7	8	9											
STOP	7.2	13.1	0	0	0	0	0	13.1	7.2											
PLAY	7.2	13.0	1.6	0	0	0	1.0	13.0	7.2											
F.F	7.2	13.0	0	0	0	0	0	13.0	7.2											
REF. NO.	IC6006																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16				
STOP	0	4.7	4.7	1.5	4.7	4.9	4.9	0	0.1	3.8	0.1	0	0	0	4.9	4.9				
PLAY	0	4.7	4.7	1.5	4.9	0	4.9	0	1.7	3.0	0.1	4.8	4.9	0	4.9	4.9				
F.F	0	4.7	4.7	1.2	4.7	4.9	4.9	0	0.1	3.0	0.1	0	0	0	4.9	4.9				
REF. NO.	IC6007																			
MODE	1	2	3																	
STOP	0	4.9	4.9																	
PLAY	0	4.9	4.9																	
F.F	0	4.9	4.9																	
REF. NO.	IC6008																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16				
STOP	0	4.7	4.7	4.9	4.9	4.9	4.9	0	4.9	4.9	4.9	4.9	4.9	4.9	4.9	4.9				
PLAY	0	4.7	4.7	4.9	4.9	0	4.9	0	3.3	4.9	4.9	0	4.9	4.9	4.9	4.9				
F.F	0	4.7	4.7	0	4.9	4.9	4.9	0	3.3	4.4	4.9	0	4.9	4.9	4.9	4.9				


SYSTEM CONTROL TRANSISTORS DC VOLTAGE CHART

REF. NO.	Q6001			Q6002			Q6003			Q6004			Q6005			Q6007(A)		
MODE	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B
STOP	13.1	7.2	13.1	8.7	8.7	8.0	0	3.6	0.1	7.2	13.1	7.8	-0.5	13.1	0.1	0	4.9	0
PLAY	13.0	7.1	13.0	8.6	8.6	7.9	0	3.6	0.1	7.2	13.0	7.8	-1.0	13.0	-0.5	0	4.9	0
F.F	13.0	7.2	13.0	8.6	8.6	7.9	0	3.6	0.1	7.1	13.0	7.8	2.7	12.1	2.8	0	4.9	0
REF. NO.	Q6007(B)																	
MODE	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B
STOP	0	4.9	0															
PLAY	0	4.9	0															
F.F	0	4.9	0															
REF. NO.	QR6001(A)			QR6001(B)			QR6002			QR6003(A)			QR6003(B)			QR6004		
MODE	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B
STOP	0	0	4.9	4.9	4.8	0	0	0	7.2	4.7	4.4	4.8	4.7	4.4	4.9	0	10.1	0
PLAY	0	5.0	0	4.9	4.8	0	0	0	7.1	4.7	4.4	4.8	4.7	4.4	2.3	0	10.0	0
F.F	0	0	4.9	4.9	4.8	0	0	0	7.1	4.7	4.5	4.8	4.7	4.4	4.8	0	10.0	0
REF. NO.	QR6005			QR6006(A)			QR6006(B)			QR6009			QR6010			Q6011(A)		
MODE	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B
STOP	4.7	4.4	4.9	4.9	4.6	4.9	4.9	4.6	4.9	4.7	4.6	0	0	0	13.4	4.7	4.5	3.9
PLAY	4.7	4.6	4.9	4.9	4.6	4.9	4.9	4.6	4.9	4.7	5.2	0	0	0	13.4	4.7	5.0	2.3
F.F	4.7	4.4	4.8	4.9	4.6	4.9	4.9	4.6	4.9	4.7	4.6	0	0	0	13.4	4.7	4.7	3.9
REF. NO.	QR6011(B)			QR6014(A)			QR6014(B)			QR6017			QR6019(A)			QR6019(B)		
MODE	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B
STOP	4.7	4.6	0	4.7	4.6	0.5	4.7	4.7	0.6	4.9	4.9	0	4.9	0	4.9	4.9	1.9	4.9
PLAY	4.6	5.2	3.6	4.7	5.2	0.5	4.7	5.2	0.6	4.9	0.1	4.9	4.9	0	4.9	4.9	2.9	4.9
F.F	4.7	4.6	0	4.7	4.6	0.5	4.7	4.7	0.6	4.9	4.9	0	4.9	0	4.9	4.9	0.1	4.9
REF. NO.	QR6020(A)			QR6020(B)			QR6022			QR6027			QR6029			QR6030		
MODE	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B
STOP	0	0	0	0	0	0	8.7	0	8.6	-0.2	4.7	0.2	0	8.0	0	0	0	4.9
PLAY	0	2.2	0	0	2.2	3.5	8.7	0	8.6	-1.2	4.8	-1.2	0	8.0	0	0	1.8	0
F.F	0	0	0	0	0	0	8.6	2.8	6.8	-1.9	5.5	-1.9	0	8.0	0	0	0	4.9
REF. NO.	QR6031(A)			QR6031(B)			QR6032(A)			QR6032(B)			QR6033(A)			QR6033(B)		
MODE	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B
STOP	4.9	-0.1	4.9	4.9	0	4.9	4.9	-0.1	4.9	4.9	-0.1	4.9	4.9	0.1	4.9	4.9	0.1	4.9
PLAY	4.9	-0.5	4.9	4.9	0.5	4.9	4.9	-0.7	4.9	4.9	-0.6	4.9	4.9	0	4.9	4.9	4.8	0
F.F	4.9	-0.6	4.9	4.9	0	4.9	4.9	4.8	0	4.9	0	4.9	4.9	-0.5	4.9	4.9	-0.4	4.9
REF. NO.	QR6034																	
MODE	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B
STOP	4.9	0	4.9															
PLAY	4.9	-1.0	4.9															
F.F	4.9	0	4.9															


3-21. SYSTEM CONTROL SCHEMATIC DIAGRAM



3-22. AUDIO SCHEMATIC DIAGRAM




3-23. AUDIO IN




3-23. AUDIO INTERFACE SCHEMATIC DIAGRAM

← MAIN SIGNAL PATH IN REC MODE → MAIN SIGNAL PATH IN PLAYBACK MODE




AUDIO CIRCUIT TP (Test Point) WAVEFORM (REF. NO. 4000 Ser)



TP4001 PLAY/REC 0.5V/0.5msec. div. 1.0Vp-p

AUDIO INTERFACE CIRCUIT TP (Test Point) WAVEFORM (REF. NO. 4800 Series)




TP4806 0.5V/0.5msec. div. 1.5Vp-p

3-24. SUB VIDEO & HEAD AMP SCHEMATIC DIAGRAM

MAIN SIGNAL PATH IN REC MODE

MAIN SIGNAL PATH IN PLAYBACK MODE




MAIN SIGNAL PATH IN REC MODE


MAIN SIGNAL PATH IN PLAYBACK MODE

SUB VIDEO & HEAD AMP Section


SUB VIDEO CIRCUIT TP (Test Point)
WAVEFORM (REF. NO. 3800 Series)



TP3801 REC
0.5V/20μsec. div. 1.2Vp-p





TP3801 PLAY
0.5V/20μsec. div. 1.3Vp-p



NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE IN THE BRACKETS () ON THIS DIAGRAM IS RECORD MODE WITH PAL COLOUR SIGNAL.



THE MEASUREMENT MODE OF THE DC VOLTAGE OUT OF THE BRACKETS ON THIS DIAGRAM IS PLAYBACK MODE WITH PAL COLOUR SIGNAL.

A — B — C — D — E






ADDRESS INFORMATION
 (C) ... COMPONENT SIDE
 (F) ... FOIL SIDE




3-71




IC3001 (VEFH08D)

PIN NO.	WAVEFORM	PIN NO.	WAVEFORM
2		19	
3		20	
6		21	
7		22	
8		24	
10		31	
13		33	
14		35	
16		39	
18		42	


LUMINANCE CIRCUIT TP (Test Point) WAVEFORM (REF. NO. 3000 Series)




TP3001 REC
0.2V/20μsec. div. 0.7Vp-p



TP3004 PLAY
0.2V/10msec. div. 0.6Vp-p




TP3005 REC/PLAY
0.5V/20μsec. div. 1.2Vp-p




TP3006 REC
0.5V/20μsec. div. 1.4Vp-p


CHROMINANCE CIRCUIT TP (Test Point) WAVEFORM (REF. NO. 8000 Series)



TP8002 REC/PLAY
0.2V/10msec. div. 0.4Vp-p



TP8003 0.2V/20μsec. div.
REC: 0.51Vp-p
PLAY: 0.62Vp-p




TP8004 REC/PLAY
0.5V/20μsec. div. 1.1Vp-p


T NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR
TO ORDER A PART, PLEASE REFER TO PARTS LIST.

NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE IN THE BRACKETS () ON THIS DIAGRAM IS RECORD MODE
WITH PAL COLOUR SIGNAL.
THE MEASUREMENT MODE OF THE DC VOLTAGE OUT OF THE BRACKETS ON THIS DIAGRAM IS PLAYBACK MODE
WITH PAL COLOUR SIGNAL.

3-27. VTR JACK SCHEMATIC DIAGRAM




3-28. VTR JACK C.B.A. (VEP04281B)




VTR JACK C.B.A.	
Transistor	
Q4901	B-2
Transistor & Resistor	
QR4901	B-2
Connector	
P4901	B-1
P4902	C-4
P4903	C-1
P4904	C-5
P4905	A-1
P4906	C-3
P4907	C-5

ADDRESS INFORMATION


3-29. CIRCUIT BOARD LAYOUT



3-30. CAMERA INTERCONNECTION SCHEMATIC DIAGRAM




3-31. VTR INTERCONNE




3-31. VTR INTERCONNECTION SCHEMATIC DIAGRAM


INTERCONNECTION Section




3-32. ICs & TRs INFORMATION




AN1358S
AN6562S
AN1358S
AN6914S
μPC1513G
NJM3415M
MST001MS
TL8809F
LM2964M
RC4558M




AN3580SB
MN3819S
MN3820S
μPD4094BG
AN2012S
RZ4052BM
AN6664S
MN4053BS




AN2154FAP
AN2254FAP
AN2584NFAP
AN3346FBP




MN3107CS
μPD6145G617A




M54543AL




M50963




MN12821




2SA1531 2SC3931
2SA812 2SC3938
2SA1255 2SC4176
2SA1532 2SD1328
2SA1610 2SD1483
2SB970 2SD1819
2SC3930 2SD1820
2SB1218 2SD601
2SB709 2SA1022
2SC3138
2SD602




MN15867VFK



AN2510S
AN3841SR
μPC2300G




S3500A2
LM2902M




AN3798NS




2SB641
2SD636
2SD1526
2SD2177S




2SB956
2SD968A
2SD1119




2SA1175




XN4601




XN4501
XN4504




XN4608




MN73912XWB
MN67461VDJF
MN73512XWA




VCR0250




M51096AU




M52059AFP




XN1501
FMW1




XN4401




XN6401




TA8402F




BA3308




VEFH08D




XN1401
FMS1




UN2211
DTA114EK
GA1A4M




UN5212
GA1F4M




UN102




BA6149LS




AN6545SP



UN2213
UN5213
GA1L4M




UN5217
GA1F4Z




UN5113
GN1L4M


22
21




MN12821




2SA1531 2SC3931
2SA812 2SC3938
2SA1255 2SC4176
2SA1532 2SD1328
2SA1610 2SD1483
2SB970 2SD1819
2SC3930 2SD1820
2SB1218 2SD601
2SB709 2SA1022
2SC3138
2SD602




2SA1175




UN5211
GN1F4M




UN521E
GA1L4L




UN5116
GN1L3Z




UN5117
GN1F4Z




UN5110
GN1L4Z




UN5111
GN1A4M




XN4501
XN4504




XN4608




IMD2




XN1113
FMA2




XN1212
FMG1




XN4401




XN6401




XN1213
FMG2




XN1112
FMA1




XN1217




UN2211
DTA114EK
GA1A4M



UN5212
GA1F4M



UN5217
GA1F4Z




UN5113
GN1L4M

① CAMERA LENS SECTION




[illegible]


③ MECHANISM SECTION (2)




④ CHASSIS & FRAME SECTION




④ CHASSIS & FRAME SECTION




5 E.V.F. SECTION




6 PACKING PARTS & ACCESSORIES SECTION (NV-M1000EM)



⑥ PACKING PARTS & ACCESSORIES SECTION (NV-M1000EM)



⑦ PACKING PARTS & ACCESSORIES SECTION (NV-M1000EN)



Note: 1. * Be sure to make your orders of replacement parts according to this list.

2. IMPORTANT SAFETY NOTICE

Components identified with the mark (!) have the special characteristics for safety. When replacing any of these components, use only the same type.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
143(2)	VMO653	CUT WASHER	1	
144(2)	VDG0372	DRIVE GEAR (B)	1	
145(2)	VXSO076	EARTH HOLDER UNIT	1	
147(2)	VDG0371	DRIVE GEAR (A)	1	
148(2)	VDG0202	CAM GEAR	1	
149(2)	VMO388	THRUST WASHER	3	
150(2)	VXL1654	MAIN ROD (K) UNIT	1	
151(2)	VDG0211	LOADING GEAR (C) (2)	1	
152(2)	VMB1324	LOADING GEAR (C) SPRING	1	
153(2)	VDG0210	LOADING GEAR (C) (1)	1	
154(2)	VMA7228	GUARD PLATE	1	
155(2)	VML1707	DRIVE ARMKICK LEVER	1	
156(2)	VMB1388	DRIVE ARMKICK LEVER SPRING	1	
157(2)	VXP0632	SECTOR GEAR UNIT	1	
158(2)	VMA6560	SAFETY TAB SW BASE	1	
159(2)	VSH0023	SAFETY TAB SW	1	
160(2)	VDG0207	DRIVE GEAR (C)	1	
161(2)	VSS0193	MODE SELECT SW	1	
163(2)	VEK3398	STATOR UNIT	1	
164(2)	VXP0634	ROTOR UNIT	1	
165(2)	VXP0897	MAIN PULLEY UNIT	1	
166(2)	VMO155	CAPSTAN BELT	1	
167(2)	VMD0935	BELT COVER	1	
200(3)	VHD0282	P2 ADJUST PLATE SCREW	1	
201(3)	VMA6542	P2 ADJUST PLATE	1	
202(3)	VMD0701	SUPPLY POST STOPPER	1	
203(3)	VMD1166	V STOPPER BASE	1	
204(3)	VXP0841	SUPPLY ROLLER POST UNIT	1	
205(3)	VQO0842	P2 CAP	1	
206(3)	VMD0769	TAPE PROTECTOR	1	
207(3)	VXA2221	SUPPLY SHAFT HOLDER(1)UNIT	1	
208(3)	VXA2256	SUPPLY SHAFT HOLDER ANGLE	1	
		UNIT	1	
209(3)	VMD144	CONNECTION ROD	1	
210(3)	VMK1282	RING GUIDE SLEEVE UNIT	3	
211(3)	VXA2231	CONNECTION TIE UNIT	1	
212(3)	VMB1319	LOADING SPRING	1	
213(3)	VXA2253	LOADING RING (S) (1) UNIT	1	
214(3)	VDP1160	RING GUIDE ROLLER	3	
215(3)	VMB1319	LOADING SPRING	1	
216(3)	VXA3576	LOADING RING (T) (1) UNIT	1	
217(3)	VMO250	PRESSER SPRING	1	
218(3)	VMD1279	RING GUIDE SLEEVE	3	
219(3)	VMD1155	LOADING GUIDE (S) (1)	1	
220(3)	VMD1128	LOADING GUIDE (S) (2)	1	
221(3)	VMK1088	SUPPLY UPPER LIMITER	1	
222(3)	VMS2888	P1 POST SLEEVE (B)	1	
223(3)	VMK1581	P1 COLLAR	1	
224(3)	VDP1265	P1 ROLLER	1	
225(3)	VMA6547	P1 LIMITER PLATE	1	
226(3)	VHD0403	SCREW	1	
227(3)	VXA3112	P1 BASE (1) UNIT	1	
228(3)	VXD0098	THRUST SPACER	1	
229(3)	VHD0204	THRUST SCREW NUT	1	
230(3)	VHD0368	ROLLER POST SCREW	2	
231(3)	VMO0775	DUST SEAL	2	
232(3)	VXD0108	CAPSTAN HOUSING UNIT	1	
233(3)	VXP0927	TAKE-UP ROLLER POST UNIT	1	
234(3)	VMA6546	TAKE-UP SHAFT HOLDER ANGLE	1	
235(3)	VXA3116	TAKE-UP SHAFT HOLDER (A)	1	
		UNIT		
236(3)	VMD1165	TAKE-UP LOADING BASE	1	
237(3)	VMO352	SHAFT HOLDER PRESSURE	1	
		SPRING		
238(3)	VMA7226	SHAFT HOLDER PLATE ANGLE	1	
239(3)	LN59NV	LED	1	
240(3)	VHD0367	TAKE-UP SHAFT ADJ. SCREW	1	
242(3)	VMD0288	LOADING MOTOR UNIT	1	
245(3)	VMB1747	TENSION SPRING	1	
246(3)	VXL1262	TENSION ARM UNIT	1	
247(3)	VX20245	TENSION BAND UNIT	1	
248(3)	VML2065	BAND RELEASE ARM	1	
249(3)	VML1631	TENSION KICK LEVER	1	
250(3)	VML2064	EJECT LEVER (A)	1	
251(3)	VXA3020	SUPPORTER UNIT	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
252(3)	VMB1405	BRAKE SPRING	1		334(4)	VSC3014	SHIELD CASE (LID)	1	
253(3)	VX20207	BRAKE (R) UNIT	1		335(4)	VXK0965	TOP FRAME UNIT	1	
254(3)	VX20206	BRAKE (L) UNIT	1		336(4)	VMD1471	TOP FRAME	1	
255(3)	VXA2392	BRAKE PLATE (1) UNIT	1		337(4)	VKM2041	HANDLE TOP COVER	1	
256(3)	VML2073	EJECT LEVER (B)	1		338(4)	VMP2533	SHOULDER BELT ANGLE (FRONT)	1	
257(3)	VED0131	A/C HEAD UNIT	1		339(4)	VMP2587	SHOULDER BELT ANGLE (REAR)	1	
258(3)	VHD0275	A/C HEAD ADJUST SCREW	1		340(4)	VMP1079	SHOE	1	
259(3)	VMB1321	A/C HEAD ADJUST SPRING	1		341(4)	VMO0575	SHOE SPRING	1	
260(3)	VHD0381	A/C HEAD TILT ADJUST SCREW	1		342(4)	VVK3075	BATTERY CASE 1 UNIT	1	
261(3)	VXL1696	A/C HEAD ARM UNIT	1		343(4)	VGU3441	BATTERY EJECT BUTTON	1	
262(3)	VJF0760	A/C HEAD BINDER	1		344(4)	VQ1122	BATTERY LOCK PIECE	1	
263(3)	VHNO077	A/C HEAD ARM NUT	1		345(4)	VQ1181	BATTERY STOPPER PIECE	1	
264(3)	VMB1320	A/C HEAD SPRING	1		346(4)	VMO0238	BATTERY STOPPER FIXING	1	
265(3)	VDO0208	LOADING GEAR (A)	1				ANGLE		
266(3)	VDO0461	LOADING GEAR (B)	1		347(4)	VMB1610	BATTERY STOPPER SPRING	1	
267(3)	VHNO072	ADJUST NUT	1		348(4)	VQ1129	BATTERY CATCHER	1	
268(3)	VHNO047	M2 NYLON NUT	2		349(4)	VMB1614	BATTERY EJECT SPRING	1	
269(3)	VMS2693	P4 POST SLEEVE	1		350(4)	VVK3076	JACK PLATE 1 UNIT	1	
270(3)	VXJ0057	P5 POST SLEEVE	1		351(4)	VGU5009	JACK KNOB	1	
271(3)	VMB1322	P4, P5 SPRING	2		352(4)	VVK2503	BATTERY HOLDER UNIT	1	
272(3)	VML2067	PINCH LEVER	1		353(4)	VJR0363	ELECTRODE (-)	1	
273(3)	VMB2071	PINCH LEVER SPRING	1		354(4)	VMO0326	ELECTRODE (+)	1	
274(3)	VXL1652	PINCH ROLLER ARM (1) UNIT	1		355(4)	VQ2027	BATTERY CASE COVER	1	
275(3)	VXL1650	PINCH ARM UNIT	1		357(4)	VKF0831	BATTERY DOOR	1	
276(3)	VMB1326	PINCH ARM SPRING	1		358(4)	VMO0237	BATTERY DOOR SPRING	1	
277(3)	VXL1264	SOFT BRAKE LEVER (S) UNIT	1		359(4)	VEJ0992	VTR JACK PLATE UNIT	1	
278(3)	VMB1314	SOFT BRAKE SPRING (S)	1		370(4)	VEX4736	MIC UNIT	1	
279(3)	VMB1771	REW ARM SPRING	1		400(5)	VVK2993	E.V.F. TOP COVER UNIT	1	
280(3)	VXL1649	FF/REW ARM UNIT	1		401(5)	VKM1777	E.V.F. BOTTOM COVER	1	
282(3)	VBS0021	FE HEAD	1		402(5)	VQ1826	E.V.F. HOOD	1	
283(3)	VMD1129	FE HEAD BASE	1		403(5)	VGL0393	LED PANEL LIGHT	1	
284(3)	VMB1447	SUPPORTER SPRING	1		404(5)	VGF0338	VOLUME CAP	1	
285(3)	VXA3579	SLIDE BASE (O) UNIT	1		405(5)	VMO0489	E.V.F. ROTATION SPRING	1	
286(3)	VMB1965	SLIDE SPRING	1		406(5)	VKM2140	CRT TOP CASE	1	
287(3)	VML2285	IMPEDANCE LEVER	1		407(5)	VMO0316	EYE CAP HOLDER SPRING	1	
288(3)	VHNO109	PUSH NUT	1		408(5)	VKF1255	EYE CAP HOLDER	1	
289(3)	VMB1964	IMPEDANCE DRIVE SPRING	1		409(5)	VDL0140	EYE CAP LENS	1	
290(3)	VXL1879	IMPEDANCE ARM (1) UNIT	1		410(5)	VMO0411	EYE CAP	1	
291(3)	VDP1285	IMPEDANCE ROLLER	1		411(5)	VKM2141	CRT BOTTOM COVER	1	
292(3)	VWX1088	SUPPLY UPPER LIMITER	1		412(5)	VDL0141	MIRROR	1	
294(3)	VXA2220	SUPPLY SHAFT HOLDER UNIT	1		413(5)	VGU3895	EYESIGHT CORRECTION KNOB	1	
300(4)	VVP2991	CASSETTE COVER UNIT	1		414(5)	VDL0139	EYESIGHT CORRECTION LENS	1	
301(4)	VHD0371	CASSETTE COVER SCREW	2		415(5)	VKF0947	LENS HOLDER	1	
302(4)	VVK3073	SIDE CASE (L) 1 UNIT	1		416(5)	VKF1278	LENS HOLDER GUIDE	1	
303(4)	VVK3074	GRIP CASE 1 UNIT	1		417(5)	VBC3604	E.V.F. CABLE UNIT	1	
304(4)	VYC0387	GRIP BELT UNIT	1		418(5)	ELY07V552A	DEFLECTION YOKE	1	
305(4)	VHD0386	GRIP BELT SCREW	1		419(5)	VJF0501	CRT HOLDER	1	
306(4)	VQ11790	ZOOM BUTTON PIECE	1		420(5)	VWX1004	CRT PROTECTOR RUBBER	1	
307(4)	VGU5007	ZOOM BUTTON	1		421(5)	MO2JV48WB	CRT	1	
308(4)	VMO0462	SWITCH RUBBER PIECE	2		422(5)	VJF0729	CRT MASKING	1	
309(4)	VKF0950	HOOD CAP	1		423(5)	VGL0416	LED SHEET	1	
310(4)	VQ11350	HOOD STRAP	1		450(6)	VQT3436	OPERATING INSTRUCTIONS (ENGLISH/ARABIC)	1	<1> NV-M1000EM
311(4)	VMO0257	E.V.F. SHOE SPRING	1		450(6)	VQT3500	OPERATING INSTRUCTIONS (HINDI/URDU)	1	<1> NV-M1000EM
312(4)	VMP1073	E.V.F. SHOE	1						
313(4)	VMP1072	E.V.F. ROTATION STAND	1		451(6)	VPN2612	CUSHION	1	NV-M1000EM
314(4)	WW-12	WAVING WASHER	1		452(6)	VPK5144	PACKING	1	NV-M1000EM
315(4)	VWX1123	E.V.F. ROTATION SPACER	1		453(6)	VPK1174	ACCESSORY PAD	1	NV-M1000EM
316(4)	VMP2532	E.V.F. ANGLE	1		454(6)	VPC0131	SHOULDER STRAP	1	NV-M1000EM
317(4)	VQ11213	E.V.F. ROTATION PIECE (A)	1		455(6)	VJA0180	BATTERY PACK CHARGING CONNECTOR	1	NV-M1000EM
318(4)	VQ11214	E.V.F. ROTATION PIECE (B)	1		456(6)	VJA0573	3P DC INPUT CORD	1	NV-M1000EM
319(4)	VDB0876	E.V.F. CLICK BALL	1		457(6)	VFA0039	AV OUTPUT CORD	1	NV-M1000EM
320(4)	VMO0576	E.V.F. CLICK SPRING (A)	1		458(6)	VJSS0070	POWER PLUG ADAPTOR	1	NV-M1000EM
321(4)	VMO0609	E.V.F. CLICK SPRING (B)	1		459(6)	VJA0376	RF CORD	1	NV-M1000EM
322(4)	VVK3144	SIDE CASE (R) 1 UNIT	1		460(6)	VYQ0367	CUSHION UNIT	1	NV-M1000EM
323(4)	VSC3023	CAMERA EARTH PLATE	1		500(7)	VQT3428	OPERATING INSTRUCTIONS (ENGLISH/CHINESE)	1	NV-M1000EM
324(4)	VGP2433	CAMERA OPERATION PANEL	1		501(7)	VPN2614	CUSHION (UPPER)	1	NV-M1000EM
325(4)	VGU5008	SLIDE KNOB	2		502(7)	VPN2615	CUSHION (LOWER)	1	NV-M1000EM
326(4)	VXU0959	OPERATION PANEL UNIT	1		503(7)	VPG5143	PACKING	1	NV-M1000EM
327(4)	VKF1388	CURSOR	1		504(7)	VFC0131	SHOULDER STRAP	1	NV-M1000EM
328(4)	VKF1387	RESET/MEMORY LID	1		505(7)	VJA0180	RECHARGEABLE BATTERY	1	NV-M1000EM
329(4)	VKF1385	BATTERY LID	1				CATCHER	1	NV-M1000EM
330(4)	VHD0437	BATTERY LID SCREW	1		506(7)	VFA0039	AUDIO/VIDEO CORD	1	NV-M1000EM
331(4)	VKM2040	E.V.F. BASE CASE	1						
332(4)	VDW0073	LENS HOOD	1						
333(4)	VYQ0096	TRIPOD FIXING BRACKET UNIT	1						

[illegible]

4-3. ELECTRICAL REPLACEMENT PARTS LIST

Note: 1. * Be sure to make your orders of replacement parts according to this list.
 2. IMPORTANT SAFETY NOTICE
 Components identified with the mark (!) have the special characteristics for safety. When replacing any of these components, use only the same type.
 3. Unless otherwise specified,
 All resistors are in OHMS, K=1,000 OHMS. All capacitors are in MICRO-FARADS (uf), P=uf.
 4. The P.C. Board units marked with '■' show below the main assembled parts.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
		---- CAMERA SECTION ----		
	VEP26055A	AWT C.B.A.	1 (NLA)	
	VEP22085A	CCD DRIVE C.B.A.	1 (NLA)	
	VEP23095A	PROCESS C.B.A.	1 (NLA)	
	VEP27044B	AUTO FOCUS C.B.A.	1 (NLA)	
	VEPO6614A	CAMERA OPERATION C.B.A.	1 (NLA)	
	VEPOOP37A	AF & ZOOM POSITION C.B.A.	1 (NLA)	
		----- E.V.F. SECTION -----		
	VEP27033G	E.V.F. C.B.A.	1 (NLA)	
	VEP27042A	E.V.F. LED C.B.A.	1 (NLA)	
	VEP27043A	E.V.F. TALLEY LED C.B.A.	1 (NLA)	
		----- VIR SECTION -----		
	VEPO6612C	MAIN C.B.A.	1 (NLA)	
	VEPO3676C	LUMINANCE/CHROMINANCE C.B.A.	1 (NLA)	
	VEPO6613A	VIR OPERATION C.B.A.	1 (NLA)	
	VEPO4281B	VIR JACK C.B.A.	1 (NLA)	
	VEPOOH73B	FE HEAD C.B.A.	1 (NLA)	
	VEK4643	E.V.F. CONNECTOR C.B.A.	1 (NLA)	
	VEK4644	REMOTE CONTROL JACK C.B.A.	1 (NLA)	
	VEK4730	ZOOM SW, START/STOP SW, SUB START/STOP SW C.B.A.	1 (NLA)	
	VES0413	MECHANISM CONNECTION C.B.A.	1 (NLA)	
	VEK3414	TAKE-UP PHOTO C.B.A.	1 (NLA)	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
	VEK3415	SUPPLY PHOTO C.B.A.	1 (NLA)	
	■ VEP26055A	AWT C.B.A.	(NLA)	
		CAPACITORS		
C601-03	ECUM1E1042FN	C.CAPACITOR CH 25V 0.1U	3	
		ICS		
IC601	M51096AU	IC	1	
IC602	AN1358S	IC	1	
		CONNECTOR		
P601	VJP1598T	CONNECTOR (MALE) 5P	1	
		RESISTORS		
R601	ERJ6GEYF123	M.RESISTOR CH 1/10W 12K	1	
R602	ERJ6GEYF822	M.RESISTOR CH 1/10W 8.2K	1	
R603	ERJ6GEYF124	M.RESISTOR CH 1/10W 120K	1	
R604	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	1	
R605	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R606,07	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	2	
R608	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R609	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	1	
R610	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
	■ VEP22085A	CCD DRIVE C.B.A.	(NLA)	
B201	VJP1948	CONNECTOR (MALE)	1	
		CAPACITORS		
C201	ECSF1AE106	T.CAPACITOR 10V 10U	1	
C202,03	ECUM1H150JCV	C.CAPACITOR CH 50V 15P	2	
C204	ECUM1H390JCV	C.CAPACITOR CH 50V 39P	1	
C206	ECRJAO10A12X	.CAPACITOR V	1	
C207	ECSF1AE106	T.CAPACITOR 10V 10U	1	
C208	ECEVOJA220	E.CAPACITOR 6.3V 22U	1	
C209	ECSF1CE106	T.CAPACITOR 16V 10U	1	
C210	ECEV1HA010	E.CAPACITOR 50V 1U	1	
C211	ECUM1E1042FN	C.CAPACITOR CH 25V 0.1U	1	
C212	ECEA1EKS100I	E.CAPACITOR 25V 10U	1	
C213	ECUM1E4732FN	C.CAPACITOR CH 25V 0.047U	1	
C214	ECEA1HKS010	E.CAPACITOR 50V 1U	1	
C215,16	ECUM1H270JCV	C.CAPACITOR CH 50V 27P	2	
C218,19	ECUM1H270JCV	C.CAPACITOR CH 50V 27P	2	
C220	ECSF1CE106	T.CAPACITOR 16V 10U	1	
C221,22	ECUM1H270JCV	C.CAPACITOR CH 50V 27P	2	
C223	ECUM1H6822FV	C.CAPACITOR CH 50V 6800P	1	
C225	ECUM1E1042FN	C.CAPACITOR CH 25V 0.1U	1	
C226	ECEA1EKS100I	E.CAPACITOR 25V 10U	1	
C229	ECEAOJKS470	E.CAPACITOR 6.3V 47U	1	
C230-33	ECUM1E1042FN	C.CAPACITOR CH 25V 0.1U	4	
C236	ECUM1H150JCV	C.CAPACITOR CH 50V 15P	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C344	ECUM1H102KBV	C.CAPACITOR CH 50V 1000P	1		IC308,09	LM2904M	IC	2	
C345	ECEVI CAN4R7R	E.CAPACITOR 16V 4.7U	1		IC310	AN2254FAP	IC	1	
C346	ECST1AB4752R	T.CAPACITOR 35V 4.7U	1		IC311	MN73512XWA	IC	1	
C348	ECEA1CK5100	E.CAPACITOR 16V 10U	1		IC312	VCR0250	IC	1	
C349	ECUM1H221JCV	C.CAPACITOR CH 50V 220P	1		IC501	R24052BM	IC	1	
C350	ECEA1CKG100	E.CAPACITOR 16V 10U	1		IC502	LM2902M	IC	1	
C351	ECUM1E1042FN	C.CAPACITOR CH 25V 0.1U	1		IC503	LM2904M	IC	1	
C353	ECUM1H330JCV	C.CAPACITOR CH 50V 33P	1		IC504,05	LM2902M	IC	2	
C354	ECUM1C2242FN	C.CAPACITOR CH 16V 0.22U	1		IC506	RC4558M	IC	1	
C355,56	ECUM1H1032FV	C.CAPACITOR CH 50V 0.01U	2						
C357	ECEA1HKG010	E.CAPACITOR 50V 1U	1						
C358	ECSF1AE225	T.CAPACITOR 10V 22U	1						
C360	ECUM1E1042FN	C.CAPACITOR CH 25V 0.1U	1		L301	VLQ0163K150	COIL 15UH	1	
C361	ECEA1CK5330	E.CAPACITOR 16V 33U	1		L302	VLQ0319F150	COIL 15UH	1	
C362	ECUM1H270JCV	C.CAPACITOR CH 50V 27P	1		L303	VLQ0163K101	COIL 100UH	1	
C363,64	ECUM1E1042FN	C.CAPACITOR CH 25V 0.1U	2		L304-06	VLQ0163K150	COIL 15UH	3	
C365	ECSF0JE336	T.CAPACITOR 6.3V 33U	1		L307	VLQ0163K330	COIL 33UH	1	
C366	ECUM1H1032FV	C.CAPACITOR CH 50V 0.01U	1		L308,09	VLQ0163K150	COIL 15UH	2	
C368	ECUM1H271JCV	C.CAPACITOR CH 50V 270P	1		L310	VLQ0291	COIL	1	
C369	ECSF1AE106	T.CAPACITOR 10V 10U	1		L311	VLQ0163K150	COIL 15UH	1	
C371	ECST1CY1052	T.CAPACITOR 16V 1U	1		L312	VLQ0163K101	COIL 100UH	1	
C372	ECEVOJA470	E.CAPACITOR 6.3V 47U	1		L313	VLQ0163K330	COIL 33UH	1	
C373	ECEA1CK5100	E.CAPACITOR 16V 10U	1		L316	VLQ0163K330	COIL 33UH	1	
C374-76	ECUM1E1042FN	C.CAPACITOR CH 25V 0.1U	3						
C377	ECUM1H1032FV	C.CAPACITOR CH 50V 0.01U	1						
C378	ECUM1H220JCV	C.CAPACITOR CH 50V 22P	1				CONNECTORS		
C380	ECUM1H330JCV	C.CAPACITOR CH 50V 33P	1		P302	VJP1609T	CONNECTOR (MALE)	1	
C382	ECUM1H220JCV	C.CAPACITOR CH 50V 22P	1		P309	VJP2261	CONNECTOR (MALE)	1	
C384	ECEA1EKS4R7I	E.CAPACITOR 25V 4.7U	1						
C385	ECEA1CK5100	E.CAPACITOR 16V 10U	1						
C386	ECEVI CA100	E.CAPACITOR 16V 10U	1				TRANSISTORS		
C387-89	ECUM1H560JCV	C.CAPACITOR CH 50V 56P	3		Q301	2SD1819	TRANSISTOR	1	
C393	ECUM1H820JCV	C.CAPACITOR CH 50V 82P	1		Q302	2SC3931	TRANSISTOR	1	
C395,96	ECUM1C1052FM	C.CAPACITOR CH 16V 1U	2		Q303	2SB1218	TRANSISTOR	1	
C398-00	ECUM1H1032FV	C.CAPACITOR CH 50V 0.01U	3		Q304	2SA1532	TRANSISTOR	1	
C401,02	ECUM1H151JCV	C.CAPACITOR CH 50V 150P	2		Q305	XN4601	TRANSISTOR-RESISTOR	1	
C416	ECEPOGK5221	E.CAPACITOR 4V 220U	1		Q306	XN4401	TRANSISTOR-RESISTOR	1	
C501	ECEVI AAN100	E.CAPACITOR 10V 10U	1		Q308	XN4601	TRANSISTOR-RESISTOR	1	
C502,03	ECUM1E1042FN	C.CAPACITOR CH 25V 0.1U	2		Q310	2SB1218	TRANSISTOR	1	
C504	ECEVI AAN100	E.CAPACITOR 10V 10U	1		Q312	2SD1819	TRANSISTOR	1	
C505,06	ECUM1E4732FN	C.CAPACITOR CH 25V 0.047U	2		Q313	2SC3931	TRANSISTOR	1	
C508	ECUM1E1042FN	C.CAPACITOR CH 25V 0.1U	1		Q314	2SD1819	TRANSISTOR	1	
					Q315	XN4401	TRANSISTOR-RESISTOR	1	
		DIODES			Q317	2SD1819	TRANSISTOR	1	
D301	MA141A	DIODE	1		Q320	XN4401	TRANSISTOR-RESISTOR	1	
D305	MA141A	DIODE	1		Q322	XN4608	TRANSISTOR-RESISTOR	1	
D306	MA141WK	DIODE	1		Q324	2SA1532	TRANSISTOR	1	
D307	MA728	DIODE	1		Q328	XN4501	TRANSISTOR-RESISTOR	1	
D308	MA3047M	DIODE	1		Q505	XN4501	TRANSISTOR-RESISTOR	1	
D309,10	MA110	DIODE	2		Q508-10	XN4601	TRANSISTOR-RESISTOR	3	
D501	MA141WA	DIODE	1						
D502	MA728	DIODE	1						
D503	MA141A	DIODE	1				RESISTORS		
					R301	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
					R302	ERJ3GEYJ271	M.RESISTOR CH 3W 270	1	
		FILTERS			R303	ERJ3GEYJ391	M.RESISTOR CH 3W 390	1	
FL301	ELB4D009	FILTER	1		R304	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
FL302	VLFO664	FILTER	1		R305	ERJ3GEYJ471	M.RESISTOR CH 3W 470	1	
FL303	ELB4B003	FILTER	1		R306	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	1	
FL304	ELB4C011	FILTER	1		R307	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
FL305	VLFO798	FILTER	1		R308	ERJ3GEYJ182	M.RESISTOR CH 3W 1.8K	1	
FL307	ELB4D010	FILTER	1		R309	ERJ3GEYJ561	M.RESISTOR CH 3W 560	1	
FL308	ELB4B030	FILTER	1		R310	ERJ3GEYJ101	M.RESISTOR CH 3W 100	1	
					R311,12	ERJ3GEYJ332	M.RESISTOR CH 3W 3.3K	2	
					R313	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	1	
		CONNECTORS			R314	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
FP306	VJS2137	CONNECTOR	1		R315	ERJ3GEYJ182	M.RESISTOR CH 3W 1.8K	1	
FP310	VJS2113	CONNECTOR (FEMALE)	1		R317	ERJ3GEYJ561	M.RESISTOR CH 3W 560	1	
					R318	ERJ3GEYJ392	M.RESISTOR CH 3W 3.9K	1	
					R319	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
		ICS			R321	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	1	
IC302	MN3819S	IC	1		R322	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
IC303	MN3820S	IC	1		R323	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	1	
IC304	AN2154FAP	IC	1		R324	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R325,26	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	2	
R327	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R328	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	1	
R329	ERJ3GEYJ183	M.RESISTOR CH 3W 18K	1	
R330	ERJ3GEYJ332	M.RESISTOR CH 3W 3.3K	1	
R331	ERJ3GEYJ562	M.RESISTOR CH 3W 5.6K	1	
R332	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	1	
R333	ERJ3GEYJ822	M.RESISTOR CH 3W 8.2K	1	
R334	ERJ3GEYJ821	M.RESISTOR CH 3W 820	1	
R336	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	1	
R337	ERJ3GEYJ154	M.RESISTOR CH 3W 150K	1	
R338	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R339	ERJ3GEYJ393	M.RESISTOR CH 3W 39K	1	
R340	ERJ3GEYJ183	M.RESISTOR CH 3W 18K	1	
R341	ERJ3GEYJ153	M.RESISTOR CH 3W 15K	1	
R342	ERJ3GEYJ473	M.RESISTOR CH 3W 47K	1	
R343	ERJ3GEYJ273	M.RESISTOR CH 3W 27K	1	
R344	ERJ3GEYJ183	M.RESISTOR CH 3W 18K	1	
R345	ERJ3GEYJ333	M.RESISTOR CH 3W 33K	1	
R348	ERJ3GEYJ473	M.RESISTOR CH 3W 47K	1	
R349	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R350	ERJ3GEYJ562	M.RESISTOR CH 3W 5.6K	1	
R351	ERJ3GEYJ560	M.RESISTOR CH 3W 56	1	
R352	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	1	
R353	ERJ3GEYJ223	M.RESISTOR CH 3W 22K	1	
R354	ERJ3GEYJ273	M.RESISTOR CH 3W 27K	1	
R355	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R357	ERJ3GEYJ273	M.RESISTOR CH 3W 27K	1	
R358	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R359	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	1	
R360	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	1	
R361,62	ERJ3GEYJ333	M.RESISTOR CH 3W 33K	2	
R363	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	1	
R364	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	1	
R365	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R366	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R367	ERJ3GEYJ561	M.RESISTOR CH 3W 560	1	
R368	ERJ3GEYJ331	M.RESISTOR CH 3W 330	1	
R369-71	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	3	
R374,75	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	2	
R376	ERJ3GEYJ473	M.RESISTOR CH 3W 47K	1	
R377	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R378	ERJ3GEYJ392	M.RESISTOR CH 3W 3.9K	1	
R379	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R380	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	1	
R381	ERJ3GEYJ152	M.RESISTOR CH 3W 1.5K	1	
R382	ERJ3GEYJ273	M.RESISTOR CH 3W 27K	1	
R383	ERJ3GEYJ683	M.RESISTOR CH 3W 68K	1	
R385	ERJ3GEYJ823	M.RESISTOR CH 3W 82K	1	
R386	ERJ3GEYJ183	M.RESISTOR CH 3W 18K	1	
R387	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R388	ERJ3GEYJ182	M.RESISTOR CH 3W 1.8K	1	
R389	ERJ3GEYJ105	M.RESISTOR CH 3W 1M	1	
R390	ERJ3GEYJ123	M.RESISTOR CH 3W 12K	1	
R394	ERJ3GEYJ154	M.RESISTOR CH 3W 150K	1	
R396	ERJ3GEYJ154	M.RESISTOR CH 3W 150K	1	
R397	ERJ3GEYJ101	M.RESISTOR CH 3W 100	1	
R398	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	1	
R399	ERJ3GEYJ563	M.RESISTOR CH 3W 56K	1	
R400	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	1	
R401	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R402,03	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	2	
R404	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	1	
R405	ERJ3GEYJ822	M.RESISTOR CH 3W 8.2K	1	
R406	ERJ3GEYJ681	M.RESISTOR CH 3W 680	1	
R408	ERJ3GEYJ681	M.RESISTOR CH 3W 680	1	
R409	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R410	ERJ3GEYJ392	M.RESISTOR CH 3W 3.9K	1	
R411	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R412	ERJ3GEYJ182	M.RESISTOR CH 3W 1.8K	1	
R413	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	1	
R414	ERJ3GEYJ391	M.RESISTOR CH 3W 390	1	
R415	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R416	ERJ3GEYJ562	M.RESISTOR CH 3W 5.6K	1	
R417	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R418	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R419	ERJ3GEYJ152	M.RESISTOR CH 3W 1.5K	1	
R426	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R427	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	1	
R428	ERJ3GEYOR00	M.RESISTOR CH 3W 0.00	1	
R429	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	1	
R431	ERJ3GEYJ223	M.RESISTOR CH 3W 22K	1	
R432	ERJ3GEYJ563	M.RESISTOR CH 3W 56K	1	
R433	ERJ3GEYJ333	M.RESISTOR CH 3W 33K	1	
R434	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R435	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R436	ERJ3GEYJ392	M.RESISTOR CH 3W 3.9K	1	
R437,38	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	2	
R439	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	1	
R440	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R442	ERJ3GEYJ473	M.RESISTOR CH 3W 47K	1	
R443,44	ERJ3GEYJ182	M.RESISTOR CH 3W 1.8K	2	
R445-47	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	3	
R448	ERJ3GEYJ332	M.RESISTOR CH 3W 3.3K	1	
R449	ERJ3GEYJ392	M.RESISTOR CH 3W 3.9K	1	
R450	ERJ3GEYJ123	M.RESISTOR CH 3W 12K	1	
R451	ERJ3GEYJ823	M.RESISTOR CH 3W 82K	1	
R452	ERJ3GEYJ123	M.RESISTOR CH 3W 12K	1	
R453	ERJ3GEYJ564	M.RESISTOR CH 3W 560K	1	
R456,57	ERJ3GEYJ153	M.RESISTOR CH 3W 15K	2	
R458	ERJ3GEYJ182	M.RESISTOR CH 3W 1.8K	1	
R459	ERJ3GEYJ392	M.RESISTOR CH 3W 3.9K	1	
R460	ERJ3GEYJ221	M.RESISTOR CH 3W 220	1	
R461	ERJ3GEYJ471	M.RESISTOR CH 3W 470	1	
R462	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R463	ERJ3GEYJ392	M.RESISTOR CH 3W 3.9K	1	
R465	ERJ3GEYJ681	M.RESISTOR CH 3W 680	1	
R468	ERJ3GEYJ154	M.RESISTOR CH 3W 150K	1	
R501,02	ERJ3GEYJ682	M.RESISTOR CH 3W 6.8K	2	
R503,04	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	2	
R505	ERJ3GEYJ334	M.RESISTOR CH 3W 330K	1	
R506,07	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	2	
R508	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	1	
R509	ERJ3GEYJ224	M.RESISTOR CH 3W 220K	1	
R510	ERJ3GEYJ154	M.RESISTOR CH 3W 150K	1	
R511	ERJ3GEYJ224	M.RESISTOR CH 3W 220K	1	
R512,13	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	2	
R514,15	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	2	
R516	ERJ3GEYJ334	M.RESISTOR CH 3W 330K	1	
R517	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R518	ERJ3GEYJ106	M.RESISTOR CH 3W 10M	1	
R519	ERJ3GEYJ563	M.RESISTOR CH 3W 56K	1	
R520	ERJ3GEYJ274	M.RESISTOR CH 3W 270K	1	
R521	ERJ3GEYJ334	M.RESISTOR CH 3W 330K	1	
R522	ERJ3GEYJ335	M.RESISTOR CH 3W 3.3M	1	
R523	ERJ3GEYJ563	M.RESISTOR CH 3W 56K	1	
R524	ERJ3GEYJ564	M.RESISTOR CH 3W 560K	1	
R525	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R526	ERJ3GEYJ106	M.RESISTOR CH 3W 10M	1	
R527	ERJ3GEYJ563	M.RESISTOR CH 3W 56K	1	
R528	ERJ3GEYJ274	M.RESISTOR CH 3W 270K	1	
R529	ERJ3GEYJ334	M.RESISTOR CH 3W 330K	1	
R530	ERJ3GEYJ335	M.RESISTOR CH 3W 3.3M	1	
R531	ERJ3GEYJ563	M.RESISTOR CH 3W 56K	1	
R532	ERJ3GEYJ564	M.RESISTOR CH 3W 560K	1	
R533	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	1	
R534-36	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	3	
R537	ERJ3GEYJ224	M.RESISTOR CH 3W 220K	1	
R538	ERJ3GEYJ154	M.RESISTOR CH 3W 150K	1	
R539	ERJ3GEYJ823	M.RESISTOR CH 3W 82K	1	
R540,41	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	2	
R542	ERJ3GEYJ224	M.RESISTOR CH 3W 220K	1	
R543	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R544-53	ERJ3GEYJ333	M.RESISTOR CH 3W 33K	10	
R554,55	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	2	
R562	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R569-71	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	3	
R572	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R574,75	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	2	
R576	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R579	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1		C740	ECEA1CKS100	E.CAPACITOR 16V 10U	1	
R580	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	1		C741	ECST1AC106Z	T.CAPACITOR 10V 10U	1	
R581	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	1		C742	ECUM1C1052FM	C.CAPACITOR CH 16V 1U	1	
R582	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	1		C743	ECUM1E1042FN	C.CAPACITOR CH 25V 0.1U	1	
R583	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1		C744,45	ECEAOJKS470	E.CAPACITOR 6.3V 47U	2	
R584	ERJ3GEYOR00	M.RESISTOR CH 3W 0.00	1		C746	ECUM1H1032FV	C.CAPACITOR CH 50V 0.01U	1	
R585	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1		C747	ECUM1E1042FN	C.CAPACITOR CH 25V 0.1U	1	
R586	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1		C748	ECEA1CU100	E.CAPACITOR 16V 10U	1	
R587,88	ERJ3GEYJ123	M.RESISTOR CH 3W 12K	2		C749,50	ECUM1E1042FN	C.CAPACITOR CH 25V 0.1U	2	
R589	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1		C751	ECEAOJKS470	E.CAPACITOR 6.3V 47U	1	
R590	ERJ3GEYJ183	M.RESISTOR CH 3W 18K	1						
R591	ERJ3GEYJ124	M.RESISTOR CH 3W 120K	1				DIODES		
R592,93	ERJ3GEYJ223	M.RESISTOR CH 3W 22K	2		D702	MA141A	DIODE	1	
R594	ERJ3GEYJ224	M.RESISTOR CH 3W 220K	1		D703,04	1SS250	DIODE	2	
		V.RESISTORS							
VR301	EVM7JSX30B14	V.RESISTOR 10K	1				FILTERS		
VR303	EVM7JSX30B24	V.RESISTOR 20K	1		FL701	ELB4B004	FILTER	1	
VR304	EVM7JSX30B54	V.RESISTOR 50K	1		FL702	VLF0595	FILTER	1	
VR305-07	EVM7JSX30B24	V.RESISTOR 20K	3		FL703	ELB4B005	FILTER	1	
VR309,10	EVM7JSX30B24	V.RESISTOR 20K	2		FL704	ELB4D001	FILTER	1	
VR311,12	EVM7JSX30B14	V.RESISTOR 10K	2		FL705	VLF0596	FILTER	1	
VR313-15	EVM7JSX30B13	V.RESISTOR 1K	3						
VR317-20	EVM7JSX30B53	V.RESISTOR 5K	4				CONNECTOR		
VR322	EVM7JSX30B54	V.RESISTOR 50K	1		FP701	VJS2112	CONNECTOR (FEMALE)	1	
VR324	EVM7JSX30B14	V.RESISTOR 10K	1						
VR327	EVM7JSX30B14	V.RESISTOR 10K	1						
VR328	EVM7JSX30B24	V.RESISTOR 20K	1						
VR329	EVM7JSX30B14	V.RESISTOR 10K	1				ICS		
VR523	EVM7JSX30B54	V.RESISTOR 50K	1		IC701	MN15867VFK	IC	1	
VR525,26	EVM7JSX30B24	V.RESISTOR 20K	2		IC702	AN2584NFAP	IC	1	
VR527	EVM7JSX30B54	V.RESISTOR 50K	1		IC704	AN6545SP	IC	1	
VR528,29	EVM7JSX30B14	V.RESISTOR 10K	2		IC705	NJM3415M	IC	1	
VR530,31	EVM7JSX30B54	V.RESISTOR 50K	2		IC706	AN6664S	IC	1	
VR532	EVM7JSX30B53	V.RESISTOR 5K	1						
VR533	EVM7JSX30B15	V.RESISTOR 100K	1				COILS		
					L701	VLQ0436	COIL	1	
					L702	VLQ0319K101	COIL 100UH	1	
					L703	VLQ0163K330	COIL 33UH	1	
					L704	VLQ0319F150	COIL 15UH	1	
							CONNECTORS		
	VEP27044B	AUTO FOCUS C.B.A.	(NLA)		P702	VJP1595R	CONNECTOR (MALE) 2P	1	
					P704	VJP1596T	CONNECTOR (MALE) 3P	1	
		CONNECTOR			P705	VJP1595T	CONNECTOR (MALE) 2P	1	
B701	VJP1948	CONNECTOR (MALE)	1		P706	VJP1608T	CONNECTOR (MALE)	1	
					P707	VJP1603T	CONNECTOR (MALE) 10P	1	
							TRANSISTORS		
		CAPACITORS			Q701	UN2211	TRANSISTOR-RESISTOR	1	
C701	ECEAOJU471	E.CAPACITOR 6.3V 470U	1		Q704	2SA1255	TRANSISTOR	1	
C702	ECUM1H180JCV	C.CAPACITOR CH 50V 18P	1		Q705	2SC3138	TRANSISTOR	1	
C703	ECRJAO30E12	V.CAPACITOR	1		Q706,07	2SD1819	TRANSISTOR	2	
C706	ECUM1H101JCV	C.CAPACITOR CH 50V 100P	1		Q708	2SD1483	TRANSISTOR	1	
C710,11	ECUM1E473KBM	C.CAPACITOR CH 25V 0.047U	2						
C712	ECEAOJKS101	E.CAPACITOR 6.3V 100U	1						
C713	ECUM1E1042FN	C.CAPACITOR CH 25V 0.1U	1				RESISTORS		
C714	ECEAOJKS101	E.CAPACITOR 6.3V 100U	1		R701	ERJ3GEYJ220	M.RESISTOR CH 3W 22	1	
C715	ECST1AE106	T.CAPACITOR 10V 10U	1		R702,03	ERJ3GEYJ563	M.RESISTOR CH 3W 56K	2	
C716-19	ECEA1CKS100	E.CAPACITOR 16V 10U	4		R704-06	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	3	
C720	ECEAOJSN220	E.CAPACITOR 6.3V 22U	1		R707,08	ERJ3GEYJ563	M.RESISTOR CH 3W 56K	2	
C721	ECUM1E4732FN	C.CAPACITOR CH 25V 0.047U	1		R709	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
C722-24	ECUM1E273KBN	C.CAPACITOR CH 25V 0.027U	3		R710-16	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	7	
C725	ECUM1E6832FN	C.CAPACITOR CH 25V 0.063U	1		R717	ERJ3GEYJ123	M.RESISTOR CH 3W 12K	1	
C726	ECUM1E1042FN	C.CAPACITOR CH 25V 0.1U	1		R718	ERJ3GEYJ154	M.RESISTOR CH 3W 150K	1	
C727-29	ECUM1C2242FN	C.CAPACITOR CH 16V 0.22U	3		R719	ERJ3GEYG473	M.RESISTOR CH 3W 47K	1	
C730	ECUM1H330JCV	C.CAPACITOR CH 50V 33P	1		R720	ERJ3GEYG563	M.RESISTOR CH 3W 56K	1	
C731	ECUM1E4732FN	C.CAPACITOR CH 25V 0.047U	1		R721,22	ERJ3GEYJ154	M.RESISTOR CH 3W 150K	2	
C732-35	ECUM1H1032FV	C.CAPACITOR CH 50V 0.01U	4		R723	ERJ3GEYG563	M.RESISTOR CH 3W 56K	1	
C736	ECUV1H331KBN	C.CAPACITOR CH 50V 330P	1		R724	ERJ3GEYG473	M.RESISTOR CH 3W 47K	1	
C737	ECRJAO20E12X	.CAPACITOR V	1						
C738,39	ECUM1C2242FN	C.CAPACITOR CH 16V 0.22U	2						

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R725	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R728	ERJ3GEYJ823	M.RESISTOR CH 3W 82K	1	
R729	ERJ3GEYJ394	M.RESISTOR CH 3W 390K	1	
R730	ERJ3GEYJ474	M.RESISTOR CH 3W 470K	1	
R731	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R732	ERJ3GEYJ822	M.RESISTOR CH 3W 8.2K	1	
R733	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	1	
R734-38	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	5	
R739	ERJ3GEYJ823	M.RESISTOR CH 3W 82K	1	
R742	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R743	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	1	
R744	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R745	ERJ3GEYJ100	M.RESISTOR CH 3W 10	1	
R746	ERJ3GEYJ273	M.RESISTOR CH 3W 27K	1	
R747	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	1	
R748,49	ERJ3GEYJ274	M.RESISTOR CH 3W 270K	2	
R750	ERJ3GEYJ561	M.RESISTOR CH 3W 560	1	
R752	ERJ3GEYJ273	M.RESISTOR CH 3W 27K	1	
R753	ERJ3GEYJ682	M.RESISTOR CH 3W 6.8K	1	
R754	ERJ3GEYJ564	M.RESISTOR CH 3W 560K	1	
R758	ERJ3GEYJ221	M.RESISTOR CH 3W 220	1	
R760,61	ERJ3GEYJ332	M.RESISTOR CH 3W 3.3K	2	
R762	ERJ3GEYJ221	M.RESISTOR CH 3W 220	1	
		TRANSFORMER		
T701	ETE13K43AY	TRANSFORMER	1	
		V.RESISTORS		
VR701	EVLHGVA12A54	V.RESISTOR 50K	1	
VR703	EVM7JSX30B14	V.RESISTOR 10K	1	
		CRYSTAL OSCILLATOR		
X701	VSOX299	CRYSTAL OSCILLATOR	1	
		VEPO6614A	CAMERA OPERATION C.B.A.	(NLA)
		CAPACITORS		
C6701,02	ECEA0JKS470	E.CAPACITOR 6.3V 47U	2	
		DIODES		
D6701	BR3668S	DIODE	1	
D6702-09	MA165	DIODE	8	
		CONNECTORS		
P6701	VJP1614T	CONNECTOR(MALE)	1	
P6702	VJP1606T	CONNECTOR(MALE)	1	
P6703	VJP1612T	CONNECTOR(MALE)	1	
P6704	VJP1607T	CONNECTOR(MALE)	1	
		TRANSISTORS		
Q6701	2SD636	TRANSISTOR	1 (Q.R.S)	
Q6702	2SB641	TRANSISTOR	1 (Q.R.S)	
Q6703	2SD636	TRANSISTOR	1 (Q.R.S)	
		RESISTORS		
R6703	ERDS2TJ183	C.RESISTOR 1/4W 18K	1	
R6704	ERDS2TJ124	C.RESISTOR 1/4W 120K	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R6705	ERDS2TJ154	C.RESISTOR 1/4W 150K	1	
R6708	ERDS2TJ102	C.RESISTOR 1/4W 1K	1	
R6731	ERDS2TJ102	C.RESISTOR 1/4W 1K	1	
R6732	ERDS2TJ394	C.RESISTOR 1/4W 390K	1	
R6733	ERDS2TJ153	C.RESISTOR 1/4W 15K	1	
R6734	ERDS2TJ333	C.RESISTOR 1/4W 33K	1	
R6735	ERDS2TJ223	C.RESISTOR 1/4W 22K	1	
R6736	ERDS2TJ153	C.RESISTOR 1/4W 15K	1	
R6737	ERDS2TJ393	C.RESISTOR 1/4W 39K	1	
		SWITCHES		
SW6701-09	EVQSU04W	SWITCH	9	
SW6710	VSS0170	SWITCH	1	
SW6711	VSS0126	SWITCH	1	
		VEPOOP37A	AF & ZOOM POSITION C.B.A.	(NLA)
	ERDS2TJ181T	RESISTOR	1	
	ON2170	PHOTO CUPLER	2	
		MISCELLANEOUS		
	VJFO771	HOLDER	1	
		VEP27033G	E.V.F. C.B.A.	(NLA)
		CAPACITORS		
C701	ECEA0JKS101	E.CAPACITOR 6.3V 100U	1	
C702	ECE1CY684V	T.CAPACITOR 16V 0.68U	1	
C703	ECEA1CKS100	E.CAPACITOR 16V 10U	1	
C704	ECEA0JKS470	E.CAPACITOR 6.3V 47U	1	
C705	ECEA1CKE101	E.CAPACITOR 16V 100U	1	
C706	ECUM1H681JCN	C.CAPACITOR CH 50V 680P	1	
C707	ECUM1C224ZFN	C.CAPACITOR CH 16V 0.22U	1	
C708	ECUM1E223KEN	C.CAPACITOR CH 25V 0.023U	1	
C709	ECEA1CKS100	E.CAPACITOR 16V 10U	1	
C710	ECUM1H152JN	C.CAPACITOR CH 50V 1500P	1	
C711	ECEA1CKS100	E.CAPACITOR 16V 10U	1	
C712	ECEA1AF470	E.CAPACITOR 10V 47U	1	
C713	ECEA0JK221	E.CAPACITOR 6.3V 220U	1	
C714	EOQK1392J2	P.CAPACITOR 100V 3900P	1	
C715	ECEA1CKS220	E.CAPACITOR 16V 22U	1	
C716	ECUM1H181KN	C.CAPACITOR CH 50V 180P	1	
C717	ECEA1HGS4R7	E.CAPACITOR 50V 4.7U	1	
C718	VCK0075K121	C.CAPACITOR 120P	1	
C719	VCK0058K331	C.CAPACITOR 330P	1	
C720,21	ECUM1H473ZFN	C.CAPACITOR CH 50V 0.047U	2	
C722	ECUM1H104ZFN	C.CAPACITOR CH 50V 0.1U	1	
		DIODES		
D701	MA151K	DIODE	1	
D702	ERA91-02	DIODE	1	
D703	ERA34-10	DIODE	1	
		ICS		
IC701	AN2510S	IC	1	
		COILS		
L701	ELCO4D007	COIL	1	
L702	ELH5L328	COIL	1	
		CONNECTORS		

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C2006	ECUM1C4732FV	C. CAPACITOR CH 16V 0.047U	1	
C2007	ECUM1H4722FV	C. CAPACITOR CH 50V 4700P	1	
C2009, 10	ECEA1CKA220	E. CAPACITOR 16V 22U	2	
C2011	ECUM1C4732FV	C. CAPACITOR CH 16V 0.047U	1	
C2012	ECUM1H222KVB	C. CAPACITOR CH 50V 2200P	1	
C2013	ECUM1H102KVB	C. CAPACITOR CH 50V 1000P	1	
C2014	ECEA1VKN2R2	E. CAPACITOR 35V 2.2U	1	
C2015, 16	ECUM1C1052FM	C. CAPACITOR CH 16V 1U	2	
C2017, 18	ECUM1H102KVB	C. CAPACITOR CH 50V 1000P	2	
C2019	ECEA0JKA470	E. CAPACITOR 6.3V 47U	1	
C2020	ECUM1H471KVB	C. CAPACITOR CH 50V 470P	1	
C2021, 22	ECUM1C1052FM	C. CAPACITOR CH 16V 1U	2	
C2023	ECUX1E3332FN	C. CAPACITOR CH 25V 0.033U	1	
C2024	ECEA1CKA220	E. CAPACITOR 16V 22U	1	
C2025, 26	ECEA0JKA470	E. CAPACITOR 6.3V 47U	2	
C2027	ECUM1H1032FV	C. CAPACITOR CH 50V 0.01U	1	
C2028	ECUM1C1052FM	C. CAPACITOR CH 16V 1U	1	
C2029	ECUM1H102KVB	C. CAPACITOR CH 50V 1000P	1	
C2030	ECUM1C1042FV	C. CAPACITOR CH 16V 0.1U	1	
C2032	ECUM1H1032FV	C. CAPACITOR CH 50V 0.01U	1	
C2033	ECUM1C1052FM	C. CAPACITOR CH 16V 1U	1	
C2034	ECUM1H101JCV	C. CAPACITOR CH 50V 100P	1	
C2035	ECUM1H102KVB	C. CAPACITOR CH 50V 1000P	1	
C2036	ECUM1E1042FM	C. CAPACITOR CH 25V 0.1U	1	
C2037	ECEA0JKA470	E. CAPACITOR 6.3V 47U	1	
C2038	ECEA0JKA220	E. CAPACITOR 6.3V 22U	1	
C2039	ECEA0JKA101	E. CAPACITOR 6.3V 100U	1	
C2040	ECUM1H1032FV	C. CAPACITOR CH 50V 0.01U	1	
C2041	ECUM1C1052FM	C. CAPACITOR CH 16V 1U	1	
C2042	ECEA0JKA470	E. CAPACITOR 6.3V 47U	1	
C2043	ECEA1CGK100	E. CAPACITOR 16V 10U	1	
C2044	ECUM1C1842FN	C. CAPACITOR CH 16V 0.18U	1	
C2045	ECQV1H393JZ	P. CAPACITOR 50V 0.039U	1	
C2046-48	ECUM1H1032FV	C. CAPACITOR CH 50V 0.01U	3	
C2049	ECUM1C3332FV	C. CAPACITOR CH 16V 0.033U	1	
C2050	ECUM1C1042FV	C. CAPACITOR CH 16V 0.1U	1	
C2051, 52	ECEA0JKA470	E. CAPACITOR 6.3V 47U	2	
C2053	ECEA0JKA101	E. CAPACITOR 6.3V 100U	1	
C2054	ECUM1C3332FV	C. CAPACITOR CH 16V 0.033U	1	
C2055	ECEA0JKA470	E. CAPACITOR 6.3V 47U	1	
C2056-58	ECEA1EKN3R3	E. CAPACITOR 25V 3.3U	3	
C2059-61	ECUM1H4722FV	C. CAPACITOR CH 50V 4700P	3	
C2062-64	ECEA1CKA470L	E. CAPACITOR 16V 47U	3	
C2065-67	ECUM1C1042FV	C. CAPACITOR CH 16V 0.1U	3	
C2068	ECEA1HKKR47	E. CAPACITOR 50V 0.47U	1	
C2071	ECUM1C3332FV	C. CAPACITOR CH 16V 0.033U	1	
C2072, 73	ECUM1C472FM	C. CAPACITOR CH 16V 0.47U	2	
C2078	ECUM1C4732FV	C. CAPACITOR CH 16V 0.047U	1	
C2081	ECEA0JKA470	E. CAPACITOR 6.3V 47U	1	
C3801	ECEA1CKA101	E. CAPACITOR 16V 100U	1	
C3802, 03	ECUM1H1032FV	C. CAPACITOR CH 50V 0.01U	2	
C3805	ECUM1H1032FV	C. CAPACITOR CH 50V 0.01U	1	
C3807	ECUM1H103KBN	C. CAPACITOR CH 50V 0.01U	1	
C3840	ECUM1H331KVB	C. CAPACITOR CH 50V 330P	1	
C3841	ECEA0JKA221	E. CAPACITOR 6.3V 220U	1	
C3842-44	ECUM1H1032FV	C. CAPACITOR CH 50V 0.01U	3	
C3847	ECUM1H471KVB	C. CAPACITOR CH 50V 470P	1	
C4001	ECQP1222JZ	P. CAPACITOR 100V 2200P	1	
C4002	ECRHC120N11	. CAPACITOR V	1	
C4003	ECUM1H562KVB	C. CAPACITOR CH 50V 5600P	1	
C4004	ECUM1H472KVB	C. CAPACITOR CH 50V 4700P	1	
C4005	ECUM1H122KVB	C. CAPACITOR CH 50V 1200P	1	
C4007	ECSE1VE105GD	T. CAPACITOR 35V 1U	1	
C4008	ECUM1E333KBN	C. CAPACITOR CH 25V 0.033U	1	
C4009	ECEA1KA330	E. CAPACITOR 10V 33U	1	
C4011	ECUM1E822KVB	C. CAPACITOR CH 25V 8200P	1	
C4012	ECEA1CKA220	E. CAPACITOR 16V 22U	1	
C4013	ECEA1HSN010	E. CAPACITOR 50V 1U	1	
C4014	ECUM1H182KVB	C. CAPACITOR CH 50V 1800P	1	
C4015	ECEA0JKA470	E. CAPACITOR 6.3V 47U	1	
C4016	ECEA1CKA470L	E. CAPACITOR 16V 47U	1	
C4017	ECEA1CKA220	E. CAPACITOR 16V 22U	1	
C4018	ECEA1KA221	E. CAPACITOR 10V 220U	1	
C4019	ECEA1HKK010	E. CAPACITOR 50V 1U	1	
C4021	ECUM1E333KBN	C. CAPACITOR CH 25V 0.033U	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C4022	ECEA1HKK010	E. CAPACITOR 50V 1U	1	
C4024-26	ECEA1CKA220	E. CAPACITOR 16V 22U	3	
C4027	ECUX1H682KBN	C. CAPACITOR CH 50V 6800P	1	
C4038	ECEA1CKA470L	E. CAPACITOR 16V 47U	1	
C4040	ECUM1H151JV	C. CAPACITOR CH 50V 150P	1	
C4803	ECEA1KA330	E. CAPACITOR 10V 33U	1	
C4805	ECEA1AKN100	E. CAPACITOR 10V 10U	1	
C4807	ECEA0JKA101	E. CAPACITOR 6.3V 100U	1	
C4809	ECEA1EKG2R2	E. CAPACITOR 25V 2.2U	1	
C4813	ECEA1CKK100	E. CAPACITOR 16V 10U	1	
C4814	ECEA1CKA101	E. CAPACITOR 16V 100U	1	
C4815	ECUM1H102KVB	C. CAPACITOR CH 50V 1000P	1	
C4816	ECUM1H330JCV	C. CAPACITOR CH 50V 33P	1	
C4817	ECEA1KA220L	E. CAPACITOR 10V 22U	1	
C4818	ECEA1CKA101	E. CAPACITOR 16V 100U	1	
C4835	ECEA0JKA221	E. CAPACITOR 6.3V 220U	1	
C4837	ECEA1CKA220	E. CAPACITOR 16V 22U	1	
C4839	ECEA1CKA470L	E. CAPACITOR 16V 47U	1	
C4840	ECEA0JKA101	E. CAPACITOR 6.3V 100U	1	
C4841	ECEA1EKN3R3	E. CAPACITOR 25V 3.3U	1	
C4845	ECEA1EKK3R3	E. CAPACITOR 25V 3.3U	1	
C4850	ECUM1H560JCV	C. CAPACITOR CH 50V 56P	1	
C4852	ECEA1HKK010	E. CAPACITOR 50V 1U	1	
C4855	ECEA0JKA101	E. CAPACITOR 6.3V 100U	1	
C4856	ECEA1CKA101	E. CAPACITOR 16V 100U	1	
C4858	ECEA0JKA101	E. CAPACITOR 6.3V 100U	1	
C4859	ECEA1EKK3R3	E. CAPACITOR 25V 3.3U	1	
C4860	ECEA1CKA470L	E. CAPACITOR 16V 47U	1	
C4862	ECEA0JKA221	E. CAPACITOR 6.3V 220U	1	
C4864	ECUM1H151JV	C. CAPACITOR CH 50V 150P	1	
C5001	ECUM1E103KVB	C. CAPACITOR CH 25V 0.01U	1	
C5002	ECUM1H103KBN	C. CAPACITOR CH 50V 0.01U	1	
C5003	ECUM1E103KVB	C. CAPACITOR CH 25V 0.01U	1	
C5004	ECUM1H103KBN	C. CAPACITOR CH 50V 0.01U	1	
C5005	ECUM1C1042FV	C. CAPACITOR CH 16V 0.1U	1	
C5006	ECEA1CKA470L	E. CAPACITOR 16V 47U	1	
C5007	ECUM1E103KVB	C. CAPACITOR CH 25V 0.01U	1	
C5008	ECEA0JKS470	E. CAPACITOR 6.3V 47U	1	
C5009	ECUM1E103KVB	C. CAPACITOR CH 25V 0.01U	1	
C5010	ECUM1H1042FN	C. CAPACITOR CH 50V 0.1U	1	
C5011	ECUM1E103KVB	C. CAPACITOR CH 25V 0.01U	1	
C5013	ECUM1C1052FM	C. CAPACITOR CH 16V 1U	1	
C5014	ECUM1E103KVB	C. CAPACITOR CH 25V 0.01U	1	
C5015	ECUM1H101JCV	C. CAPACITOR CH 50V 100P	1	
C5016, 17	ECUM1E103KVB	C. CAPACITOR CH 25V 0.01U	2	
C5018	ECUM1H101JCV	C. CAPACITOR CH 50V 100P	1	
C5019	ECUM1E103KVB	C. CAPACITOR CH 25V 0.01U	1	
C5020	ECUM1C1052FM	C. CAPACITOR CH 16V 1U	1	
C5023	ECUM1C1052FM	C. CAPACITOR CH 16V 1U	1	
C5025	ECUM1E103KVB	C. CAPACITOR CH 25V 0.01U	1	
C5026, 27	ECUM1H101JCV	C. CAPACITOR CH 50V 100P	2	
C5028-30	ECUM1E103KVB	C. CAPACITOR CH 25V 0.01U	3	
C5031	ECUM1C1052FM	C. CAPACITOR CH 16V 1U	1	
C5033	ECEA0JKA470	E. CAPACITOR 6.3V 47U	1	
C5034-36	ECUM1E103KVB	C. CAPACITOR CH 25V 0.01U	3	
C5037	ECUM1C1042FV	C. CAPACITOR CH 16V 0.1U	1	
C5038	ECUM1H151JV	C. CAPACITOR CH 50V 150P	1	
C5039	ECUM1H121JCV	C. CAPACITOR CH 50V 120P	1	
C5040	ECUM1H390JCV	C. CAPACITOR CH 50V 39P	1	
C5041-44	ECUM1H4722FV	C. CAPACITOR CH 50V 4700P	4	
C6001	ECUM1C1042FV	C. CAPACITOR CH 16V 0.1U	1	
C6002	ECEA1CKA470L	E. CAPACITOR 16V 47U	1	
C6003	ECEA1EKA100	E. CAPACITOR 25V 10U	1	
C6004	ECEA1KA330	E. CAPACITOR 10V 33U	1	
C6005	ECUM1C1042FV	C. CAPACITOR CH 16V 0.1U	1	
C6006, 07	ECUM1H1032FV	C. CAPACITOR CH 50V 0.01U	2	
C6008	ECEA1CKA470L	E. CAPACITOR 16V 47U	1	
C6009	ECUM1C1042FV	C. CAPACITOR CH 16V 0.1U	1	
C6010	ECUM1H330JCV	C. CAPACITOR CH 50V 33P	1	
C6011	ECRJ1A030E12	V. CAPACITOR	1	
C6014	ECUM1C1042FV	C. CAPACITOR CH 16V 0.1U	1	
C6015	ECEA1CKA470L	E. CAPACITOR 16V 47U	1	
C6016-18	ECUM1C1042FV	C. CAPACITOR CH 16V 0.1U	3	
C6019	ECEA1EKA220	E. CAPACITOR 25V 22U	1	
C6020	ECUM1C1042FV	C. CAPACITOR CH 16V 0.1U	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C6021-23	ECUM1H1032FV	C.CAPACITOR CH 50V 0.01U	3		L1004	VLQ0128	COIL 47UH	1	
C6024	ECUM1H5622FV	C.CAPACITOR CH 50V 5600P	1		L1005	ELC08D050	COIL	1	
C6025	ECUM1H1042FN	C.CAPACITOR CH 50V 0.1U	1		L1006	VLQ0128	COIL 47UH	1	
C6026	ECUM1C1042FV	C.CAPACITOR CH 16V 0.1U	1		L1007	ELC08D025	COIL 600UH	1	
C6027	ECEA1EKA100	E.CAPACITOR 25V 10U	1		L1008	VLQ0129	COIL 300UH	1	
C6028	ECEA1HKK010	E.CAPACITOR 50V 1U	1		L1011,12	VLQEL05T221K	COIL 200UH	2	
C6029	ECUM1H331KBV	C.CAPACITOR CH 50V 330P	1		L1014	VLQEL05T101K	COIL H	1	
C6030	ECEA1EGE221	E.CAPACITOR 25V 220U	1		L3801	VLQEL05T101K	COIL H	1	
C6031	ECUM1H151JV	C.CAPACITOR CH 50V 150P	1		L4001	VLQEL05T221K	COIL 200UH	1	
					L4002	VLQEL07F822J	COIL 8200UH	1	
					L4003	VLQEL07R153J	COIL 15H	1	
		DIODES			L5001-03	VLQEL05T101K	COIL H	3	
D1001,02	MA141K	DIODE	2		L5004	VLQEL05T100K	COIL H	1	
D1003	MA159A	DIODE	1		L5005	VLQEL05F120T	COIL 12UH	1	
D1004	MA3075H	DIODE	1		L6001	VLQEL05T101K	COIL H	1	
D1005,06	MA141K	DIODE	2		L6002	VLQEL04F101K	COIL H	1	
D2001-03	MA143	DIODE	3		L6003	VLQ0163F390	COIL 39UH	1	
D2005	MA121	DIODE	1						
D2012,13	MA141K	DIODE	2						
D3801,02	MA141WK	DIODE	2				CONNECTORS		
D3803	MA3056	DIODE	1		P1001	VJP1231T	CONNECTOR (MALE) 4P	1	
D4801	MA141K	DIODE	1		P1003	VJP1229T	CONNECTOR (MALE) 2P	1	
D4802	MA141WK	DIODE	1		P2001	VJS2120	CONNECTOR	1	
D4803,04	MA143	DIODE	2		P2002	VJP1923T	CONNECTOR	1	
D4805	MA141K	DIODE	1		P3801	VJP2237	CONNECTOR (MALE)	1	
D4806	MA141WA	DIODE	1		P3802	VJS2119	CONNECTOR	1	
D4807	MA143	DIODE	1		P3803	VJP1598T	CONNECTOR (MALE) 5P	1	
D4808	MA141WA	DIODE	1		P3804	VJP1603T	CONNECTOR (MALE) 10P	1	
D6001	MA141WA	DIODE	1		P3805	VJP1595T	CONNECTOR (MALE) 2P	1	
D6002	MA141K	DIODE	1		P4001	VJP1597T	CONNECTOR (MALE) 4P	1	
D6003	MA141WA	DIODE	1		P4002	VJP1600T	CONNECTOR (MALE) 7P	1	
D6004	MA141WK	DIODE	1		P4004	VJP1595T	CONNECTOR (MALE) 2P	1	
D6005	MA141WA	DIODE	1		P4801	VJP1602T	CONNECTOR	1	
D6009	MA141WA	DIODE	1		P5001	VJS2117	CONNECTOR	1	
D6010,11	MA141K	DIODE	2		P6002	VJP1603T	CONNECTOR (MALE) 10P	1	
D6012	MA141WK	DIODE	1		P6003	VJS2107	CONNECTOR	1	
D6015	MA141WA	DIODE	1		P6004	VJP1229T	CONNECTOR (MALE) 2P	1	
D6017	MA143	DIODE	1		P6005	VJP1595T	CONNECTOR (MALE) 2P	1	
D6018	MA141WK	DIODE	1		P6006	VJP1596T	CONNECTOR (MALE) 3P	1	
D6019	MA141K	DIODE	1		P6007	VJP1602T	CONNECTOR	1	
D6021-25	MA141K	DIODE	5		P6010	VJP1596T	CONNECTOR (MALE) 3P	1	
D6026	MA3056	DIODE	1		P6011	VJP2523	CONNECTOR (MALE)	1	
D6029	MA141K	DIODE	1		P6012	VJP1229T	CONNECTOR (MALE) 2P	1	
					P6013	VJP1595R	CONNECTOR (MALE) 2P	1	
					P6014	VJP1600T	CONNECTOR (MALE) 7P	1	
					P6016	VJP1595T	CONNECTOR (MALE) 2P	1	
		ICS							
IC1001	BA6149LS	IC	1				TRANSISTORS		
IC1002	UN102	TRANSISTOR-RESISTOR	1		Q1001	2SB1218	TRANSISTOR	1	
IC1003	AN6562S	IC	1		Q1002	2SB956	TRANSISTOR	1	
IC1004	AN6914S	IC	1		Q1003	2SD1526	TRANSISTOR	1	
IC1005	AN1358S	IC	1		Q1004	2SD1119	TRANSISTOR	1	
IC2001	MN67461VDJF	IC	1		Q1005	2SD602	TRANSISTOR CHIP	1 (Q,R,S)	
IC2002	AN3798NS	IC	1		Q1006	2SB970X	TRANSISTOR	1	
IC2005	AN3841SR	IC	1		Q1007	2SD1328X	TRANSISTOR	1	
IC2006	TA8402F	IC	1		Q1008	2SD602	TRANSISTOR CHIP	1 (Q,R,S)	
IC4001	UPC1513G	IC	1		Q1011	2SB1218	TRANSISTOR	1	
IC4002	UPC2300G	IC	1		Q2001-03	2SB956	TRANSISTOR	3	
IC4801	BA3308	IC	1		Q3801,02	2SB970X	TRANSISTOR	2	
IC4804	MN4053BS	IC	1		Q3803,04	FMS1	TRANSISTOR-RESISTOR	2	
IC4805	NJM3415M	IC	1		Q3805	2SC3938	TRANSISTOR	1	
IC5001	AN3346FBP	IC	1		Q3806	2SD1819	TRANSISTOR	1	
IC6001	UPD4094BG	IC	1		Q3808	2SB1218	TRANSISTOR	1	
IC6002	MS0963MS2AC	IC	1		Q4001	2SD1820	TRANSISTOR	1	
IC6003	S3500A2	IC	1		Q4005	2SB970X	TRANSISTOR	1	
IC6004	UPD6145G617A	IC	1		Q4802	2SA1531	TRANSISTOR	1	
IC6005	MS4543AL	IC	1		Q4804,05	2SD1819	TRANSISTOR	2	
IC6006	UPD4094BG	IC	1		Q4808	2SD1328	TRANSISTOR CHIP	1	
IC6007	MN12821Q	IC	1		Q4810	2SD1328X	TRANSISTOR	1	
IC6008	UPD4094BG	IC	1		Q5001	2SB1218	TRANSISTOR	1	
					Q5002	2SA812	TRANSISTOR	1	
					Q5003	2SA1175	TRANSISTOR	1	
		COILS			Q5004,05	XN4504	TRANSISTOR-RESISTOR	2	
L1001	VLQ0128	COIL 47UH	1		Q6001	2SB1218	TRANSISTOR	1	
L1002	ELC08D038	COIL 180UH	1						
L1003	ELC06D005	COIL	1						

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
Q6002	2SB970X	TRANSISTOR	1	
Q6003	2SD1819	TRANSISTOR	1	
Q6004, 05	2SD1820	TRANSISTOR	2	
Q6006	2SD1819	TRANSISTOR	1	
Q6007	FMW1	TRANSISTOR-RESISTOR	1	
		COMBINATION PARTS		
QR1001	FMG2	TRANSISTOR-RESISTOR	1	
QR1002	GA114M	TRANSISTOR-RESISTOR	1	
QR2005	GN1F4Z	TRANSISTOR-RESISTOR	1	
QR3801	GN1F4M	TRANSISTOR-RESISTOR	1	
QR3802	GA1F4Z	TRANSISTOR-RESISTOR	1	
QR3803	GN1F4M	TRANSISTOR-RESISTOR	1	
QR3804	GA1F4Z	TRANSISTOR-RESISTOR	1	
QR3805	FMG1	TRANSISTOR-RESISTOR	1	
QR3806	GA114M	TRANSISTOR-RESISTOR	1	
QR3807	GA1F4M	TRANSISTOR-RESISTOR	1	
QR3808	FMS1	TRANSISTOR-RESISTOR	1	
QR3809	GA1F4M	TRANSISTOR-RESISTOR	1	
QR4002	GA1F4M	TRANSISTOR-RESISTOR	1	
QR4003, 04	GN113Z	TRANSISTOR-RESISTOR	2	
QR4803, 04	GA114M	TRANSISTOR-RESISTOR	2	
QR4805	GN114M	TRANSISTOR-RESISTOR	1	
QR4806	GN114Z	TRANSISTOR-RESISTOR	1	
QR4807	GN114M	TRANSISTOR-RESISTOR	1	
QR4808	GA114M	TRANSISTOR-RESISTOR	1	
QR5001	GA1A4Z	TRANSISTOR-RESISTOR	1	
QR5002, 03	FMG1	TRANSISTOR-RESISTOR	2	
QR6001	IMD2	TRANSISTOR-RESISTOR	1	
QR6002	GA1F4M	TRANSISTOR-RESISTOR	1	
QR6003	XN1217	TRANSISTOR-RESISTOR	1	
QR6004	GA114M	TRANSISTOR-RESISTOR	1	
QR6005	GA1F4Z	TRANSISTOR-RESISTOR	1	
QR6006	XN1217	TRANSISTOR-RESISTOR	1	
QR6009	GA1F4Z	TRANSISTOR-RESISTOR	1	
QR6010	GA114L	TRANSISTOR-RESISTOR	1	
QR6011	XN1217	TRANSISTOR-RESISTOR	1	
QR6014	XN1217	TRANSISTOR-RESISTOR	1	
QR6017	GN1A4M	TRANSISTOR-RESISTOR	1	
QR6019	FMA1	TRANSISTOR-RESISTOR	1	
QR6020	FMG2	TRANSISTOR-RESISTOR	1	
QR6022	GN114M	TRANSISTOR-RESISTOR	1	
QR6027	GA114M	TRANSISTOR-RESISTOR	1	
QR6029, 30	GA114M	TRANSISTOR-RESISTOR	2	
QR6031-33	FMA2	TRANSISTOR-RESISTOR	3	
QR6034	GN114M	TRANSISTOR-RESISTOR	1	
QR6035	UN4213	TRANSISTOR-RESISTOR	1	
		RESISTORS		
R1001	ERJ3GEYJ563	M.RESISTOR CH 3W 56K	1	
R1002	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	1	
R1003	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R1004	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	1	
R1005	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R1006	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	1	
R1007	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R1008	ERJ3GEYJ334	M.RESISTOR CH 3W 330K	1	
R1009	ERJ3GEYJ154	M.RESISTOR CH 3W 150K	1	
R1010	ERJ3GEYJ562	M.RESISTOR CH 3W 5.6K	1	
R1011	ERJ3GEYJ512	M.RESISTOR CH 3W 5.1K	1	
R1012, 13	ERJ8GCYJ122	M.RESISTOR CH 1/8W 1.2K	2	
R1014, 15	ERJ8GCYJ102	M.RESISTOR CH 1/8W 1K	2	
R1016, 17	ERJ3GEYJ512	M.RESISTOR CH 3W 5.1K	2	
R1018	ERJ8GCYJ122	M.RESISTOR CH 1/8W 1.2K	1	
R1019	ERJ8GCYJ821	M.RESISTOR CH 1/8W 820	1	
R1020, 21	ERJ3GEYJ183	M.RESISTOR CH 3W 18K	2	
R1022, 23	ERJ3GEYJ681	M.RESISTOR CH 3W 680	2	
R1024	ERJ3GEYJ153	M.RESISTOR CH 3W 15K	1	
R1025	ERJ3GEYJ562	M.RESISTOR CH 3W 5.6K	1	
R1026-31	ERJ3GEYJ391	M.RESISTOR CH 3W 390	6	
R1032	ERJ3GEYJ821	M.RESISTOR CH 3W 820	1	
R1033	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R1034	ERJ3GEYJ562	M.RESISTOR CH 3W 5.6K	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R1035	ERJ3GEYJ105	M.RESISTOR CH 3W 1M	1	
R1036	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	1	
R1037	ERJ3GEYJ272	M.RESISTOR CH 3W 2.7K	1	
R1038	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	1	
R1039	ERJ3GEYJ272	M.RESISTOR CH 3W 2.7K	1	
R1041	ERJ3GEYJ330	M.RESISTOR CH 3W 33	1	
R1042	ERJ3GEYJ683	M.RESISTOR CH 3W 68K	1	
R1043	ERJ3GEYJ123	M.RESISTOR CH 3W 12K	1	
R1044	ERJ8GCYJ560	M.RESISTOR CH 1/8W 56	1	
R1045	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	1	
R1046	ERJ3GEYJ684	M.RESISTOR CH 3W 680K	1	
R1047	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	1	
R1048	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R1049, 50	ERDS2TJ332T	.RESISTOR CH 2W 3.3K	2	
R1051	ERJ3GEYJ681	M.RESISTOR CH 3W 680	1	
R1052-54	ERJ3GEYJ105	M.RESISTOR CH 3W 1M	3	
R1055	ERJ3GEYJ474	M.RESISTOR CH 3W 470K	1	
R1056	ERJ3GEYJ105	M.RESISTOR CH 3W 1M	1	
R1057	ERJ3GEYJ184	M.RESISTOR CH 3W 180K	1	
R1058	ERJ3GEYJ681	M.RESISTOR CH 3W 680	1	
R1071	VSF0059	FUSE	1	
R1072-75	VSF0015A10	FUSE	4	
R1076	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R1077	ERJ3GEYJ183	M.RESISTOR CH 3W 18K	1	
R2001, 02	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	2	
R2003	ERJ3GEYJ272	M.RESISTOR CH 3W 2.7K	1	
R2004	ERJ3GEYJ333	M.RESISTOR CH 3W 33K	1	
R2005	ERJ3GEYJ473	M.RESISTOR CH 3W 47K	1	
R2006	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	1	
R2007	ERJ3GEYJ154	M.RESISTOR CH 3W 150K	1	
R2009	ERJ3GEYJ154	M.RESISTOR CH 3W 150K	1	
R2010	ERJ3GEYJ822	M.RESISTOR CH 3W 8.2K	1	
R2011	ERJ3GEYJ563	M.RESISTOR CH 3W 56K	1	
R2012	ERJ3GEYJ274	M.RESISTOR CH 3W 270K	1	
R2013	ERJ3GEYJ154	M.RESISTOR CH 3W 150K	1	
R2014	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R2015	ERJ3GEYJ123	M.RESISTOR CH 3W 12K	1	
R2017	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R2018	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R2019	ERJ3GEYJ105	M.RESISTOR CH 3W 1M	1	
R2020	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	1	
R2021	ERJ3GEYJ000	M.RESISTOR CH 3W 0.00	1	
R2022	ERJ3GEYJ271	M.RESISTOR CH 3W 270	1	
R2025	ERJ3GEYJ393	M.RESISTOR CH 3W 39K	1	
R2028	ERJ3GEYJ105	M.RESISTOR CH 3W 1M	1	
R2029	ERJ3GEYJ153	M.RESISTOR CH 3W 15K	1	
R2030	ERJ3GEYJ273	M.RESISTOR CH 3W 27K	1	
R2031	ERJ3GEYJ333	M.RESISTOR CH 3W 33K	1	
R2032	ERJ3GEYJ274	M.RESISTOR CH 3W 270K	1	
R2034	ERJ3GEYJ272	M.RESISTOR CH 3W 2.7K	1	
R2038	ERDS2TJR47	.RESISTOR W	1	
R2040	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R2041	ERJ3GEYJ332	M.RESISTOR CH 3W 3.3K	1	
R2042	ERJ3GEYJ563	M.RESISTOR CH 3W 56K	1	
R2043	ERJ3GEYJ221	M.RESISTOR CH 3W 220	1	
R2044	ERJ3GEYJ820	M.RESISTOR CH 3W 82	1	
R2045	ERJ8GCYJ2R2	M.RESISTOR CH 1/8W 2.2	1	
R2046, 47	ERJ8GCYJ1R8	M.RESISTOR CH 1/8W 1.8	2	
R2048	ERJ3GEYJ153	M.RESISTOR CH 3W 15K	1	
R2049-51	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	3	
R2053, 54	ERJ3GEYJ682	M.RESISTOR CH 3W 6.8K	2	
R2060	ERJ3GEYJ334	M.RESISTOR CH 3W 330K	1	
R2062	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R2066	ERJ3GEYJ221	M.RESISTOR CH 3W 220	1	
R2067-69	ERJ6QMYJ150	M.RESISTOR CH 1/10W 15	3	
R2070-72	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	3	
R2077	ERJ3GEYJ392	M.RESISTOR CH 3W 3.9K	1	
R2079	ERJ3GEYJ152	M.RESISTOR CH 3W 1.5K	1	
R2080	ERJ3GEYJ000	M.RESISTOR CH 3W 0.00	1	
R2085, 86	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	2	
R2087	ERJ3GEYJ000	M.RESISTOR CH 3W 0.00	1	
R2090	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R3801	ERJ3GEYJ471	M.RESISTOR CH 3W 470	1	
R3802	ERJ3GEYJ681	M.RESISTOR CH 3W 680	1	
R3803-05	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	3	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R3806	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R3808	ERJ3GEYJ272	M.RESISTOR CH 3W 2.7K	1	
R3811.12	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	2	
R3813	ERJ3GEYJ153	M.RESISTOR CH 3W 15K	1	
R3814	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R3816	ERJ3GEYJ223	M.RESISTOR CH 3W 22K	1	
R3830	ERJ3GEYJ223	M.RESISTOR CH 3W 22K	1	
R3834	ERJ3GEYJ393	M.RESISTOR CH 3W 39K	1	
R3837	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R3841-44	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	4	
R3845	ERJ3GEYJ123	M.RESISTOR CH 3W 12K	1	
R3846	ERJ3GEYJ101	M.RESISTOR CH 3W 100	1	
R3848	ERJ3GEYJ681	M.RESISTOR CH 3W 680	1	
R3851	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R3858	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R3876	ERJ3GEYJ332	M.RESISTOR CH 3W 3.3K	1	
R3885	ERJ3GEYJ223	M.RESISTOR CH 3W 22K	1	
R3886	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R4001	ERJ3GEYJ100	M.RESISTOR CH 3W 10	1	
R4002	ERJ3GEYJ223	M.RESISTOR CH 3W 22K	1	
R4003	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R4004	ERJ3GEYJ273	M.RESISTOR CH 3W 27K	1	
R4005	ERJ3GEYJ151	M.RESISTOR CH 3W 150	1	
R4006	ERJ3GEYJ184	M.RESISTOR CH 3W 180K	1	
R4007	ERJ3GEYJ332	M.RESISTOR CH 3W 3.3K	1	
R4009	ERJ3GEYJ122	M.RESISTOR CH 3W 1.2K	1	
R4010	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	1	
R4011	ERJ3GEYJ331	M.RESISTOR CH 3W 330	1	
R4012	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	1	
R4013	ERJ3GEYJ153	M.RESISTOR CH 3W 15K	1	
R4014	ERJ3GEYJ122	M.RESISTOR CH 3W 1.2K	1	
R4016	ERJ3GEYJ181	M.RESISTOR CH 3W 180	1	
R4018	ERJ3GEYJ105	M.RESISTOR CH 3W 1M	1	
R4027	ERJ3GEYJ561	M.RESISTOR CH 3W 560	1	
R4044	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	1	
R4049	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R4052	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R4053	ERJ3GEYJ562	M.RESISTOR CH 3W 5.6K	1	
R4054	ERJ3GEYJ821	M.RESISTOR CH 3W 820	1	
R4055.56	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	2	
R4058.59	ERJ3GEYOR00	M.RESISTOR CH 3W 0.00	2	
R4802	ERJ3GEYJ473	M.RESISTOR CH 3W 47K	1	
R4804	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	1	
R4806	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	1	
R4808	ERJ3GEYJ473	M.RESISTOR CH 3W 47K	1	
R4810	ERJ3GEYJ122	M.RESISTOR CH 3W 1.2K	1	
R4812	ERJ3GEYJ221	M.RESISTOR CH 3W 220	1	
R4814	ERJ3GEYJ333	M.RESISTOR CH 3W 33K	1	
R4816	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	1	
R4817	ERJ3GEYOR00	M.RESISTOR CH 3W 0.00	1	
R4818	ERJ3GEYJ332	M.RESISTOR CH 3W 3.3K	1	
R4819	ERJ3GEYOR00	M.RESISTOR CH 3W 0.00	1	
R4820	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R4824	ERJ3GEYJ334	M.RESISTOR CH 3W 330K	1	
R4825	ERJ8GCYJ221	M.RESISTOR CH 1/8W 220	1	
R4826	ERJ3GEYOR00	M.RESISTOR CH 3W 0.00	1	
R4827	ERJ3GEYJ392	M.RESISTOR CH 3W 39K	1	
R4828	ERJ3GEYJ221	M.RESISTOR CH 3W 220	1	
R4829	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R4839	ERJ3GEYJ221	M.RESISTOR CH 3W 220	1	
R4843	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7	1	
R4845	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R4846	ERJ3GEYJ224	M.RESISTOR CH 3W 220K	1	
R4847	ERJ3GEYJ183	M.RESISTOR CH 3W 18K	1	
R4848	ERJ8GCYJ221	M.RESISTOR CH 1/8W 220	1	
R4849	ERJ3GEYJ224	M.RESISTOR CH 3W 220K	1	
R4853	ERJ3GEYJ224	M.RESISTOR CH 3W 220K	1	
R4855.56	ERJ3GEYJ562	M.RESISTOR CH 3W 5.6K	2	
R4857	ERJ3GEYJ123	M.RESISTOR CH 3W 12K	1	
R4858	ERJ3GEYJ274	M.RESISTOR CH 3W 270K	1	
R4859	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	1	
R4862	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R4863.64	ERJ3GEYJ224	M.RESISTOR CH 3W 220K	2	
R4865.66	ERJ3GEYJ562	M.RESISTOR CH 3W 5.6K	2	
R4868	ERJ8GCYJ121	M.RESISTOR CH 1/8W 120	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R4870	ERJ3GEYJ822	M.RESISTOR CH 3W 8.2K	1	
R4872	ERJ3GEYJ562	M.RESISTOR CH 3W 5.6K	1	
R4873	ERJ3GEYJ124	M.RESISTOR CH 3W 120K	1	
R4876	ERJ8GCYJ101	M.RESISTOR CH 1/8W 100	1	
R4882	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R4883	ERJ3GEYJ124	M.RESISTOR CH 3W 120K	1	
R4885	ERJ8GCYJ560	M.RESISTOR CH 1/8W 56	1	
R4886	ERJ3GEYJ122	M.RESISTOR CH 3W 1.2K	1	
R4887	ERJ3GEYJ471	M.RESISTOR CH 3W 470	1	
R4890.91	ERJ3GEYOR00	M.RESISTOR CH 3W 0.00	2	
R4892.93	ERJ3GEYJ473	M.RESISTOR CH 3W 47K	2	
R5001	ERJ3GEYJ152	M.RESISTOR CH 3W 1.5K	1	
R5002	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R5003-05	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	3	
R5006	ERJ3GEYJ471	M.RESISTOR CH 3W 470	1	
R5007	ERJ3GEYJ681	M.RESISTOR CH 3W 680	1	
R5008	ERJ3GEYOR00	M.RESISTOR CH 3W 0.00	1	
R5009	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R5010	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	1	
R5011.12	ERJ3GEYJ100	M.RESISTOR CH 3W 10	2	
R5013.14	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	2	
R5015.16	ERJ3GEYJ100	M.RESISTOR CH 3W 10	2	
R5017.18	ERJ3GEYJ681	M.RESISTOR CH 3W 680	2	
R5019	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	1	
R5020	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R5021-24	ERJ3GEYJ333	M.RESISTOR CH 3W 33K	4	
R5025	ERJ3GEYJ393	M.RESISTOR CH 3W 39K	1	
R5026	ERJ3GEYJ822	M.RESISTOR CH 3W 8.2K	1	
R5027	ERJ3GEYJ271	M.RESISTOR CH 3W 270	1	
R5028	ERJ3GEYJ391	M.RESISTOR CH 3W 390	1	
R5031-34	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	4	
R5035-38	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	4	
R5040	ERJ8GCYJ4R7	M.RESISTOR CH 1/8W 4.7	1	
R5041.42	ERJ3GEYJ681	M.RESISTOR CH 3W 680	2	
R5043	ERJ3GEYJ684	M.RESISTOR CH 3W 680K	1	
R5044	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	1	
R6001	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R6003	ERJ3GEYJ332	M.RESISTOR CH 3W 3.3K	1	
R6004	ERJ3GEYJ562	M.RESISTOR CH 3W 5.6K	1	
R6005-09	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	5	
R6010	ERJ6QMYJ471	M.RESISTOR CH 1/10W 470	1	
R6011	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R6015-23	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	9	
R6025	ERJ6QMYJ391	M.RESISTOR CH 1/10W 390	1	
R6027	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R6029	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R6030.31	ERJ3GEYJ152	M.RESISTOR CH 3W 1.5K	2	
R6032-39	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	8	
R6040	ERJ3GEYJ473	M.RESISTOR CH 3W 47K	1	
R6041	ERJ3GEYJ154	M.RESISTOR CH 3W 150K	1	
R6042	ERJ3GEYJ184	M.RESISTOR CH 3W 180K	1	
R6043-45	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	3	
R6046	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R6047-50	ERJ3GEYJ473	M.RESISTOR CH 3W 47K	4	
R6051	ERJ3GEYJ184	M.RESISTOR CH 3W 180K	1	
R6052	ERJ3GEYJ393	M.RESISTOR CH 3W 39K	1	
R6053	ERJ3GEYJ392	M.RESISTOR CH 3W 3.9K	1	
R6054-56	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	3	
R6058	ERJ3GEYJ272	M.RESISTOR CH 3W 2.7K	1	
R6059.60	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	2	
R6062	ERJ3GEYJ224	M.RESISTOR CH 3W 220K	1	
R6063	ERJ3GEYJ394	M.RESISTOR CH 3W 390K	1	
R6064	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R6065	ERJ3GEYJ473	M.RESISTOR CH 3W 47K	1	
R6066	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R6067	ERJ3GEYJ563	M.RESISTOR CH 3W 56K	1	
R6068	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R6069	ERJ3GEYJ184	M.RESISTOR CH 3W 180K	1	
R6070	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R6071	ERJ3GEYJ184	M.RESISTOR CH 3W 180K	1	
R6072	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R6073	ERJ6QMYJ391	M.RESISTOR CH 1/10W 390	1	
R6074.75	ERJ8GCYJ331	M.RESISTOR CH 1/8W 330	2	
R6076	ERJ8GCYJ271	M.RESISTOR CH 1/8W 270	1	
R6077-79	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	3	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C8006-18	ECUM1H1032FV	C. CAPACITOR CH 50V 0.01U	13		L8013	VLQEL04X150K	COIL	H 1	
C8019	ECEA1EK4R7	E. CAPACITOR 25V 4.7U	1		L8014	VLQEL05T681K	COIL	H 1	
C8020	ECEA1EK02R2	E. CAPACITOR 25V 2.2U	1		L8015	VLQEL04X121K	COIL	H 1	
C8021	ECUM1H1032FV	C. CAPACITOR CH 50V 0.01U	1		L8016	VLQEL05T101K	COIL	H 1	
C8022	ECEA1EK03R3	E. CAPACITOR 25V 3.3U	1		L8017	VLQEL04X101K	COIL	H 1	
C8023, 24	ECUM1H1032FV	C. CAPACITOR CH 50V 0.01U	2		L8018	VLQEL05T101K	COIL	H 1	
C8025	ECEA0JKA101	E. CAPACITOR 6.3V 100U	1						
C8026	ECUM1H030CCV	C. CAPACITOR CH 50V 3P	1				CONNECTORS		
C8027	ECUM1H102KBV	C. CAPACITOR CH 50V 1000P	1		F3001	VJS2237	CONNECTOR	1	
C8028	ECEA0JSJ151	E. CAPACITOR 6.3V 150U	1		F3002	VJP2263	CONNECTOR	1	
C8029	ECUM1H1032FV	C. CAPACITOR CH 50V 0.01U	1						
C8030	ECUM1H101JCV	C. CAPACITOR CH 50V 100P	1						
C8031-35	ECUM1H1032FV	C. CAPACITOR CH 50V 0.01U	5				TRANSISTORS		
C8036	ECUM1C4742FM	C. CAPACITOR CH 16V 0.47U	1		Q3001	2SD1819	TRANSISTOR	1	
C8037	ECUM1H680JCV	C. CAPACITOR CH 50V 68P	1		Q3002	2SC3931	TRANSISTOR	1	
C8038	ECUM1H332KBV	C. CAPACITOR CH 50V 3300P	1		Q3003	2SD1819	TRANSISTOR	1	
C8039	ECEA1HK0R1	E. CAPACITOR 50V 0.1U	1		Q3005, 06	2SD1819	TRANSISTOR	2	
C8043	ECUM1C1042FV	C. CAPACITOR CH 16V 0.1U	1		Q3007	2SC3931	TRANSISTOR	1	
C8045	ECUM1H390JCV	C. CAPACITOR CH 50V 39P	1		Q3008	2SD1819	TRANSISTOR	1	
C8047, 48	ECUM1H1032FV	C. CAPACITOR CH 50V 0.01U	2		Q3010	2SD1819	TRANSISTOR	1	
C8049	ECEA0JSJ220	E. CAPACITOR 6.3V 22U	1		Q3012	2SC3931	TRANSISTOR	1	
C8050	ECUM1H151JCN	C. CAPACITOR CH 50V 150P	1		Q3013, 14	2SB1218	TRANSISTOR	2	
C8053	ECUM1H1042FN	C. CAPACITOR CH 50V 0.1U	1		Q3015	2SC3931	TRANSISTOR	1	
					Q3020, 21	2SD1819	TRANSISTOR	2	
		DIODES							
D02	MA110	DIODE	1				COMBINATION PARTS		
D3003, 04	MA141K	DIODE	2		QR10	GN1L32	TRANSISTOR-RESISTOR	1	
D3005	MA165	DIODE	1		QR3001	GA1F4M-T1	TRANSISTOR-RESISTOR	1	
					QR3006	GA1L4M-T1	TRANSISTOR-RESISTOR	1	
		DELAY			QR3008	GA1F4M-T1	TRANSISTOR-RESISTOR	1	
DL8001	VL00174	DELAY	1		QR8001	FMG1-T98	TRANSISTOR-RESISTOR	1	
					QR8004, 05	GA1F4M-T1	TRANSISTOR-RESISTOR	2	
		FILTERS			QR8006	FMW1-T98	TRANSISTOR-RESISTOR	1	
FL3001	ELB4C014	FILTER	1		QR8007	FMG2-T98	TRANSISTOR-RESISTOR	1	
FL3002	VLFO806	FILTER	1						
FL3003	ELB4A020	FILTER	1				RESISTORS		
FL8001	ELB4B010	FILTER	1		R01	ERJ3GEYJ224	M. RESISTOR CH 3W 220K	1	
FL8002	ELB4B048	FILTER	1		R02, 03	ERJ3GEYJ103	M. RESISTOR CH 3W 10K	2	
FL8003	VLFO769	FILTER	1		R04	ERJ3GEYJ225	M. RESISTOR CH 3W 2.2M	1	
FL8008	ELB4B024	FILTER	1		R07, 08	ERJ3GEYJ472	M. RESISTOR CH 3W 4.7K	2	
FL8009	VLFO750	FILTER	1		R09	ERJ3GEYJ221	M. RESISTOR CH 3W 220	1	
					R11	ERJ3GEYJ102	M. RESISTOR CH 3W 1K	1	
		ICS			R13	ERJ3GEYJ393	M. RESISTOR CH 3W 39K	1	
IC01	AN3237FA	IC	1		R14	ERJ3GEYJ133	M. RESISTOR CH 3W 13K	1	
IC3001	VEFH08D	IC	1		R15	ERJ3GEYJ563	M. RESISTOR CH 3W 56K	1	
IC3002	MST001MS	IC	1		R16	VRRD2EJ471B	. RESISTOR W	1	
IC3003	AN3580SB	IC	1		R22	ERJ3GEYJ394	M. RESISTOR CH 3W 390K	1	
IC3004	TL8809F	IC	1		R23	ERJ3GEYJ153	M. RESISTOR CH 3W 15K	1	
IC8001	MS2059AFP	IC	1		R24, 25	VRRD2EG152A	. RESISTOR W	2	
					R26	ERJ3GEYJ271	M. RESISTOR CH 3W 270	1	
					R28	VRRD3EJ473A	. RESISTOR W	1	
					R29	ERJ3GEYJ564	M. RESISTOR CH 3W 560K	1	
L3001, 02	VLQEL05T101K	COIL	H 2		R31, 32	VRRD3FF1002B	V. RESISTOR 10K	2	
L3003	VLQEL04X180K	COIL	H 1		R35	VRRD2FF3001B	. RESISTOR W	1	
L3004	VLQEL04X121K	COIL	H 1		R36	VRRD2FF1501B	V. RESISTOR 1.5K	1	
L3005	VLQEL04X101K	COIL	H 1		R37	VRRD3FF8201B	V. RESISTOR 82K	1	
L3007	VLQEL05T101K	COIL	H 1		R40, 41	VRRD3FF7501B	. RESISTOR W	2	
L3008	VLQEL04X101K	COIL	H 1		R42, 43	VRRD3FF1302B	. RESISTOR W	2	
L3009	VLQEL05T101K	COIL	H 1		R47	VRRD3FF1302B	. RESISTOR W	1	
L3010	VLQEL04X330K	COIL	H 1		R49	VRRD3FF2202B	. RESISTOR W	1	
L3011	VLQEL04X151K	COIL	H 1		R51	ERJ3GEYJ103	M. RESISTOR CH 3W 10K	1	
L3012	VLQEL04X150K	COIL	H 1		R3001, 02	ERJ3GEYJ561	M. RESISTOR CH 3W 560	2	
L3013	VLQEL05T101K	COIL	H 1		R3003, 04	ERJ3GEYJ102	M. RESISTOR CH 3W 1K	2	
L3015	VLQEL04X470K	COIL	H 1		R3005	ERJ3GEYJ272	M. RESISTOR CH 3W 2.7K	1	
L3016	VLQEL04X181K	COIL	H 1		R3006	ERJ3GEYJ182	M. RESISTOR CH 3W 1.8K	1	
L3017	VLQEL04X100K	COIL	H 1		R3007	ERJ3GEYJ561	M. RESISTOR CH 3W 560	1	
L3018	VLQEL04X221K	COIL	H 1		R3008	ERJ3GEYJ102	M. RESISTOR CH 3W 1K	1	
L3020	VLQEL04X470K	COIL	H 1		R3010	ERJ3GEYJ102	M. RESISTOR CH 3W 1K	1	
L8002	VLQEL04X101K	COIL	H 1		R3011	ERJ3GEYJ821	M. RESISTOR CH 3W 820	1	
L8003	VLQEL05T331K	COIL	H 1		R3012	ERJ3GEYJ102	M. RESISTOR CH 3W 1K	1	
L8012	VLQEL05T101K	COIL	H 1		R3013, 14	ERJ3GEYJ273	M. RESISTOR CH 3W 27K	2	


Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R3015	ERJ3GEYJ821	M.RESISTOR CH 3W 820	1	
R3016, 17	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	2	
R3019	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R3021	ERJ3GEYJ152	M.RESISTOR CH 3W 1.5K	1	
R3022	ERJ3GEYOR00	M.RESISTOR CH 3W 0.00	1	
R3023, 24	ERJ3GEYJ223	M.RESISTOR CH 3W 22K	2	
R3025	ERJ3GEYJ181	M.RESISTOR CH 3W 180	1	
R3026	ERJ3GEYJ101	M.RESISTOR CH 3W 100	1	
R3028	ERJ3GEYJ682	M.RESISTOR CH 3W 6.8K	1	
R3029	ERJ3GEYJ123	M.RESISTOR CH 3W 12K	1	
R3030	ERJ3GEYJ391	M.RESISTOR CH 3W 390	1	
R3031	ERJ3GEYJ123	M.RESISTOR CH 3W 12K	1	
R3032	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R3033	ERJ3GEYJ471	M.RESISTOR CH 3W 470	1	
R3034	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R3035	ERJ3GEYJ750	M.RESISTOR CH 3W 75	1	
R3036, 37	ERJ3GEYJ223	M.RESISTOR CH 3W 22K	2	
R3039	ERJ3GEYJ331	M.RESISTOR CH 3W 330	1	
R3040	ERJ3GEYJ471	M.RESISTOR CH 3W 470	1	
R3041	ERJ3GEYJ821	M.RESISTOR CH 3W 820	1	
R3042	ERJ6GMVJ102	M.RESISTOR CH 1/10W 1K	1	
R3043	ERJ3GEYJ271	M.RESISTOR CH 3W 270	1	
R3044	ERJ3GEYJ680	M.RESISTOR CH 3W 68	1	
R3045, 46	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	2	
R3049, 50	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	2	
R3052	ERJ3GEYJ333	M.RESISTOR CH 3W 33K	1	
R3053	ERJ3GEYJ153	M.RESISTOR CH 3W 15K	1	
R3054	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R3059	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R3062	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R3063	ERJ3GEYJ562	M.RESISTOR CH 3W 5.6K	1	
R3068, 69	ERJ3GEYJ822	M.RESISTOR CH 3W 8.2K	2	
R3071	ERJ3GEYJ392	M.RESISTOR CH 3W 3.9K	1	
R3072	ERJ3GEYJ561	M.RESISTOR CH 3W 560	1	
R3073	ERJ3GEYJ101	M.RESISTOR CH 3W 100	1	
R3074	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R3075	ERJ3GEYJ681	M.RESISTOR CH 3W 680	1	
R3076	ERJ3GEYJ391	M.RESISTOR CH 3W 390	1	
R3077	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R3080	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R3081	ERJ3GEYJ561	M.RESISTOR CH 3W 560	1	
R3082	ERJ3GEYJ122	M.RESISTOR CH 3W 1.2K	1	
R3083	ERJ3GEYJ272	M.RESISTOR CH 3W 2.7K	1	
R3084	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R3085	ERJ3GEYJ122	M.RESISTOR CH 3W 1.2K	1	
R3086	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R3087	ERJ3GEYJ104	M.RESISTOR CH 3W 100K	1	
R3088	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R3089	ERJ3GEYOR00	M.RESISTOR CH 3W 0.00	1	
R3091	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	1	
R3092	ERJ3GEYOR00	M.RESISTOR CH 3W 0.00	1	
R3093	ERJ3GEYJ101	M.RESISTOR CH 3W 100	1	
R3094	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R3095	ERDS27J105	C.RESISTOR 1/4W 1000K	1	
R8001-03	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	3	
R8004	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R8005	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R8006	ERJ3GEYJ103	M.RESISTOR CH 3W 10K	1	
R8007	ERJ6GMVJ225	M.RESISTOR CH 1/10W 2.2M	1	
R8008	ERJ3GEYJ271	M.RESISTOR CH 3W 270	1	
R8009	ERJ3GEYJ122	M.RESISTOR CH 3W 1.2K	1	
R8010	ERJ3GEYJ821	M.RESISTOR CH 3W 820	1	
R8011	ERJ3GEYJ472	M.RESISTOR CH 3W 4.7K	1	
R8012	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R8013	ERJ3GEYJ563	M.RESISTOR CH 3W 56K	1	
R8014	ERJ3GEYJ222	M.RESISTOR CH 3W 2.2K	1	
R8015	ERJ3GEYJ182	M.RESISTOR CH 3W 1.8K	1	
R8017	ERJ3GEYJ822	M.RESISTOR CH 3W 8.2K	1	
R8018	ERJ3GEYJ153	M.RESISTOR CH 3W 15K	1	
R8020	ERJ3GEYJ182	M.RESISTOR CH 3W 1.8K	1	
R8025, 26	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	2	
R8027	ERJ3GEYJ433	M.RESISTOR CH 3W 43K	1	
R8028	ERJ3GEYJ182	M.RESISTOR CH 3W 1.8K	1	
R8029	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R8101	ERJ3GEYJ223	M.RESISTOR CH 3W 22K	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R8103	ERJ3GEYJ473	M.RESISTOR CH 3W 47K	1	
R8105	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	1	
R8106	ERJ3GEYJ272	M.RESISTOR CH 3W 2.7K	1	
R8107, 08	ERJ3GEYJ102	M.RESISTOR CH 3W 1K	2	
R8109	ERJ3GEYJ272	M.RESISTOR CH 3W 2.7K	1	
R8110	ERJ3GEYJ182	M.RESISTOR CH 3W 1.8K	1	
R8111	ERJ3GEYJ223	M.RESISTOR CH 3W 22K	1	
R8112	ERJ6GMVJ223	M.RESISTOR CH 1/10W 22K	1	
R8113	ERJ3GEYJ182	M.RESISTOR CH 3W 1.8K	1	
R8116	ERJ3GEYJ473	M.RESISTOR CH 3W 47K	1	
R8133	ERJ3GEYOR00	M.RESISTOR CH 3W 0.00	1	
VR3001, 02	EVM7JSX30B23	V.RESISTOR	2	
VR3003	EVM7JSX30B52	V.RESISTOR 500	1	
VR3004	EVM7JSX30B54	V.RESISTOR 50K	1	
VR3005	EVM7JSX30B52	V.RESISTOR 500	1	
VR8001	EVM7JSX30B13	V.RESISTOR 1K	1	
VR8007	EVM7JSX30B24	V.RESISTOR 20K	1	
X8001	VSX0188	CHRISTAL OSCILLATOR	1	
	■ VEPO6613A	VTR OPERATION C.B.A.	(N/A)	
		DIODES		
D6501	BR3668S	DIODE	1	
D6502, 03	MA141WA	DIODE	2	
D6504	MA141K	DIODE	1	
D6505	MA141WA	DIODE	1	
D6508	MA4033M	DIODE	1	
D6510	MA141WA	DIODE	1	
D6511, 12	MA141K	DIODE	2	
D6514	MA141K	DIODE	1	
D6516-20	BR3668S	DIODE	5	
D6522	BR3668S	DIODE	1	
		CONNECTOR		
P6501	VJP2107	CONNECTOR	1	
		SWITCHES		
SW6501, 02	ESD100127	SWITCH	2	
SW6503-08	EVQQSBO4B	SWITCH	6	
SW6510-12	EVQQSBO4B	SWITCH	3	
SW6514-17	EVQQSBO4B	SWITCH	4	
SW6518	VST0098	SWITCH	1	
	■ VEPO4281B	VTR JACK C.B.A.	(N/A)	
		CAPACITORS		
C4901	ECUM1E1042FN	C.CAPACITOR CH 25V 0.1U	1	
C4902, 03	ECUM1H221JN	C.CAPACITOR CH 50V 220P	2	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
D4902	MA738	DIODE	1	
D4903	MA151WK	DIODE	1	
D4904	MA151WA	DIODE	1	
D4905	MA3056	DIODE	1	
F4901	VJP1610T	CONNECTOR	1	
P4902	VJP1609T	CONNECTOR(MALE)	1	
P4903	VJP1608T	CONNECTOR(MALE)	1	
P4904,05	VJP1611T	CONNECTOR(MALE)	2	
P4906	VJP1244T	CONNECTOR(MALE) 4P	1	
Q4901	2SD601	TRANSISTOR CHIP	1	
QR4901	UN2213	TRANSISTOR-RESISTOR	1	
R4902	ERJ6GMYJ103	M.RESISTOR CH 1/10W 10K	1	
R4903	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
R4904	ERJ6GMYJ101	M.RESISTOR CH 1/10W 100	1	
R4905	ERJ6GMYJ222	M.RESISTOR CH 1/10W 2.2K	1	
R4906	ERJ6GMYJ101	M.RESISTOR CH 1/10W 100	1	
■ VEPOOH73B	FE HEAD C.B.A.	(NLA)		
C1501	ECEA1CKS100	E.CAPACITOR 16V 10U	1	
C1502	ECKF1H472ZF	C.CAPACITOR 50V 4700P	1	
C1503	VCYD1C103MR1	S.CAPACITOR 16V 0.01U	1	
C1504	ECQV1H333JZ	P.CAPACITOR 50V 0.033U	1	
L1501	VLQEL05 F221K	COIL 220UH	1	
Q1504	ZSC2603AE2F	TRANSISTOR	1	
R1503	ERDS2TJ333	C.RESISTOR 1/4W 33K	1	
T1501	EIQ7QT007Q	FILTER	1	
■ VEK4643	E.V.F. CONNECTOR C.B.A.	(NLA)		
J1504	VJJ0163	CONNECTOR	1	
P1505	VJP1614T	CONNECTOR(MALE)	1	
■ VEK4644	REMOTE CONTROL JACK C.B.A.	(NLA)		
VJJ0125	REMOTE CONTROL JACK	1		
■ VEX4730	ZOOM SW, START/STOP SW, SUB START/STOP SW C.B.A.	(NLA)		
EVQQSU04W	SWITCH	2		
■ VES0413	MECHANISM CONNECTION C.B.A.	(NLA)		
Q1503	ON2170	TRANSISTOR	1	
VJP1229R	CONNECTOR	2P	1	
VJP1235T	CONNECTOR	8P	1	
VWX1280	DETECTOR SPACER	1		
VSS0193	MODE SWITCH	1		
■ VEK3414	TAKE-UP PHOTO C.B.A.	(NLA)		
PN158NV	PHOTO Tr.	1		
VMD0606	PHOTO Tr. HOLDER	1		
■ VEX3415	SUPPLY PHOTO C.B.A.	(NLA)		

AC Adaptor

VW-AM10^{EN}_{EM}



SPECIFICATIONS

ITEM	SPECIFICATION
POWER	Source: 100~240 V AC 50/60 Hz (Automatic Voltage Adjustment)
	Consumption: 44 watts
	Output: DC 12V, 1.8A for VHS Movie DC 12V, 1.5A for battery charge
DIMENSIONS	80(W) × 54(H) × 196(D) mm
WEIGHT	Approx. 0.62 kg

Weight and dimensions shown are approximate.
Specifications are subject to change without notice.


CAUTION: FOR USE WITH VHS VIDEO MOVIE, MODEL NV-M1000.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE.

CONTENTS

1. CONTROLS AND COMPONENTS	1
2. DISASSEMBLY METHOD	1
3. ELECTRICAL ADJUSTMENT PROCEDURES	2
4. MAIN C.B.A. (VEP61058A), SECONDARY SUB MAIN C.B.A. (VEP60190A) & FRONT PANEL C.B.A. (VEP60182A)	3
5. AC ADAPTOR SCHEMATIC DIAGRAM	5
6. EXPLODED VIEW	8
❶ CHASSIS & FRAME SECTION	8
7. MECHANICAL REPLACEMENT PARTS LIST	9
8. ELECTRICAL REPLACEMENT PARTS LIST	9

1. CONTROLS AND COMPONENTS



- ① Power Indicator
- ② Charging Indicator
- ③ DC Output Socket
- ④ Battery Pack Charging Socket
- ⑤ Power On/Off Switch
- ⑥ Mains Lead

2. DISASSEMBLY METHOD

1. REMOVAL OF TOP CASE AND BOTTOM CASE

- (1) Unscrew 4 Screws (A) and then remove the Top Case and Bottom Case.




Fig. 1

2. REMOVAL OF FRONT PANEL

- (1) Remove the Front Panel disconnecting the connector P1.




Fig. 2

3. REMOVAL OF MAIN C.B.A.

- (1) Unscrew 3 Screws (B) and then remove the Top Shield.
- (2) Unscrew the Screw (C) and then remove the Bottom Shield.




Fig. 3

4. REMOVAL OF FRONT PANEL C.B.A.

- (1) Unscrew 2 Screws (D).
- (2) While pushing 2 Portions of the DC Output Socket and the Battery Pack Charging Socket, Remove the Front Panel C.B.A.




Fig. 4

3. ELECTRICAL ADJUSTMENT PROCEDURES

This section provides complete electrical adjustment procedures which may be required for electronic circuit of the AC Adaptor.

3-1. TEST EQUIPMENT

To perform the electrical adjustments completely following equipments are required.

1. D.V.M. (Digital Volt Meter)
Voltage Range : 0.001~50V
2. Oscilloscope
Voltage Range : 0.005~50V/div
3. DC Ammeter
Current Range : 0~10A
4. DC Voltmeter
Voltage Range : 0~20V
5. Plastic Tip Driver
6. Resistor (5ohm Variable 200W)
7. DC Power Supply (5A/20V)

3-2. INITIAL CHARGE CURRENT AND SCHMITT VOLTAGE ADJUSTMENT

TP	ADJ.	MODE	INPUT
BATTERY HOLDER (+) (-)	VR201 VR202	CHARGE	
TAPE	M. EQ.	SPEC.	
	DC AM/ D.V.M.	A=1.5+-0.005[A] VR201 From High to Low VR202	

1. Make the connection as shown below.





Fig. 5

2. Adjust the output of the DC power supply that the indication of the DC voltmeter becomes 14.0V and adjust R1 so that indication of the DC ammeter (A2) becomes 3.0A.
3. Adjust VR201 so that the indication of the ammeter (A1) becomes 1.5+-0.05A.
4. Adjust the output level of the DC power supply to 15.3V.
5. Adjust the VR202 so that voltage at TP201 changed from high (approx. 15V) to (approx. 0.5).

It is also available to use a resistor 5ohm/50W 2 pieces of 10ohm/20W resistors in parallel use equivalent, instead of variable resistor 5ohm/200W to get specified current.


4. MAIN C.B.A. (VEP61058A), SECONDARY SUB MAIN C.B.A. (VEP60190A) & FRONT PANEL C.B.A. (VEP60182A)




MAIN C.B.A. & SECONDARY SUB MAIN C.B.A.	
Transistor	
Q101	B-4
Q201	C-1
Q202	C-2
Transistor & Resistor	
QR101	B-5
Integrated Circuit	
IC001	B-3
IC002	A-3
IC101	A-5
IC201	C-1
IC202	C-2
IC203	C-1
Test Point	
TP201	C-2
Adjustment	
VR201	C-2
VR202	C-2
Connector	
P1	C-4
P1	B-5

ADDRESS INFORMATION

5. AC ADAPTOR SCHEMATIC DIAGRAM



1 CHASSIS & FRAME SECTION



8. ELECTRICAL REPLACEMENT PARTS LIST

Note:1.* Be sure to make your orders of replacement parts according to this list.

2.IMPORTANT SAFETY NOTICE

Components identified with the mark (!) have the special characteristics for safety. When replacing any of these components, use only the same type.

3.Unless otherwise specified,
All resistors are in OHMS, K=1.000 OHMS. All capacitors are in MICROFARADS (uF), P=nanofarad.

4.The P.C.Board units marked with " " show below the main assembled parts.

[illegible]

7. MECHANICAL REPLACEMENT PARTS LIST

Note: 1. * Be sure to make your orders of replacement parts according to this list.
2. IMPORTANT SAFETY NOTICE
Components identified with the mark (!) have the special characteristics for safety. When replacing any of these components, use only the same type.

[illegible]

8. ELECTRICAL REPLACEMENT PARTS LIST

Note: 1. * Be sure to make your orders of replacement parts according to this list.

2. **IMPORTANT SAFETY NOTICE**
Components identified with the mark (!) have the special characteristics for safety. When replacing any of these components, use only the same type.


3. Unless otherwise specified,
All resistors are in OHMS, $K=1,000$ OHMS. All capacitors are in MICRO-FARADS (uf), $P=uuf$.

4. The P.C.Board units marked with 'M' show below the main assembled parts.

[illegible][illegible][illegible]

Line Adaptor

VW-KM10EN



SPECIFICATIONS

ITEM	SPECIFICATION
POWER	Source: DC 12V
	Consumption: 0.4W (DC 12V)
VIDEO	Input: VIDEO IN connector (Phono type) 1.0V _{p-p} , 75Ω terminated
AUDIO	Input: AUDIO IN connector (Phono type) -1.0dB, 47kΩ terminated
DIMENSIONS	85 mm(W) × 27 mm(H) × 100 mm(D)
WEIGHT	120 g

Weight and dimensions shown are approximate.
Specifications are subject to change without notice.


CONTENTS

1. CONNECTION DIAGRAM	1
2. MAIN C.B.A.	2
3. LINE ADAPTOR SCHEMATIC DIAGRAM	3
4. EXPLODED VIEW	5
❶ CASING PARTS SECTION	5
❷ PACKING PARTS SECTION	6
5. MECHANICAL REPLACEMENT PARTS LIST	7
6. ELECTRICAL REPLACEMENT PARTS LIST	8


1. CONNECTION DIAGRAM

Before connecting, make sure that the Operation On/Off Switch of the VHS Movie is in the "OFF" position.

- It is also possible to use the Battery Pack or Car Battery Cord instead of the AC Adaptor.



2. MAIN C.B.A. (VEP60199A)



3. LINE ADAPTOR SCHEMATIC DIAGRAM

10P PLUG (TO DECK)

A. GND (R)	1
12V (+B)	2
A. IN (R)	3
A. GND (L)	4
AUX (L)	5
GND (+B)	6
Y. IN	7
Y/C GND	8
C. IN	9
A. IN (L)	10


VIDEO IN

AUDIO IN (L)


AUDIO IN (R)

NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE REFER TO PARTS LIST.

4. EXPLODED VIEW
① CASING PARTS SECTION



② PACKING PARTS SECTION



5. MECHANICAL REPLACEMENT PARTS LIST

Note: 1. * Be sure to make your orders of replacement parts according to this list.
2. **IMPORTANT SAFETY NOTICE**
Components identified with the mark (⚠) have the special characteristics for safety. When replacing any of these components, use only the same type.

[illegible][illegible]

6. ELECTRICAL REPLACEMENT PARTS LIST

Note: 1. * Be sure to make your orders of replacement parts according to this list.
2. IMPORTANT SAFETY NOTICE
Components identified with the mark (!) have the special characteristics for safety. When replacing any of these components, use only the same type.
3. Unless otherwise specified,
All resistors are in OHMS, K=1,000 OHMS. All capacitors are in MICRO-FARADS (uF). P=ohm.
4. The P.C. Board units marked width "W" show below the main assembled parts.

[illegible][illegible]